


# TX6 PLUS UTP Keyed Jack Module


Part Number: CJK688TG\*\*


© Panduit Corp. 2008


# **INSTALLATION INSTRUCTIONS PN458A**





# **TERMINATION STEPS**























<sup>\*\*</sup> Denotes color.


#### **INSTALLATION INSTRUCTIONS PN458A**








## REMOVAL STEPS







### Notes:

- 1. For specified performance, follow TIA/EIA 568-B installation guidelines.
- Jack Modules can terminate PVC or Plenum rated 22-26 AWG solid or stranded IWC cable with 0.048 inch (1.2 mm) maximum insulated conductor outside diameter.
- 3. Jack Modules may be re-terminated a minimum of 20 times.
- 4. On cable end 2 for A & B wiring and cable end 1 of A wiring, wrap the designated pairs around the proper center dividing post (A or B) and terminate in the proper location.
- 5. For technical and performance information, consult PANDUIT Technical Support.

## As with all Communication Components, the following statements apply:

- 1. Never install communications wiring during a lightning storm.
- 2. Never install communications wiring in wet locations unless the jack is specifically designed for use in wet locations.
- 3. Never touch uninsulated communications wiring or terminals unless the communication line has been disconnected at the network interface.
- 4. Use caution when installing or modifying communication wiring.

For Instructions in Local Languages and Technical Support:

http://www.panduit.com/resources/install\_maintain.asp



E-mail: cs@panduit.com Fax:

(708) 444-6993