

# PSL-WS1A Installation Procedure

## WARNING!

- 1. VERIFICATION OF DE-ENERGIZED CONDITION:**  
Operate the switch controlled equipment & use voltage tester to make sure all related power sources are de-energized.
- 2. BLOCKING VERIFICATION TEST:**  
If the switch actuator can be moved to the ON position (after installing the Universal Wall Switch Lockout) **DO NOT** use this lockout.
- 3. DO NOT** lock switch in ON position when it is unsafe to do so.
- 4. APPROPRIATE USE of Universal Wall Switch Lockout** is the sole responsibility of the user in relation to compliance with OSHA Lockout/Tagout regulations.
- 5. Keep out of reach of children.**

Ask for these additional lockout products at your local Panduit distributor:

**Circuit Breaker Lockout Devices:**

(PSL-CB, -CBL, -CBIL, -CBNT, -CBILNT, -PCB, -PCBNT)

**Disconnect Switch/Universal Gate Valve**

**Lockout Device:** (PSL-MLD)

**Wall Switch Lockout Devices**

(PSL-WS, -WS1A)

**Plug Lockout Devices:** (PSL-P)

**Lockout Kits:**

(PSL-PK-EA, PSL-KT-CONA, PSL-KT-MROA, PSL-KT-PWR)

**Receptacle Lockout Device:** (PSL-ERB)

**Lockout Stations:**

(PSL-20SWCA, -10SWCA, -4SWCA)

**Lockout Training Programs:** (PSL-LTP, -LTSP)

**Gate Valve Lockout Devices:**

(PSL-V\* in multiple colors and sizes)

**Ball Valve Lockout Devices:**

(PSL-BV1, -BV2, -BV3, -BFV)

**Padlocks:**

(PSL-6, -7, -8, -9, -12 in multiple colors and shackle lengths)

**Safety Signs and Tags**

# PANDUIT

## Universal Wall Switch Lockout

Part Number: PSL-WS1A

© Panduit Corp. 2014

GMPSSL-INWS1

For locking out electrical supply controlled by ordinary toggle and rocker switches.

Can be used to lock switch in on or off position.

Quick installation with standard screwdriver.

**PANDUIT**  
www.panduit.com

E-mail:  
techsupport@panduit.com

Phone:  
866-405-6654



# PSL-WS1A Installation Instructions

## Installation on Toggle Switch

1. Place switch in off position. Remove screws from the switch cover plate. Reinsert through lockout's top keyhole & middle hole. Tighten both screws.
2. Lower flap on the lockout, wording on flap will read "Locked Off". Secure with a padlock.
3. Verify that switch actuator cannot be repositioned to ON position.
4. To install on 3-way or multiple switches make sure all switches are off regardless of actuator position. Lockout may have to be installed upside down (flap will read "Locked On") in order to lock the 3-way switch in OFF position.
5. Hang a warning tag with appropriate instructions.
6. To lock the switch in ON position, turn the universal wall switch lockout upside down, leave the switch in ON position. Remove the switch cover plate screws and reinsert through the lockout with the keyhole side down and middle hole of lockout up. Tighten the screws and close the lockout flap. Printed letters will read "LOCKED ON", secure with a padlock. Hang a warning tag with the appropriate instructions.

## Installation on Rocker Switch

1. Place switch in OFF position, lower half of the switch actuator will be flush with the switch cover plate. Remove screws from the switch cover plate. Use longer screws provided with the package. Insert screws through the lockout's keyhole & hole at the end of the lockout plate. Tighten screws.
2. Follow Steps 2 - 5 as described in Toggle Switch Installation.
3. To lock Rocker switch in ON position follow instruction #6 as described in Toggle Switch Installation except use end hole instead of middle hole.



"Our products are warranted to be free from defects in material and workmanship at the time of sale but our obligation under this warranty is limited to the replacement of any product proved to be defective within six months (for product) or 90 days (for tools) from the date of delivery. Tool warranty is void if Panduit tools are modified, altered or misused in any way. Use of Panduit tooling with any product other than the specified Panduit products for which the tool was designed, constitutes misuse. Before using, user shall determine the suitability of the product for his intended use and user assumes a risk and liability whatsoever in connection therewith. This warranty is made in lieu of and excludes all other warranties, expressed or implied. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR USE ARE SPECIFICALLY EXCLUDED. Neither seller nor manufacturer shall be liable for any other injury, loss or damage whether direct or consequential, arising out of the use of or the inability to use the product."