

PRODUCT-DETAILS

1785-803

Rocker for Switch/push button, Two-part rocker grey metallic - 63x63



Informations générales

Extension du type de produit	1785-803
Code de produit	2CKA001751A3018
EAN	4011395110874
Description courte	Rocker for Switch/push button, Two-part rocker grey metallic - 63x63
Description longue	For flush-mounted switch 2g 1w, 2g push switch.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	No document needed
Application	Switch/push button
Design Range	63x63 Busch-axcent Busch-axcent pur solo
Type de montage	Flush Mounted

Type of Fastening	Clamp
Finition de surface	Untreated Glossy
Matériau	Thermoplastic
Model Number	Two-part rocker
Couleur	grey metallic

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E1934
REACH Declaration	2CKA309999E9999
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Produit Largeur Net	63 mm
Produit Hauteur Net	63 mm
Produit Longueur Net	20 mm
Poids net	0.029 kg
Schéma dimensionnel	2CKA000097E0409

Commande

ID du produit remplacé	1751-0-3018
------------------------	-------------

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E1934
--------------------------------	-----------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144002

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001012A1150	Flush Mounted Inserts Series switch 2000/5 US-500		1	piece

2CKA001012A2108	Flush Mounted Inserts Series switch 2000/5 US-507		1	piece
2CKA001012A1135	Switch insert Series switch with Neon lamp	2000/5 USGL	1	piece
2CKA001011A0928	Flush Mounted Inserts Alternating-/alternating switch	2000/6/6US-101-500	1	piece
2CKA001012A2238	Flush Mounted Inserts Series switch with LED not exchangeable	2400/5 USK-500	1	piece
2CKA001022A0663	Flush Mounted Inserts Alternating-/alternating switch	2400/6/6US-101-500	1	piece
2CKA001754A4240	Cover Frame 1gang anthracite - future linear	1721-181K	1	piece
2CKA001754A4168	Cover Frame 1gang ivory white - future	1721-182	1	piece
2CKA001754A4506	Cover Frame 1gang ivory white - future linear	1721-182K-500	1	piece
2CKA001754A4529	Cover Frame 1gang aluminium silver - future linear	1721-183K-500	1	piece
2CKA001754A4173	Cover Frame 1gang studio white - future	1721-184	1	piece
2CKA001754A4527	Cover Frame 1gang studio white - future linear	1721-184 NSK-500	1	piece
2CKA001754A4504	Cover Frame 1gang studio white - future	1721-184-500	1	piece
2CKA001754A4498	Cover Frame 1gang studio white - future linear	1721-184K-500	1	piece
2CKA001754A4775	Cover Frame 1gang glass purple - Busch-axcent pur	1721-223	1	piece
2CKA001754A4760	Cover Frame 1gang glass sun - Busch-axcent pur	1721-225	1	piece
2CKA001754A4770	Cover Frame 1gang glass avocado - Busch-axcent pur	1721-226	1	piece
2CKA001754A4765	Cover Frame 1gang glass coral - Busch-axcent pur	1721-227	1	piece
2CKA001754A4755	Cover Frame 1gang glass ocean - Busch-axcent pur	1721-228	1	piece
2CKA001754A4780	Cover Frame 1gang glass oyster - Busch-axcent pur	1721-229	1	piece
2CKA001754A4790	Cover Frame 1gang paper brown - Busch-axcent pur	1721-243	1	piece
2CKA001754A4800	Cover Frame 1gang glass black - Busch-axcent pur	1721-245	1	piece
2CKA001754A4785	Cover Frame 1gang paper blue - Busch-axcent pur	1721-248	1	piece
2CKA001754A4688	Cover Frame 1gang platinum - Busch-axcent pur	1721-270-500	1	piece
2CKA001754A4708	Cover Frame 1gang black matt - Busch-axcent pur	1721-275-500	1	piece
2CKA001754A4698	Cover Frame 1gang titanium - Busch-axcent pur	1721-276-500	1	piece
2CKA001754A4437	Cover Frame 1gang white glass - Busch-axcent pur	1721-280	1	piece
2CKA001754A4409	Cover Frame 1gang black - Busch-axcent	1721-281	1	piece
2CKA001753A4126	Cover Frame 1gang black - Busch-axcent flat	1721-281/11	1	piece
2CKA001754A4543	Cover Frame 1gang brown glass - Busch-axcent pur	1721-283	1	piece
2CKA001754A4331	Cover Frame 1gang studio white - Busch-axcent	1721-284	1	piece
2CKA001753A4121	Cover Frame 1gang studio white - Busch-axcent flat	1721-284/11	1	piece
2CKA001754A4334	Cover Frame 1gang yellow - Busch-axcent	1721-285	1	piece
2CKA001754A4337	Cover Frame 1gang green - Busch-axcent	1721-286	1	piece
2CKA001754A4340	Cover Frame 1gang red - Busch-axcent	1721-287	1	piece
2CKA001754A4343	Cover Frame 1gang blue - Busch-axcent	1721-288	1	piece

2CKA001754A4805	Cover Frame 1gang slate grey - Busch-axcent pur	1721-290	1	piece
2CKA001754A4471	Cover Frame 1gang entrée grey - Busch-axcent	1721-291-500	1	piece
2CKA001754A4491	Cover Frame 1gang château-black - Busch-axcent	1721-295-500	1	piece
2CKA001754A4795	Cover Frame 1gang concrete grey - Busch-axcent pur	1721-298	1	piece
2CKA001754A4481	Cover Frame 1gang maison-beige - Busch-axcent	1721-299-500	1	piece
2CKA001754A4535	Cover Frame 1gang chrome - solo	1721-80-500	1	piece
2CKA001754A4538	Cover Frame 1gang chrome gloss - solo	1721-80G-500	1	piece
2CKA001754A4442	Cover Frame 1gang white glass - carat	1721-811	1	piece
2CKA001754A4820	Cover Frame 1gang porcelain anthracite - carat	1721-815	1	piece
2CKA001754A4258	Cover Frame 1gang bronze - carat	1721-821	1	piece
2CKA001754A4356	Cover Frame 1gang gold - carat	1721-823-101	1	piece
2CKA001754A4322	Cover Frame 1gang glass black - carat	1721-825	1	piece
2CKA001754A4360	Cover Frame 1gang chrome - carat	1721-826-101	1	piece
2CKA001754A4605	Cover Frame 1gang anthracite - Busch-Dynasty	1721-831-500	1	piece
2CKA001754A4600	Cover Frame 1gang ivory white - Busch-Dynasty	1721-832-500	1	piece
2CKA001754A4575	Cover Frame 1gang polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	piece
2CKA001754A4565	Cover Frame 1gang polished brass anthracite - Busch-Dynasty	1721-835-500	1	piece
2CKA001754A4570	Cover Frame 1gang polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	piece
2CKA001754A4560	Cover Frame 1gang polished brass ivory white - Busch-Dynasty	1721-838-500	1	piece
2CKA001754A4595	Cover Frame 1gang antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	piece
2CKA001754A4536	Cover Frame 1gang studio white - solo	1721-84-500	1	piece
2CKA001754A4585	Cover Frame 1gang antique brass anthracite - Busch-Dynasty	1721-845-500	1	piece
2CKA001754A4590	Cover Frame 1gang antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	piece
2CKA001754A4580	Cover Frame 1gang antique brass ivory white - Busch-Dynasty	1721-848-500	1	piece
2CKA001754A4254	Cover Frame 1gang stainless steel - carat	1721-860	1	piece
2CKA001754A4500	Cover Frame 1gang stainless steel - Pure Stainless Steel	1721-866K-500	1	piece
2CKA001754A4531	Cover Frame 1gang studio white matt - future linear	1721-884K-500	1	piece
2CKA001754A4532	Cover Frame 1gang black matt - future linear	1721-885K-500	1	piece
2CKA001754A4714	Cover Frame 2gang red - future linear	1722-12-182K-101	1	piece
2CKA001754A4241	Cover Frame 2gang anthracite - future linear	1722-181K	1	piece
2CKA001754A4169	Cover Frame 2gang ivory white - future	1722-182	1	piece
2CKA001754A4231	Cover Frame 2gang ivory white - future linear	1722-182K	1	piece
2CKA001754A4530	Cover Frame 2gang aluminium silver - future linear	1722-183K-500	1	piece
2CKA001754A4174	Cover Frame 2gang studio white - future	1722-184	1	piece
2CKA001754A4508	Cover Frame 2gang studio white - future	1722-184-500	1	piece
2CKA001754A4499	Cover Frame 2gang studio white - future linear	1722-184K-500	1	piece


2CKA001754A4776	Cover Frame 2gang glass purple - Busch-axcent pur	1722-223	1	piece
2CKA001754A4761	Cover Frame 2gang glass sun - Busch-axcent pur	1722-225	1	piece
2CKA001754A4771	Cover Frame 2gang glass avocado - Busch-axcent pur	1722-226	1	piece
2CKA001754A4766	Cover Frame 2gang glass coral - Busch-axcent pur	1722-227	1	piece
2CKA001754A4756	Cover Frame 2gang glass ocean - Busch-axcent pur	1722-228	1	piece
2CKA001754A4781	Cover Frame 2gang glass oyster - Busch-axcent pur	1722-229	1	piece
2CKA001754A4791	Cover Frame 2gang paper brown - Busch-axcent pur	1722-243	1	piece
2CKA001754A4801	Cover Frame 2gang glass black - Busch-axcent pur	1722-245	1	piece
2CKA001754A4786	Cover Frame 2gang paper blue - Busch-axcent pur	1722-248	1	piece
2CKA001754A4689	Cover Frame 2gang platinum - Busch-axcent pur	1722-270-500	1	piece
2CKA001754A4709	Cover Frame 2gang black matt - Busch-axcent pur	1722-275-500	1	piece
2CKA001754A4699	Cover Frame 2gang titanium - Busch-axcent pur	1722-276-500	1	piece
2CKA001754A4438	Cover Frame 2gang white glass - Busch-axcent pur	1722-280	1	piece
2CKA001754A4410	Cover Frame 2gang black - Busch-axcent	1722-281	1	piece
2CKA001753A4127	Cover Frame 2gang black - Busch-axcent flat	1722-281/11	1	piece
2CKA001754A4544	Cover Frame 2gang brown glass - Busch-axcent pur	1722-283	1	piece
2CKA001754A4332	Cover Frame 2gang studio white - Busch-axcent	1722-284	1	piece
2CKA001753A4122	Cover Frame 2gang studio white - Busch-axcent flat	1722-284/11	1	piece
2CKA001754A4335	Cover Frame 2gang yellow - Busch-axcent	1722-285	1	piece
2CKA001754A4338	Cover Frame 2gang green - Busch-axcent	1722-286	1	piece
2CKA001754A4341	Cover Frame 2gang red - Busch-axcent	1722-287	1	piece
2CKA001754A4344	Cover Frame 2gang blue - Busch-axcent	1722-288	1	piece
2CKA001754A4806	Cover Frame 2gang slate grey - Busch-axcent pur	1722-290	1	piece
2CKA001754A4472	Cover Frame 2gang entrée grey - Busch-axcent	1722-291-500	1	piece
2CKA001754A4492	Cover Frame 2gang château-black - Busch-axcent	1722-295-500	1	piece
2CKA001754A4796	Cover Frame 2gang concrete grey - Busch-axcent pur	1722-298	1	piece
2CKA001754A4482	Cover Frame 2gang maison-beige - Busch-axcent	1722-299-500	1	piece
2CKA001754A4537	Cover Frame 2gang chrome - solo	1722-80-500	1	piece
2CKA001754A4327	Cover Frame 2gang chrome gloss - solo	1722-80G	1	piece
2CKA001754A4443	Cover Frame 2gang white glass - carat	1722-811	1	piece
2CKA001754A4821	Cover Frame 2gang porcelain anthracite - carat	1722-815	1	piece
2CKA001754A4259	Cover Frame 2gang bronze - carat	1722-821	1	piece
2CKA001754A4357	Cover Frame 2gang gold - carat	1722-823-101	1	piece
2CKA001754A4323	Cover Frame 2gang glass black - carat	1722-825	1	piece
2CKA001754A4361	Cover Frame 2gang chrome - carat	1722-826-101	1	piece
2CKA001754A4606	Cover Frame 2gang anthracite - Busch-Dynasty	1722-831-500	1	piece
2CKA001754A4601	Cover Frame 2gang ivory white - Busch-Dynasty	1722-832-500	1	piece

2CKA001754A4576	Cover Frame 2gang polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	piece
2CKA001754A4566	Cover Frame 2gang polished brass anthracite - Busch-Dynasty	1722-835-500	1	piece
2CKA001754A4571	Cover Frame 2gang polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	piece
2CKA001754A4561	Cover Frame 2gang polished brass ivory white - Busch-Dynasty	1722-838-500	1	piece
2CKA001754A4596	Cover Frame 2gang antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	piece
2CKA001754A4539	Cover Frame 2gang studio white - solo	1722-84-500	1	piece
2CKA001754A4586	Cover Frame 2gang antique brass anthracite - Busch-Dynasty	1722-845-500	1	piece
2CKA001754A4591	Cover Frame 2gang antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	piece
2CKA001754A4581	Cover Frame 2gang antique brass ivory white - Busch-Dynasty	1722-848-500	1	piece
2CKA001754A4255	Cover Frame 2gang stainless steel - carat	1722-860	1	piece
2CKA001754A4501	Cover Frame 2gang stainless steel - Pure Stainless Steel	1722-866K-500	1	piece
2CKA001754A4415	Cover Frame 2gang studio white matt - future linear	1722-884K	1	piece
2CKA001754A4534	Cover Frame 2gang black matt - future linear	1722-885K-500	1	piece
2CKA001754A4242	Cover Frame 3gang anthracite - future linear	1723-181K	1	piece
2CKA001754A4170	Cover Frame 3gang ivory white - future	1723-182	1	piece
2CKA001754A4232	Cover Frame 3gang ivory white - future linear	1723-182K	1	piece
2CKA001754A4533	Cover Frame 3gang aluminium silver - future linear	1723-183K-500	1	piece
2CKA001754A4175	Cover Frame 3gang studio white - future	1723-184	1	piece
2CKA001754A4366	Cover Frame 3gang studio white - future linear	1723-184 NSK	1	piece
2CKA001754A4502	Cover Frame 3gang studio white - future linear	1723-184K-500	1	piece
2CKA001754A4777	Cover Frame 3gang glass purple - Busch-axcent pur	1723-223	1	piece
2CKA001754A4762	Cover Frame 3gang glass sun - Busch-axcent pur	1723-225	1	piece
2CKA001754A4772	Cover Frame 3gang glass avocado - Busch-axcent pur	1723-226	1	piece
2CKA001754A4767	Cover Frame 3gang glass coral - Busch-axcent pur	1723-227	1	piece
2CKA001754A4757	Cover Frame 3gang glass ocean - Busch-axcent pur	1723-228	1	piece
2CKA001754A4792	Cover Frame 3gang paper brown - Busch-axcent pur	1723-243	1	piece
2CKA001754A4802	Cover Frame 3gang glass black - Busch-axcent pur	1723-245	1	piece
2CKA001754A4787	Cover Frame 3gang paper blue - Busch-axcent pur	1723-248	1	piece
2CKA001754A4690	Cover Frame 3gang platinum - Busch-axcent pur	1723-270-500	1	piece
2CKA001754A4710	Cover Frame 3gang black matt - Busch-axcent pur	1723-275-500	1	piece
2CKA001754A4700	Cover Frame 3gang titanium - Busch-axcent pur	1723-276-500	1	piece
2CKA001754A4439	Cover Frame 3gang white glass - Busch-axcent pur	1723-280	1	piece
2CKA001754A4411	Cover Frame 3gang black - Busch-axcent	1723-281	1	piece

2CKA001753A4128	Cover Frame 3gang black - Busch-axcent flat	1723-281/11	1	piece
2CKA001754A4545	Cover Frame 3gang brown glass - Busch-axcent pur	1723-283	1	piece
2CKA001754A4333	Cover Frame 3gang studio white - Busch-axcent	1723-284	1	piece
2CKA001753A4123	Cover Frame 3gang studio white - Busch-axcent flat	1723-284/11	1	piece
2CKA001754A4336	Cover Frame 3gang yellow - Busch-axcent	1723-285	1	piece
2CKA001754A4339	Cover Frame 3gang green - Busch-axcent	1723-286	1	piece
2CKA001754A4342	Cover Frame 3gang red - Busch-axcent	1723-287	1	piece
2CKA001754A4345	Cover Frame 3gang blue - Busch-axcent	1723-288	1	piece
2CKA001754A4807	Cover Frame 3gang slate grey - Busch-axcent pur	1723-290	1	piece
2CKA001754A4473	Cover Frame 3gang entrée grey - Busch-axcent	1723-291-500	1	piece
2CKA001754A4493	Cover Frame 3gang château-black - Busch-axcent	1723-295-500	1	piece
2CKA001754A4797	Cover Frame 3gang concrete grey - Busch-axcent pur	1723-298	1	piece
2CKA001754A4483	Cover Frame 3gang maison-beige - Busch-axcent	1723-299-500	1	piece
2CKA001754A4540	Cover Frame 3gang chrome - solo	1723-80-500	1	piece
2CKA001754A4328	Cover Frame 3gang chrome gloss - solo	1723-80G	1	piece
2CKA001754A4444	Cover Frame 3gang white glass - carat	1723-811	1	piece
2CKA001754A4260	Cover Frame 3gang bronze - carat	1723-821	1	piece
2CKA001754A4358	Cover Frame 3gang gold - carat	1723-823-101	1	piece
2CKA001754A4324	Cover Frame 3gang glass black - carat	1723-825	1	piece
2CKA001754A4362	Cover Frame 3gang chrome - carat	1723-826-101	1	piece
2CKA001754A4607	Cover Frame 3gang anthracite - Busch-Dynasty	1723-831-500	1	piece
2CKA001754A4602	Cover Frame 3gang ivory white - Busch-Dynasty	1723-832-500	1	piece
2CKA001754A4577	Cover Frame 3gang polished brass decor anthracite - Busch-Dynasty	1723-833-500	1	piece
2CKA001754A4567	Cover Frame 3gang polished brass anthracite - Busch-Dynasty	1723-835-500	1	piece
2CKA001754A4572	Cover Frame 3gang polished brass decor ivory white - Busch-Dynasty	1723-836-500	1	piece
2CKA001754A4562	Cover Frame 3gang polished brass ivory white - Busch-Dynasty	1723-838-500	1	piece
2CKA001754A4597	Cover Frame 3gang antique brass decor anthracite - Busch-Dynasty	1723-843-500	1	piece
2CKA001754A4541	Cover Frame 3gang studio white - solo	1723-84-500	1	piece
2CKA001754A4587	Cover Frame 3gang antique brass anthracite - Busch-Dynasty	1723-845-500	1	piece
2CKA001754A4592	Cover Frame 3gang antique brass decor ivory white - Busch-Dynasty	1723-846-500	1	piece
2CKA001754A4582	Cover Frame 3gang antique brass ivory white - Busch-Dynasty	1723-848-500	1	piece
2CKA001754A4256	Cover Frame 3gang stainless steel - carat	1723-860	1	piece
2CKA001754A4319	Cover Frame 3gang stainless steel - Pure Stainless Steel	1723-866K	1	piece
2CKA001754A4416	Cover Frame 3gang studio white matt - future linear	1723-884K	1	piece
2CKA001754A4421	Cover Frame 3gang black matt - future linear	1723-885K	1	piece

Catégories

Produits basse tension → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Mechanical Controls



360°