



Odade

S5--227
S5--208
S5--207
S5--243



S5--227 fr Commande pour automatisme v/roulants
es Pulsador persianas 10A para automatismo
nl Rolluikdrukknop NO (1-2) Stop (1+2) 10A
pt Botão Pressão Estores 10A automatismo
en Blinds PB NO (1-2) Stop (1+2) 10A automa





1	fr	Commande locale
	es	Comando local
	nl	Lokaal commando
	pt	Comando local
	en	Local command
2	fr	Commande centrale
	es	Comando Central
	nl	Central commando
	pt	Comando Central
	en	Central command
3	fr	Module de commande
	es	Módulo de comando
	nl	Moduul commando
	pt	Módulo de comando
	en	Module of command



S5--208 fr Inter volets roulants 3 positions
es Interruptor persianas 6A
nl Rolluikschakelaar 3 standen 6A
pt Interruptor de Estores 6A
en Blinds SW 3 rockers / position 6A





S5--243 fr Interrupteur VMC avec arrêt
es Inter Ventilador 2 velocidad 6A c/paro 6A
nl Ventilatorbedien 3 standen met STOP 6A
pt Comutador de Ventilacion 6A 3 posic
en Two way SW fan ctrl VMC stop 3 posit 6A




S5--207

- fr Pousoir volet roulant 3 positions
- es Pulsador persianas 6A
- nl Rolluikdrukknop 2 toetsen 6A
- pt Botão de Pressão de Estores 6A
- en Blinds PB 2 rockers 6A



fr	Boîtes d'automatization
es	Caja automatización
nl	Automatische doos
pt	Caixa de Automatização
en	Automatic Box



S520690

