




02/18 IL05009002Z  
 (AWA2731-2257)

## XT-RJ45-ETH-RS232


### Dimensions – Abmessungen – Dimensions – Dimensiones – Dimensioni



### Fitting Montage Montaje Montaggio




### Dismantling Demontage Démontage Desmontaje Smontaggio



		Signal Señal Segnale	
		Ethernet	RS232
I N	8	8	RxD
	7	7	GND
	6	6	Rx-
	5	5	TxD
	4	4	GND
	3	3	Rx+
	2	2	Tx-
	1	1	Tx+

		Signal Señal Segnale	
		Ethernet	
E T H E R N E T	8	8	-
	7	7	-
	6	6	Rx-
	5	5	-
	4	4	-
	3	3	Rx+
	2	2	Tx-
	1	1	Tx+

		Signal Señal Segnale	
			RS232
R S 2 3 2	8	8	RxD
	7	7	GND
	6	6	-
	5	5	TxD
	4	4	GND
	3	3	-
	2	2	-
	1	1	-



02/18 IL05009002Z

