



LEDDim Smart Pill Mini





230V, 50/60Hz, -20°C to 35°C

LEDDim App GET IT ON Google Play Android OS 5.1, Ram 2.5GB mid-range CPUs< <http://www.sg-as.no/leddim/getapp/>

Download on the App Store iOS 9.0, iPhone 5s<




Max. 200W	Max. 160W	Max. 160W	



NO: Kan kun installeres av en registrert installasjonsvirksomhet.
EN: Only to be installed by an authorized electrician.
FR: Doit être installé par un électricien autorisé.
NL: Mag alleen geïnstalleerd worden door een bevoegde elektricien.
DE: Dieses Produkt darf nur durch autorisiertes Personal (z. B. Elektro-Installateur) angeschlossen und in Betrieb genommen werden.
FI: Asentaa saa vain valtuutettu sähköasentaja

NO: Skru av strømmen før montering.
EN: Turn off power before installing.
FR: Couper le courant avant l'installation.
NL: Stroom uitschakelen voor u het toestel installeert.
DE: Vor Installationsarbeiten den Strom abschalten.
FI: Sammuta virta ennen kytkemistä



NORWAY SG Armaturen AS
 Tlf:+47 37 50 03 00
 firmapost@sg-as.no
 www.sg-as.no

DENMARK SG Armaturen A/S
 Tel: +45 70 70 72 13
 info@sg-as.dk
 www.sg-as.dk

SWEDEN SG Armaturen AB
 Tel: +46 31 81 71 10
 info@sg-ab.se
 www.sg-ab.se

FINLAND SG Armaturen Oy
 info@sg-oy.fi
 www.sg-oy.fi

FRANCE SG Lighting SA/NV
 Tel: +33(0) 4 94 93 00 00
 info.france@sglighting.fr
 www.sglighting.net

BENELUX SG Lighting SA/NV
 Tel: +32(0) 15 20 72 71
 info.benelux@sglighting.net
 www.sglighting.net





GERMANY SG Leuchten GmbH
 Tel: +49 40 23 99 44 59
 info@sg-leuchten.de
 www.sg-leuchten.de

INTERNATIONAL SG Lighting Co Ltd.
 Tel: +86 769 88 49 20 88
 cindy@sgdgc.com
 www.sg-as.com




iOS LEDDim Guide







1. REGISTER create account




2. LOCATION create location




3. MANAGE DEVICE add dimmers



4. GROUP create group



5. LOCATION Share location



LEDDIM Guide






<http://www.sg-as.no/leddim/>






Android LEDDim Guide




1. REGISTER create account




2. LOCATION create location



3. MANAGE DEVICE add dimmers



4. GROUP create group



5. LOCATION Share location

