


# SACE Tmax XT



PLL - Blocco a lucchetti XT5 in aperto o aperto-chiuso.  
PLL - Padlock device XT5 in open or open-close position.  
PLL - Schloßverriegelung XT5 für ausgeschaltet oder ausgeschaltet-eingeschaltet.  
PLL - Verrouillage par cadenas XT5 portatif en position ouverte ou ouverte-fermé.  
PLL - Bloqueo por candados XT5 portátil en posición de abierto o abierto-cerrado.  
PLL - 操作手柄分闸、分/合闸位置挂锁装置 XT5

XT5




Open position

Open-Close position




1

XT5 F/P



2

XT5 F/P



3

XT5 F/P

