



PANDUIT TX6ATM UTP FieldCord TM ASSEMBLY Part Number: EC-ICC/P3MBLL EC-ICC/P3MM/H EC-ICC/V3MAA EC ISC

Part Number: FC-ICC/P3MBU, FC-ICC/P3MWH, FC-ICC/Y3M^, FC-ISC




For Technical Support: www.panduit.com/resources/install_maintain.asp




* Panduit 6A cord/plug provided is wired T568B

INSTALLATION INSTRUCTIONS

PN652B




For Technical Support: www.panduit.com/resources/install_maintain.asp




For Technical Support: www.panduit.com/resources/install_maintain.asp

PN652B



For Technical Support: www.panduit.com/resources/install_maintain.asp



- As with all Wiring Accessories, the following statements apply:
- 1.
- Never install communications wiring during a lightning storm. Never install communications wiring in wet locations unless the plug is specifically designed for use in wet locations. 2.
- Never touch uninsulated communications wiring or terminals unless the communication line has been disconnected at the network interface. 3.
- 4. Use caution when installing or modifying communication wiring.

STD 1863. **Certified to CSA** STD C22.2#233

Intertek

5020430 **Conforms to UL**

For Instructions in Local Languages and Technical Support:

www.panduit.com/resources/install_maintain.asp



E-mail: techsupport@panduit.com

Phone: 866-405-6654