

Lenovo

ThinkVision

The drivers and files for this monitor can be downloaded from [http://support.lenovo.com/docs/T32h\\_20](http://support.lenovo.com/docs/T32h_20) or scan QR code



ThinkVision T32h\_20 supports Lenovo Display Control Center - ThinkColour.



**1**

(WW) (WW) (USA/Canada) (USA/Canada) (SS) \*  
USB3.0 C-C

**2**

**3**

35° 0°-5° 135mm 90° 90° -45° 45°

**4**

**5**

**6**

**7**

**8** HDMI

**9** DP

**10**

**11**

**12**

**13**

**14**

$\theta > 5^\circ$   $\theta > 5^\circ$   $\theta > 5^\circ$   $\theta > 5^\circ$