

**PC Diagnostics**




Software  
246 301 5... 0

Interface-Set  
[incl. Cable to PC]  
446 301 021 0 (COM)  
446 301 022 0 (USB)

Diagnostic-Cable  
446 300 329 2


**Couplings**




Supply  
952 201 002 0

Brake  
952 201 001 0

System plate  
899 200 922 4




Sticker  
if wear indicators fitted



813 000 008 3    813 000 025 3


**Data/Info Plates**



Dual Circuit  
463 084 010 0


Single Circuit  
463 084 030 0

**Lift Axle Control Valve**




Standard 4S/2M    480 102 010 0 (2S/2M - 4S/2M)  
Premium + 4S/3M    480 102 014 0 (2S/2M - 4S/3M)  
TCE + 4S/3M    480 102 015 0 (2S/2M - 4S/3M)

**EBS Trailer Modulator**



Type	Part Number
16	423 104 710 0
18	423 112 710 0
20	423 505 000 0
22	423 110 710 0
24	423 506 001 0

**Brake Actuator** (for disc brakes)



Type	Part Number
16/16	925 464 ... 0
16/24	925 464 ... 0
18/24	925 463 ... 0
20/24	925 460 ... 0
24/24	925 461 ... 0

**Springbrake Actuator** (for disc brakes)

**Park Release Emergency Valve**




PREV  
971 002 900 0

**Reservoir**


	Part Number	Litre	Diam.
	950 560 001 0	60	246 mm
	950 760 002 0	60	276 mm
	950 060 003 0	60	310 mm
Drain Valve	950 060 004 0	60	396 mm
	950 080 002 0	80	396 mm

**Reservoir Mounting Strap**



Diam.	Part Number
246 mm	451 999 246 2
276 mm	451 999 276 2
310 mm	451 999 310 2
396 mm	451 999 396 2

**Sensor & Cable / Sensor Bush**



Sensor kit  
(Sensor + bush + grease)

Length	Part Number
0.4 m	441 032 921 2
1.0 m	441 032 922 2

**Wear indicator**




Wear Indicator Set  
(2 Indicators / Set)  
12 999 ...



973 011 201 0

**Relay Valve**



# Semi-trailer with Single Lift Axle and D Series EBS

## Pneumatic system and Components

