



**Kana valahdot**

1. Tuulima koneesta asuntoon
2. Poistoma asunnosta koneeseen
3. Ulkoma koneesta ulos
4. Ulkoma koneeseen

**Duct outlets**

1. Supply air from the unit to the apartment
2. Exhaust air from the apartment to the unit
3. Exhaust air flowing outdoors from the unit
4. Outdoor air to the unit

**Kanalarisar**

1. Tuuli rikin aggregaatti illi bostaden
2. Friaktluft rikin bostaden till aggregatet
3. Avluft ut från aggregatet
4. Uteluft till aggregatet

Naaras-älän löuköksen sisälähuusija ø 160 mm  
inner diameter of the female collar ø 160 mm  
Kanaalarisar, inom, inre diameter ø 160 mm

