

449 Attwell Drive, Toronto, Ontario M9W 5C4

BURNABY, B.C. (LOCAL AREA) TOLL FREE: (888) 294-7104 • CALGARY, ALBERTA TOLL FREE: (888) 832-0550

• EDMONTON, ALBERTA TOLL FREE: (888) 441-9883 • SASKATOON, SASKATCHEWAN TOLL FREE: (866) 866-9198

• WINNIPEG, MANITOBA TOLL FREE: (888) 290-3821 • MISSISSAUGA, ONTARIO TOLL FREE: (800) 800-4018

LAVAL, QUEBEC TOLL FREE: (800) 663-334 • DIEPPE (MONCTON), NEW BRUNSWICK TOLL FREE: (800) 561-8551

www.fairviewfittings.com service@fairviewfittings.com

• WOBURN, MASSACHUSETTS CONTINENTAL U.S.A.: (800) 695-3101

WHEATFIELD, NEW YORK CONTINENTAL U.S.A.: (800) 688-4088 • ELKHART, INDIANA 46514 CONTINENTAL U.S.A.: (877) 459-0700

INSTALLATION INSTRUCTIONS FOR GAS APPLIANCE REGULATOR

CSA Certified ANSI Z21.80 / CSA 6.22 CSA Certified ANSI Z21.18 / CSA 6.3 **CSA Certified Indoor/Outdoor Application**

(Vent Limiter Included)





DANGER

Failure to follow these instructions may result in an explosion or fire that may cause property damage, serious injury or death.

Model: GR-207VL Model: GR-211VL

Inlet Pressure: 2 PSI **Inlet Pressure:** 2PSI

Outlet Pressure Setting: 7" W.C. (Non-Adjustable) Outlet Pressure Setting: 11" W.C. (Non-Adjustable)

Maximum Load: 65,000 BTU/h (Natural Gas) **Maximum Load:** 100,000 BTU/h (Propane)

Temp: -40°F to +250°F Temp: -40°F to +250°F

Vent Connection: 5/16-24 (Vent Limiter **Vent Connection:** 5/16-24 (Vent Limiter

> Included) Included)

Orientation: Regulator can be mounted Orientation: Regulator can be mounted

in any direction

Gas: **Natural Gas** Gas: Propane

in any direction

Caution

If venting externally regulator must be piped in accordance with government and local codes and regulations.

Installation:

Warning

Be sure all instructions are read and understood before installation, operation and service. Failure to do so may result in an explosion or fire causing severe injury or death.

Caution

This regulator should be installed and adjusted by a qualified LP Gas technician. Contact a qualified LP Gas contractor or dealer for installation.

- 1. Installation shall be performed in accordance with local codes, or in the absence of local codes, in accordance with the National Fuel Gas Code, ANSI Z223.1/NFPA 54, or the Natural Gas and Propane Install Code, CAN/CSA-B149.1, as applicable.
- 2. The regulator is intended for natural gas or propane vapour service only. DO NOT CONNECT TO LIQUID PROPANE SYSTEMS
- 3. To minimalize the possibility of debris/insects blocking the vent keep the vent cover in place. Vent cap should be in place for outdoor use to protect the vent from snow, rain and other foreign particles
- 4. Use an approved pipe dope or tape when making threaded pipe connections.
- 5. If an electronic detector is not available, test connections for leaks with Gas-Flo leak detector or other commercial leak detector solution.

Warning

Never check for leaks with an open flame, do not check for leaks using ammoniated or chlorinated household type detergents, these can cause cracks to form on the metal, tubing and brass fittings.