

Installation Instruction

Temporary Work Light

Trouble Light



Read the installation instructions and all product labels before proceeding with the installation. This product must be installed in full accordance with applicable electrical and building codes.

TO PREVENT ELECTRICAL SHOCK, POWER SHOULD BE TURNED OFF FROM THE ELECTRICAL PANEL BEFORE INSTALLATION OR MAINTENANCE.

SAFETY WARNINGS

- Suitable for dry locations
- To reduce the risk of electrical shock and fire, do not exceed the maximum wattage per socket.
- Do not use it if the cord is damaged.
- Do not open- no user serviceable parts inside
- Operating Temperature: -40°C / -40°F to 60°C / 140°F
- Do not connect or disconnect when wet.

PRODUCT SPECIFICATIONS

Working Voltage	125V
Amps	13A
NEMA 5-15	Yes
Wire	16/3C
Sockets	E26

INSTALLATION INSTRUCTIONS

1. Make sure the power is turned OFF.
2. Insert the lamp (sold separately) into the socket.
3. Snap the metal cage together to secure the lamp.
4. Hang the trouble light using the hook.
5. Turn the power ON.

RELAMPING INSTRUCTIONS

1. Disconnect power before relamping.
2. Unsnap the metal cage to replace the lamp inside. It is not necessary to remove the entire metal cage from the socket to relamp.
3. Turn the power ON.