

Installation Instruction **Temporary Work Light** 50 W Portable Flood Light Battery Powered

Read the installation instructions and all product labels before proceeding with the installation. This product must be installed in full accordance with applicable electrical and building codes.

TO PREVENT ELECTRICAL SHOCK, POWER SHOULD BE TURNED OFF FROM THE ELECTRICAL PANEL BEFORE INSTALLATION OR MAINTENANCE.

SAFETY WARNINGS

- This device utilizes a rechargeable Lithium-ion battery that can rupture, ignite and cause serious injury if misused. Follow the below safety rules:
- Do not place battery/device in fire or in high temperature.
- Do not tamper with battery wiring.
- Do not puncture or damage the battery.
- Do not immerge or expose battery to water.
- Do not alter or modify the battery
- Do not attempt changing the battery in any manner other than prescribed in this guide.
- Do not turn on the light when charging.
- Do not use a modified or damager charger.
- Recharge the battery every six months when in storage.
- Suitable for dry locations
- Do not open- no user serviceable parts inside
- Operating Temperature: -10°C / 14°F to 40°C / 104°F

PRODUCT SPECIFICATIONS

Voltage	(DC15-24V 2A) 100-240VAC
Colour Temperature	Cool White
Battery	18.5V 6.6AH
Charging Time	6 hours
Working Time	3 to 12 hours



Installation Instruction **Temporary Work Light** 50 W Portable Flood Light Battery Powered



TURN THE LUMINAIRE ON/OFF – STEPS

- 1. Turn ON the luminaire: Press Power Switch (Part #5).
- 2. Dimming option: Press the Dimmer Switch (Part #6), to select the desired level of brightness (3 pre-set levels).
- 3. Turn OFF the luminaire: Press Power Switch (Part #5).

LED BATTERY CAPACITY INDICATOR

- Charging: LED indicator flashes green and red.
- Fully charged: LED indicator will turn on green.