

# **CJ6 & CJ6S** Colorado Jim Cable Support





Furring Strip

## Sizing Chart


No Load Rating, For Positioning Only.

| Part<br>Number | Cable<br>Type                                   | Cable<br>Size  | Cables<br>Per<br>Fastener | Description   | Box/Case<br>Quantity |
|----------------|---|--|---------------------------|---|----------------------|
| CJ6            | Romex® and<br>Non-Metallic<br>Sheathed<br>Cable | 14-2, 12-2,<br>10-2, 14-3,<br>12-3 and<br>10-3<br>w/ground                           | 6 MAX.                    | To attach<br>Romex<br>Non-Metallic<br>Sheathed<br>Cable, AC,<br>BX, and MC<br>Cable to<br>Wood or<br>Metal Stud | 100/600              |
|                |   | 8-2 and 6-2<br>w/ground  | 4 MAX.                    |   |                      |
|                | Metal Clad<br>(MC) Cable                        | 14-2, 12-2,<br>10-2, 14-3,<br>12-3, 10-3,<br>14-4, 12-4,<br>and 10-4<br>w/ground     | 4 MAX.                    |   |                      |
| CJ6S           | Armored<br>Cable (AC)                           | 14-2, 12-2,<br>10-2, 8-2,<br>14-3, 12-3,<br>10-3, 14-4,<br>12-4 and<br>10-4 w/ground | 4 MAX.                    | Furring Strip<br>and Hat<br>Channel   |                      |
|                | Flexible<br>Conduit (BX)                        | 5/16, 3/8  | 4 MAX.                    |   |                      |

### Application

Ref. NEC 1990 Article 300-4d.

Note: The CJ6S Fastener is not approved to satisfy NEC 1990 Article 300-4d in all states. Contact your local inspector.



#### WARNING

- RNING:

  Nent products shall be installed and used only as indicated in nVent product instruction sheets and training materials. Instruction sheets are available at <a href="https://www.nVent.com">www.nVent.com</a> and from your nVent customer service representative.

  NVent products must never be used for a purpose other than the purpose for which they were designed or in a manner that exceeds specified load ratings.

  All instructions must be <a href="https://completely">completely</a> followed to ensure proper and sofe installation and performance.

  Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, properly damage, serious bodily injury and/or death, and void your warranty.

  Products that are manufactured using spring steel components shall be used only in a non-corrosive indoor environment.

  All pipe supports, hangers, intermediate components and structural attachments must ONLY be used as described herein and are NEVER to be used for any other purpose.

NOTE: All load ratings are for static conditions and do not account for dynamic loading such as wind, water or seismic loads, unless otherwise noted.

The customer is responsible for:

- a. Conformance to all governing codes.
  b. The integrity of structures to which the products are attached, including their capability of safely accepting the loads imposed, as evaluated by a qualified engineer.

  c. Using appropriate industry standard hardware as noted above.

www.nVent.com


SAFETY INSTRUCTIONS:
All governing codes and regulations and those required by the job site must be observed.
Always use appropriate safety equipment such as eye protection, hard hat, and gloves as appropriate to the application.







### Installation







CFS206\_E