



Use and Care Guide

Recessed Dryer Vent Box



TOOLS REQUIRED



Scissors



Utility knife



Electric drill



Screwdriver



Rubber mallet

HARDWARE REQUIRED (NOT INCLUDED)



Worm gear clamp (1)


Notice

For gas dryer installations: Use a utility knife to cut out gas punchouts on the top of dryer vent box before installing.

Installing dryer vent box


1 REMOVING THE MOUNTING BRACKETS

- Attach mounting brackets to sides of dryer vent box using a rubber mallet to lightly tap into position.




2 DISCONNECTING THE ROUND TO OVAL DUCT ADAPTER

- Disconnect round to oval duct adapter from dryer vent box by pressing the round tabs on both sides.




3 POSITIONING THE DRYER VENT BOX

- Position dryer vent box between studs at least 1 1/2" from the floor to allow for the trim piece. Screw both long brackets on one side and both short brackets on the other side, being careful not to over tighten.




4 ATTACHING IN-WALL DUCT TO OVAL DRYER VENT BOX PORT

- Attach solid metal duct to oval dryer vent box port.




5 INSTALLING DRYWALL

- Install drywall around dryer vent box.



6 ATTACHING TRIM PIECE


- Snap trim piece into place.



Connecting dryer duct to dryer vent box


7 ATTACHING ADAPTER ONTO DUCT

- Thread the adapter onto flexible aluminum foil duct or semi-rigid aluminum duct by turning counter clockwise.



8 CONNECTING DUCT TO DRYER

- Connect opposite end of duct to dryer using a Dundas Jafine clamp (not included). Snap duct adapter piece back into the dryer vent box and push the dryer into place, being careful not to crush the duct.



Warranty

WHAT IS COVERED

All merchandise is warranted to be free from defects in workmanship and material for one year from the date of purchase. This includes normal wear and performance failure on items. The manufacturer will replace or repair at their option.

WHAT IS NOT COVERED

This warranty only covers normal wear and performance failure. It does not cover any malfunction, performance failure, or defect arising from the misuse, abuse, neglect, or modification of the product. Any damage or malfunction inflicted upon the product by the user or other external sources, or any failure to comply with the warnings and instructions, is not covered.

For further assistance visit www.DundasJafine.com.