

Hydronic Heating—Aquastat Accessories

Single and Multifunction Aquastat Parts

Product Number	Type	Bulb Diameter (in.)	Leadwire			Description
			Temperature	Length	Ending	
104484C	1 1/2 inch Insulation	—	—	—	—	Bag assembly
112721	Clip	—	—	—	—	Clip
120650	—	—	—	—	—	Tube
126580	—	—	—	—	—	Dial stop, use with L4081, L6081, L8124, R8182D and R8182H.
129353	Terminal	—	—	—	—	Terminal Adapter
132686	—	—	—	—	—	Clamp - Pipe
204326	Transformer	—	—	—	—	Transformer Assembly
204360	Relay	—	—	—	—	SPDT Relay
112626AA	Well	1/2	—	—	—	Well
123726AT	—	—	—	—	—	Aquastat assembly for F8182J.
137536A	—	—	—	—	—	Scale Lock Assembly
198799E	Sensor	3/8	150 C	42 in.	3/16 in. quick-connect receptacle	Sensor Assembly
198799F	Sensor	3/8	125 C	48 in.	1/4 in. quick-connect receptacle	Sensor Assembly
198799H	Sensor	3/8	125 C	42 in.	3/16 in. quick-connect receptacle	Sensor Assembly
198799K	—	3/8	150 C	42 in.	3/16 in. quick-connect receptacle	Monel Capsule
198799R	Sensor	3/8	125 C	48 in.	3/16 in. quick-connect receptacle	Sensor Assembly
198799W	Sensor	3/8	150 C	50 in.	3/16 in. quick-connect receptacle	Sensor Assembly
198799Z	Sensor	3/8	125 C	42 in.	Strip & Retain	Sensor Assembly
32002190-001	Relay	—	—	—	—	Replacement Relay for L7124U
32002656-001	Sensor Clip	—	—	—	—	Clip, Spring
32004955-001	Sensor	—	—	12 in.	—	Sensor Assembly for use with L71XX series of Electronic Aquastats
32004955-002	Sensor	—	—	18 in.	—	Sensor Assembly for use with L71XX series of Electronic Aquastats
32004955-003	Sensor	—	—	24 in.	—	Sensor Assembly for use with L71XX series of Electronic Aquastats
32004955-004	Sensor	—	—	36 in.	—	Sensor Assembly for use with L71XX series of Electronic Aquastats
32004955-005	Sensor	—	—	48 in.	—	Sensor Assembly for use with L71XX series of Electronic Aquastats
4074BMR	—	—	—	—	—	Grommet, adapter, wire nut L4081.
4074EVC	Terminal Adapters	—	—	—	—	Bag Assembly w/10 129353 terminal adapters
4074EUS	—	—	—	—	—	Bag Assembly containing quick-connect to Screw Terminal for L8124 or L8148
4074EYZ	Fuse	—	—	—	—	Bag assembly