


Part Search

Exploded View of Product **BDP250**



REF # 🔍	PART # 🔍	NAME 🔍	NOTES 🔍	FP # 🔍	QTY 🔍
1	 5H73627-1	Top Panel		12945	1
2	 3H36720-18	Heat Exchanger Replacement Kit (Stainless Steel)		12945	1
3	 3H34178	MTG. Reinforcement Angle		34300	1
5	 5H73616	Inner Side Panel,L.H		12940	1
6	 5H73615	Inner Side Panel R.H.		12939	1
7	 5H62882-4	Side Panel		11911	1
8	 5H62891-5	Lower Front Panel		11923	1
9	 3H25931-7	Bottom Pan Assembly		11125	1
10	 3H32709-5	Rear Panel		11356	1
14	 5H56761	Spring (Deflector Blade)		27532	1
15	 5H62892-6	Deflector Blade		11930	6
15	 5H72300-2	Deflector Blade (Lanced)		27283	1
16	 5H73086-3	Air Baffle		29193	1
20	 5H73593	Limit Control		12925	1
21	 5H73979	Manifold		29221	1
22	 5H54751-18	Main Orifice (Natural Gas)	More common replacement part	11756	1
22	 5H54751-36	Main Orifice (Propane Gas)	More common replacement part	11774	1
23	 3H20634-2	Primary Air Control		11107	1
24	 5H71675	Fan Timer / TD Relay		12339	1
26	 3H33074-7	Burner (Stainless Steel)		11533	1
27	 5H73598-1	Power Exhauster (115V)		12929	1
27	 5H73598-2	Power Exhauster (230V)		12930	1
29	 5H73591-9	Pressure Switch		48447	1
30	 5H75048	Blower Housing Assembly		46036	1
34	 3H34180-13	Support Bracket (R.H)		27276	1
35	 3H34180-14	Support Bracket (L.H)		27277	1
36	 5H58064-3	Motor Sheave	Power Code 9,10,11,12,13	11852	1
36	 5H58065-2	Motor Sheave	Power Code 15,16,17,18,19,20,21,22,23,25,26,27,28,29,30,31,32,33,34,35,36,37,38,39,57,58,59,60,61,62,63	11857	1
36	 CF	Motor Sheave	Power Code 47,52,53,54,55,71	34146	1
36	 CF	Motor Sheave	Power Code 41,42,43,44,45,65,66,67,68,69	11859	1
37	 5H59828-52	Belt	Power Code 15,16,17,18,19,20,21,22,23,52,53,54,55,57,58,59,60,61,62,63	11893	1
37	 5H59828-46	Belt	Power Code 25,26,27,28,29,30,31,32,33,34,35,36,37,38,39	27291	1
37	 5H59828-54	Belt	Power Code 41,42,43,44,45,47	11895	1
37	 5H59828-56	Belt	Power Code 65,66,67,68,69,71	11897	1
38	 5H71956-1	Transformer	120/24V	12396	1
38	 5H71956-2	Transformer	208-240/24V	12397	1

39	 5H58052-23	Sheave Blower	Power Code 65,66,67,68,69,71	11846	1
39	 5H58052-19	Sheave Blower	Power Code 52,53,54,55	11843	1
39	 5H58052-15	Sheave Blower	Power Code 25,26,27,28,29,30,31,32,33,34 ,35,36,37,38,39	11841	1
39	 5H58052-21	Sheave Blower	Power Code 9,10,11,12,13,15,16,17,18,19, 20,21,22,23,41,42,43,44,45,47 ,57,58,59,60,61,62,63	11844	1
39	 No Part Number	Sheave Motor(CF)	CF (Consult Factory)	0	1
40	 CF	Motor	Power Code 9,10	12766	1
40	 CF	Motor	Power Code 17,18	12764	1
40	 9F20215	Motor	Power Code 33,34	38118	1
40	 No Part Number	Motor(CF)	CD (Consult Factory)	0	1
40	 CF	Motor	Power Code 12,13	12793	1
40	 9F40141	Motor 1/3 HP	Power Code 15	29228	1
40	 CF	Motor	Power Code 20,21	12789	1
40	 9F40142	Motor 1/2 HP	Power Code 23	29229	1
40	 CF	Motor	Power Code 25,26,57,58	12765	1
40	 CF	Motor	Power Code 28,29,60,61	12791	1
40	 9F40143	Motor 3/4 HP	Power Code 31,63	29230	1
40	 CF	Motor	Power Code 36,37	12800	1
40	 9F60395	Motor (1 HP)	Power Code 39	29231	1
40	 CF	Motor	Power Code 44,45,68,69	12802	1
40	 9F60396	Motor (1-1/2 HP)	Power Code 47,71	29232	1
40	 CF	Motor	Power Code 52	12798	1
40	 CF	Motor	Power Code 53	12804	1
40	 9F60397	Motor (2 HP)	Power Code 55	29233	1
41	 5H73688-1	Modulating Valve (Series 102)		12951	1
41	 5H73686-1	Modulating valve (Series 101)		12949	1
42	 5H80689	Ignition Controller		0	1
43	 5H71847	Energy Cut Off		12364	1
44	 5H73100-2	Combination Gas Control (Series 101,102)	Control Code 11,12,13,14	12535	1
44	 5H73119-1	Combination Gas Control/Pilot Valve	Control Code 25,26	12560	1
44	 5H73096-2	Combination Gas Control (Main Valve - Series 101)	Control Code 30,31,32,33	12528	1
44	 5H72493-2	Combination Gas Control (Main Valve - Series 101)	Control Code 63,64	12493	1
44	 5H73115-2	Combination Gas Control (Main Valve - Series 101)	Control Code 81,82,91,92	12556	1
44	 5H73090-2	Combination Gas Control/ Pilot Valve	Control Code 83,84	12527	1
44	 5H73098-2	Combination Gas Control (Main Valve - Series 101)	Control Code 85,86,93,94	12531	1
44	 5H73018-2	Combination Gas Control (Main Valve - Series 101)	Control Code 87,88	29190	1

44	 5H71933-3	Combination Gas Control (Main Valve - Series 102)	Control Code 30,31,32,33	29188	1
44	 5H73434-2	Combination Gas Control (Main Valve - Series 102)	Control Code 63,64	12584	1
44	 5H73118-2	Combination Gas Control/Pilot Valve	Control Code 81,82,91,92	29199	1
44	 5H73206-2	Combination Gas Control (Main Valve - Series 102)	Control Code 85,86,93,94	29201	1
44	 5H73216-2	Combination Gas Control (Main Valve - Series 102)	Control Code 87,88	12580	1
44	 5H64000	Combination Gas Control (Main Valve - Series 102)	Control Code 59,60,89,90	12046	1
44	 5H73121-2	Combination Gas Control (Main Valve - Series 103)	Control Code 11,12,13,14	12564	1
44	 5H73207-3	Combination Gas Control (Main Valve - Series 103)	Control Code 32,33	29202	1
44	 5H73122-1	Combination Gas Control (Main Valve - Series 103)	Control Code 81,82,91,92	12565	1
44	 5H73684-2	Combination Gas Control (Main Valve - Series 103)	Control Code 85,86,93,94	12948	1
44	 5H73601-1	Combination Gas Control (Main Valve - Series 103)	Control Code 30,31	12931	1
45	 5H80690-1	Pilot Burner Assembly (Natural Gas)	Natural Gas	56154	1
45	 5H80690-2	Pilot Burner Assembly (Propane Gas)	Propane Gas	56155	1
46	 3H34030-10	Standing Pilot Assembly	Control Code 11/12/13/14/25/26/91/92/81/83 /84	27281	1
46	 3H34030-10	Standing Pilot Assembly	Control Code 91/92/81/83/84/81/91/92/81/81	27281	1
46	 3H34030-10	Standing Pilot Assembly	Control Code 14/13/12/11/81/81/91/92	27281	1