

Plumbing Repair Parts



| Description | Purpose | Part # | Description | Purpose | Part # | Description | Purpose | Part # |
|-------------|--|---|-----------------|--|----------------------------------|-------------------|--|----------------------------------|
| Thread Seal | To be used on threaded pipes and fittings to seal the joints. | M6112 M6124 M6125 M6125PB M6150 | Pipe Cleaner | Cleans pipes for leak proof solder joints. | M7710 M7720 M7770 | Seat Wrench | Removes threaded faucet seats from faucet body. | M7160 M7170 |
| Putty | Use as a seal for fixtures, sinks, tubs and more. | M6115 M6120 | Fitting Cleaner | Cleans fittings for leak proof solder joints. | M7710 M7750 M7760 M7770 | Component Remover | Used to remove various fixture components. | M3203 M7040 M7125 M7210 |
| Lubricant | For use on selected faucet components to keep them moving properly. | M6144 M6145 | Tube Cutter | Easily cuts various types of metal tubing to desired length. | M7530 M7540 M7562 | Basin Wrench | Removal of under-the-counter faucet installation nuts. | M7010 M7011 |

