

CHEF PLUS S1644.558.210 PURE WATER SERIES KITCHEN FAUCET PARTS BREAKDOWN



PART No.	DESCRIPTION:
1	Shower head
2	Rubber ring
3	Hose assembly
4	Spring assembly
5	Screw
6	Hose 77CM
7	Rubber ring
8	Connector
9	Rubber ring
10	Core
11	Swing bar assembly
12	Plastic core
13	Plastic washer
14	Connector
15	Plastic
16	Rubber ring
17	Ring
18	Sleeve, Plastic
19	Welded assembly, Body
20	Shank
21	Base
22	Rubber ring
23	Rubber ring

PART No.	DESCRIPTION:
24	Plate
25	Plastic Fixed Set
26	Screw nut assembly
27	Cartridge
28	Press cover
29	Cover
30	Handle assembly
31	Cartridge
32	Cover
33	Washer
34	Washer
35	Screw
36	Small Handle assembly
37	
38	
39	Rubber ring
40	Neoperl Aerator
41	Water nozzle
42	Hose
43	Hose
44	Allen wrench kit
45	Restrictor

