



**EK, ADK, BOK, UK,
UDK & ALF
Filter Drier
APD Muffler**
Installation Instructions



COPELAND



System Location
Localización en el Sistema
Localização do Sistema
Emplacement du système

取付位置
시스템 설치장소
系统中的位置

①

R-11
R-12
R-22
R-113
R-114
R-115
R-123
R-124
R-125
R-134a
R-290
R-401A
R-401B




R-402A
R-402B
R-404A
R-407A
R-407B
R-407C
R-410A
R-448A
R-449A
R-450A
R-500
R-502
R-507
R-513A
R-744

Refrigerant Compatibility
Compatibilidad con Refrigerantes
Compatibilidade do Refrigerante
Compatibilité du réfrigérant

冷媒適合性
냉매 호환성
冷媒兼容性

③



All positions OK except for APD Muffler. Do not install Muffler in horizontal position.

Todas las posiciones OK, excepto para el Mofle APD. No instale el Mofle en posición horizontal.

Todas as posições OK, exceto para a Mufla APD. Não instale a Mufla na posição horizontal.


Toute position OK, à l'exception du silencieux APD. Ne pas installer les silencieux en position horizontale.

APDマフラー以外はどの向きでも問題ありません。

マフラーは水平方向に設置しないでください。

필터드라이어 설치 시 어떤 방향으로 해도 관계없으나, APD 머플러는 수평방향 설치를 금지합니다.

所有位置均可，除APD消音器外。
APD系列不可安装于水平位置



Remove Seals

Remueva los Empaques


Remova os Tampões

Enlever les capuchons

シーンを取外す

봉인을 제거

拿去密封端盖



Flow Follows Arrow*

El Flujo sigue la Flecha**

Barra Indica Posição do Fluido

L'écoulement doit suivre la flèche


矢印方向に冷媒流

화살표방향으로 흐름

流向箭头

*APD can be installed in either direction

**APD se puede instalar en cualquier dirección



Installation Precautions

Precauciones de Instalación

Precações na Instalação

Précautions d'insatallation

取付時の注意

설치시 주의점

安装注意事项



Pressurize And Check For Leaks

Presurize y Verifique si existen Fugas

Pressurize e Verifique Vazamentos

Pressuriser et vérifier pour les fuites

圧力をかけて漏れを検査

압력을 가하여 누설을 점검

增压及检查泄漏

www.copeland.com/en-us/products/heating-and-air-conditioning/air-conditioning-controls
Technical Support: 1-844-529-7943

PA-00292001 ©2024 Copeland LP.

COPELAND