


PARTS AND HARDWARE LISTING / LISTE DES PIÈCES ET QUINCAILLERIE



ITEM		PARTS AND HARDWARE / PIÈCES ET QUINCAILLERIE	QTY
1	STA32-BTMTRK-11 STA36-BTMTRK-11 STA40-BTMTRK-11	BOTTOM RAIL / RAIL INFÉRIEUR	1
2	STA32-TOPTRK-11 STA36-TOPTRK-11 STA40-TOPTRK-11	TOP RAIL / RAIL SUPÉRIEUR	1
3	STA-WJAMB-XX-75	WALL JAMB / JAMBAGE	2
4	COEX A310-72	SIDE GASKET / JOINT LATÉRAL	4
5	MAGNET-EA-SET-75	MAGNETIC GASKET / JOINT MAGNÉTIQUE	2
6	VINYL-FSR-ST-6	EXTERIOR GASKET / JOINT EXTÉRIEUR	2
7	ST-EXPANDER-XX-75	EXPANDER / EXTENSEUR	2
8		DOOR PANEL / PANNEAU DE PORTE	2
9		FIXED PANEL / PANNEAU FIXE	2
10	NA-HANDLE-XX	HANDLE BAR / POIGNÉE	2
11	ST-CLIP1-XX	BOTTOM SUPPORT / SUPPORT DU BAS	2
12	NA-ROLLER-XX	ROULEAU SUPÉRIEUR - TOP ROLLER	2
13	ST-B-ROLLER-XX	ROULEAU INFÉRIEUR - BOTTOM ROLLER	4
14	NA-FASTENER-XX	GLASS FASTENER / FIXATION DE VERRE	4
15		SUPPORT CAP / CAPUCHON DU SUPPORT	2
16		HOLE PLUG / BOUCHON DE TROU	4
17		ROUND HEAD SELF DRILLING SCREW / VIS RONDE AUTO-PERÇANTE	8
18		SCREW / VIS	14
19		SCREW CAP / CAPUCHON COUVRE-VIS	12
20		BACK SCREW CAP / L'ARRIÈRE DU CAPUCHON COUVRE-VIS	12
21		WALL PLUG / CHEVILLE	6
22	ST-CLIP2-XX	GLASS SUPPORT / SUPPORT DE VERRE	2
23	NA-STOPPER	STOPPER / BUTOIR	6