ECODOME FIN-MOUNT DISPENSER

OPERATION INSTRUCTIONS

FOR HOUSEKEEPING

Pouch Installation & Replacement:

DO NOT USE abrasive cleaning chemicals, abrasive acidic cleaning chemicals or abrasive cleaning sponge or cloth.

Attaching & Removing Dispenser

The EcoDome Fin-Mount Dispenser is designed to attach to your existing wall-mounted bracket system.

MOUNTING THE ECODOME

The EcoDome slides in and out of the channel in the bracket, just like a bottle.

To install, simply align the fin on the back of the EcoDome with the channel in your bracket, and slide downward into position.

Refer to the instructions provided by your bracket manufacturer for details, and how to lock and unlock your specific bracket system.

Dispenser Operation

STEP 1: ROTATE SPOUT

To open the dispenser, first rotate the pump spout so it points toward the wall.

STEP 2: LOCATE KEY SLOT

Locate the key slot on the bottom left side of the dispenser.

STEP 3: INSERT KEY

Insert the key into the key slot and push up into the lock.

STEP 4: REMOVE COVER

While holding the key in position, gently slide the cover straight upwards.

Remove the key, and place the cover aside.

*Remember to store the key in a secure place so it does not get lost.

STEP 5: REMOVE POUCH

Remove empty pouch by pulling the collar and pump straight forward.

ECODOME FIN-MOUNT DISPENSER

OPERATION INSTRUCTIONS

FOR HOUSEKEEPING

Pouch Installation & Replacement:

DO NOT USE abrasive cleaning chemicals, abrasive acidic cleaning chemicals or abrasive cleaning sponge or cloth.

Dispenser Operation (CONTINUED)

STEP 6: INSERT POUCH

Insert a full pouch into the dispenser bottom first.

STEP 6A: ALIGN COLLAR

Then align the slots on the collar with the support surface in the dispenser.

STEP 6B: INSERT COLLAR

Slide the pouch collar straight back and press until it “snaps” into place.

STEP 7: TURN PUMP SPOUT

Turn pump spout so it is facing backwards, pointing toward the wall.

Also, press the pouch into place and tuck the corners/ edges inside, as neatly as possible.

STEP 8: INSTALL COVER

Make sure the pump spout is facing backwards!

Align the cover above the base as shown.

Then slide downward until you hear a “click” sound.

The cover locks automatically.

TIP:

If the pouch is very full, it may be helpful to gently press on the front of the pouch with your thumb while installing the cover.

STEP 9: ALIGN PUMP

Rotate the pump spout to realign it with the front of the dispenser.

NOTE:

The embossed low-fill line on the view window indicates when there is about 1oz of product remaining in the pouch.

ECODOME FIN-MOUNT DISPENSER

CARE INSTRUCTIONS

These guest room accessories are handcrafted and require special care for long term enjoyment.

CAUTION: DO NOT USE

Abrasive cleaning chemicals

Acidic cleaning chemicals

Abrasive cleaning sponge / cloth

RECOMMENDED CLEANING INSTRUCTIONS

Use clean damp cloth with mild soap to gently wipe down the bracket, bottles & pump spouts.

Wipe with clean damp cloth to remove soap.

With a dry clean cloth, wipe off all cleaned areas to remove water spots.

Warranty available upon request.