AVer
www.aver.com

AVer
www.aver.com

CUSTOM CHARGE

```
2.CUSTOM-CHARGE ↑
3.SCHED-CHARGE  ↓
```
Ext.   CH1   CH2   CH3
Esc — + Enter
① ② ③

Step 1: Press [Esc] button.

Step 2: Press [—] button, go to

   CUSTOM-CHARGE.

Step 3: Press [Enter] button.

   - **SET TIME**

   - **VIEW SETTING**

```
1.SET TIME      ↓
2.VIEW SETTING  ↑
```

```
START CHARGE
CH1/2/3(Y/N)?N
```

```
SETTING COMPLETE
PRESS ENTER
```

Note.

- Charging period can be adjusted at 1 HR interval; max charging time is 8 HR.

- to check current charging setting, [Enter] update the setting.

- Select "**Y**" to execute CUSTOM-CHARGE. Select "**N**" to execute CUSTOM-CHARGE.

INFORMATION

```
5.INFORMATION   ↑
2013/07/24-13:50
```
Ext.   CH1   CH2   CH3
Esc — + Enter
① ② ③

```
AVER     : 0.09
BATTERY : 3.11V
```

Step 1: Press [Esc] button.

Step 2: Press [—] button, go to

   INFORMATION.

Step 3: Press [Enter] button.

Note.

- Firmware version.

- Remaining battery capacity of the charging timer.

CHARGING TIMER

1 **O**SD **D**isplay.

2 **C**harging **L**ED **D**isplay.

3 **C**ontrol **P**anel.

4 **B**atteries

```
    13:50:43
WED 2013/07/24
```
Ext.   CH1   CH2   CH3
Esc — + Enter
① ② ③ ④

Caution:

By default, you only need to push the LED button inside the front side panel to active or deactivate the charging mechanism. However, if you had previously used the scheduling function in the Timer to set the charging times, your scheduled charging events will be interrupted if the Timer's batteries have drained completely. To remedy this, change both batteries and re-set the Timer to the current time.

OSD CONTROL OPERATION

① Esc

② [—] [+]

Step 2: [—] ↓ [+] ↑

③ Enter

Step 3: Press "**Enter**" button.

```
1.4HR-CHARGE   ■
2.CUSTOM-CHARGE↓
```

```
2.CUSTOM-CHARGE↑
3.SCHED-CHARGE ↓
```

```
3.SCHED-CHARGE ↑
4.SET TIME     ↓
```

```
4.SET TIME     ↑
5.INFORMATION  ↓
```

```
5.INFORMATION  ↑
2013/07/24-13:50
```

AVer
www.aver.com

AVer
www.aver.com

SET TIME

```
4.SET TIME     ↑
5.INFORMATION  ↓
```

Ext.   CH1   CH2   CH3

① ② ③

Esc — + Enter

```
NEW 15:46 WED
NOW 15:46 WED
```

Step 1: Press Esc button.

Step 2: Press — button, go to
**SET TIME**.

Step 3: Press Enter button.

Note.
- to set the present time.

DEFAULT CHARGE - 4HR CHARGE

```
1.4HR-CHARGE
2.CUSTOM-CHARGE↓
```

Ext.   CH1   CH2   CH3

① ②

Esc — + Enter

```
CH 1 CHARGING
CH 2 WAITING
```

Ext.   CH1   CH2   CH3

③

Esc — + Enter

Step 1: Press Esc button.

Step 2: Press Enter button.

Step 3: Charging starts from channel 1,
and moves to channel 2 and 3
sequentially.

Note.
- By pressing the Esc button,
charging will be "**Paused**".

Tips!
- Press and hold the Esc button for
4 sec to return to the Home screen.

SCHEDULE CHARGE

```
3.SCHED-CHARGE ↑
4.SET TIME     ↓
```

Ext.   CH1   CH2   CH3

① ② ③

Esc — + Enter

```
1 ALL 05:00 N
2 MON 04:00 N
```

Ext.   CH1   CH2   CH3

④

Esc — + Enter

```
7 SAT 14:00 N
8 M-F 16:00 N
```

```
PROJECT 1 ALL
START=05:00 Y
```

```
START CHARGE
CH1/2/3(Y/N)?N
```

Step 1: Press Esc button.

Step 2: Press — button, go to
SCHEDULE-CHARGE.

Step 3: Press Enter button to edit.

Note.
- Scheduled charge on:

Mon, Tue, Wed, Thu, Fri , Sat (**M-F**)
or Mon to Sun (**ALL**)

- Select "**Y**" to confirm schedule.
Select "**N**" to disable schedule.

- Select "**Y**" to execute SCHEDULE-CHARGE.
Select "**N**" to disable SCHEDULE-CHARGE.