Cleaning Instructions

SuperScrape Plus mats can be cleaned in several different ways.

- Commercially laundered (see Laundering Instructions)
- Sterilized in an autoclave
- Washed by hand using the following instructions: Scrub with a deck brush (as needed), using a detergent with a neutral pH. Rinse with a hose or pressure washer. Hang to dry.

Laundering Instructions

SuperScrape Plus mats can be commercially laundered periodically to remove soil. The formula below does not require extensive mechanical action or drying.

- 1. Flush 2-3 minutes, high water level, cold
- 2. Break 5-10 minutes, high water level, 120 degrees F (49 degrees C)
- 3. Rinse 2 minutes, high water level, cold
- 4. Rinse 2 minutes, high water level, cold
- 5. Drain 2 minutes
- 6. Rotate wash well with drain valve in open position to allow excess water to drain off mats.
- 7. Lay mats flat following removal from washer. Allow to cool before rolling.