## Storage and Cleaning Guidelines— MetroMax Q

<u>Continuous Temperature Usage (shelves under load)</u>: -20° to +120°F (-29° to +49°C)

## General Guidelines: MetroMax Q<sup>®</sup> Shelves & Epoxy-Coated Posts



MetroMax Q

The shelves and posts must be cleaned with mild, non abrasive detergents. Shelf mats— Use only cleaners that are recommended for use on plastics. Shelf frames and posts– Use only mild cleaners. Avoid the use of any abrasive materials and stiff brushes or scrapers. MetroMax Q is <u>not</u> intended for automated high temperature cart wash applications or autoclave sterilization.

## Wash Parameters: polymer components

- 1. Water temperatures in the range of  $140^{\circ}$ F to  $180^{\circ}$ F ( $60^{\circ}$  to  $82^{\circ}$ C) are allowed with an exposure period not to exceed 30 minutes.
- 2. Hot air drying is allowed with the temperatures not to exceed 200°F (82°C) and an exposure period not to exceed 15 minutes.
- 3. Steam sanitation is allowed with the temperature not to exceed 212°F (100°C) and an exposure period not to exceed 15 minutes.



