



Palm Side

Back Hand Side

Glove Laundering

For proper operation, the ESD Gloves must be laundered periodically. Woolite works well. Liquid detergents are better than dry detergents in that there is less caking and frictional wear. Launder glove in cool or warm water, tumble dry with low heat or hang dry. Machine washing works well if using a standard home machine on gentle cycle. It is not recommended to launder these gloves in heavy industrial laundry machines as it will lead to premature wear. Gloves should be tumbled dry using low heat. DO NOT BLEACH. After laundering, verify $R_{tt} 1 \times 10^5 < 1 \times 10^9$ ohms. Desco's ESD inspection gloves will retain their ESD properties for 25 washing or approximately 1 year.

*Not recommended for use above 104°F (40°C)

- A. Dissipative (1×10^5 to $< 1 \times 10^8$ ohms) Thunderon® Fibers
Protective Carrier Yarn
Seamless Fine Gauge Knit
- B. Polyurethane Coated Palm and Fingers
- C. Non-Scratch Touchscreen Compatible

Item	Size	Cuff Color
68124	X-Small	Orange
68125	Small	Light Grey
68126	Medium	Green
68127	Large	Brown
68128	X-Large	Yellow
68129	XX-Large	Dark Grey

Sold in pairs

Protection from mechanical risks. Tested per EU EN388.	
Test	Performance Level
6.1 Abrasion Resistance	4
6.2 Blade Cut Resistance	1
6.3 Tear Resistance	3
6.4 Puncture Resistance	1

Specifications and procedures subject to change without notice

DISSIPATIVE NYLON GLOVES WITH POLYURETHANE COATING

DESCO

DESCO WEST: 3651 WALNUT AVE., CHINO, CA 91710 WEB SITE: Desco.com
PHONE (909) 627-8178
DESCO EAST: ONE COLGATE WAY, CANTON, MA 02021-1407
PHONE (781) 821-8370

DRAWING NUMBER
68124

DATE:
March
2019