

Supplement

Title: 360 Instruction Sheet

Supplement Issue: 1

Part Number: 2726405

Issue Date: 6/08

Print Date: October 2006

Page Count: 2

Revision/Date:

This supplement contains information necessary to ensure the accuracy of the above Instruction Sheet.

Change #1, 47119

Under ***Auto Power Off***, add the following Paragraph:

Press mA/A or HOLD button to postpone automatic power off for another 10 minutes. To disable auto power off, press the hold button and power button when turning on clamp meter. After approximately 3 seconds, the auto off indicator will turn off. The clamp meter will default to auto off enabled at power on.

Under ***General Specifications***, replace the ***Temperature Coefficient*** section with the following:

Temperature Coefficient <18 °C or >28 °C

Measuring range: 0 to 50 A
 ± 0.08 % of reading/°C + 0.5 digit

Measuring range: 50 to 60 A
 ± 0.3 % of reading/°C ± 0.5 digit

Under ***Electrical Specifications***, add:

Frequency: 50 Hz ± 1 Hz, 60 Hz ± 1 Hz



205 Westwood Ave
Long Branch, NJ 07740
1-877-742-TEST (8378)
Fax: (732) 222-7088
salesteam@Tequipment.NET