

Quick Start Guide

Secure the StatIQ Band around your upper arm in the orientation shown, ensuring that the sensor is unobscured and pointed away from your body.

Use only with electrically dissipative clothing such as an ESD rated smock.

Power button

Long press: turn the device on and off

Short press: change the alarm mode

 **Yellow** → device muted

 **Green** → audible alarms enabled

Alarms

Constant alarm → body voltage past threshold

3 quick beeps → ESD event detected



IONA Tech App

Download the IONA Tech App from the App Store or Google Play Store to visualize the measured voltage data, change device parameters, and more.



User Manual

Find the complete user manual at www.iona.tech/manuals.

Please reach out to support@iona.tech or call **(844) 844-IONA** for support.