



# IMI ONYX Quick Start Guide



# ONYX Quick Start Guide



ONYX is designed to *always* be on, like a cell phone.

The switch on the bottom of the instrument controls whether the instrument is either actively taking and displaying radiation levels in *Active Mode*(Un-Lock) , or it is in *Stealth Logging Mode*(Lock) , continuously and quietly monitoring and logging background radiation without displaying information. You may switch between Modes at any time.

*Active/Logging Mode*  
Switch



The Front-Panel keypad is touch-sensitive. Use the keypad to access the following functions:

-  - **Home** *Main Menu is displayed*
-  - **Select** *Function (Select a menu item, or a setting)*

◀ - **Back** (*return to previous menu screen*)

△ - **Scroll Up** (*to menu items*)

▽ - **Scroll Down** (*to menu items*)

□ - **Help** Function, (*context-sensitive information*)

**To immediately begin using the instrument as a Geiger Counter**, from any screen, select the **Home** ○ Key, **Current Readings**, then the **Select** ▷ Key.

### **Logging Data to Flash Memory**

If you choose to use the logging function, it will periodically record radiation data as long as the battery has a charge. The logging interval is set under the *Settings/Geiger* Menu. A -000- setting disables logging.

### **To Lock the Keypad**

Simultaneously touch and hold the left ◀ and right ▷ arrow Keys. A Lock icon 🔒 will indicate Lock status in the lower right screen after approximately 3-seconds. Repeat to UnLock 🔓 the keypad.

### **To Refresh Display from the Dimmed State**

Simply brush a finger across the arrow keys to revive.

### **The Factory Default Settings are:**

English Language Menus, Display Auto-Dims, No Logging, No Beep, Max Brightness, Warnings Off

## To Enable the Beeper

Touch the *Home* button, then Down Arrow twice to the *Settings* Menu, Right arrow Key to *Interface* Menu then Right Arrow, then Right Arrow to enable or disable the Beeper.

## To Change Display Brightness

Touch the *Home* button, then Down Arrow twice ▾ ▾ to the *Settings* Menu, Right arrow key ▷ to *Interface* Menu then Right Arrow twice ▷ ▷, and adjust display brightness.

## To select Interface Language

Touch the *Home* button, then Down Arrow twice ▾ ▾ to the *Settings* Menu, Right arrow key ▷ to *Interface* Menu, then Right Arrow ▷, Down Arrow twice ▾ ▾ to the *Language* Menu, Right Arrow ▷, then select your Interface Language.



**For Further Information and Updates**

[www.medcom.com/onyx-resources](http://www.medcom.com/onyx-resources)