How to setup EasyConnect MPX 200

EasyConnect MPX 200 is an innovative screen sharing hub with integrated charging, cable management and control of the meeting room equipment. The system is plug-and-play and pre-configured for a BYOD setup. Different setups can be applied with the EasyConnect management console.



Press and hold any of the touch buttons for 5 second until the a white light appears at port 4.



Connect that cable to your computer and open the EasyConnect management console.

Software configuration guide

Evoko knowledge base will guide you through the process of setting up the EasyConnect MPX 200. https://support.meetevoko.com/hc/en-us

Biamp strives to improve its products on a continual basis. Specifications are therefore subject to change without notice. Biamp and EasyConnect MPX 200 are either trademarks or registered trademarks of Biamp Systems, LLC in the United States and other countries.



🛿 9300 S.W. Gemini Drive Beaverton, OR 97008 USA 💦 T: +1 503.641.7287

Use EasyConnect for BYOD/BYOM



When in idle mode, EasyConnect MPX 200 has a uniform green halo light showing that it is available.



When connecting one of the USB-C cables to a device the light will glow up in that section and the other parts will dim down to show that the device is connected and charging.



When connecting more of the USB-C cables to other devices the light will continue to light up in those sections.



When pressing one of the touch buttons on a connected port the screen sharing starts and access to connected devices such as cameras, speakers and microphones. The light in that section will turn red and the light will turn off in the other sections.

Biamp strives to improve its products on a continual basis. Specifications are therefore subject to change without notice. Biamp and EasyConnect MPX 200 are either trademarks or registered trademarks of Biamp Systems, LLC in the United States and other countries



A: 9300 S.W. Gemini Drive Beaverton, OR 97008 USA T: +1 503.641.7287



When pressing another touch button on a connected port the screen sharing and the connected equipment will switch to the other device. The light in that section will turn red and the light will turn off in the other sections.



To stop sharing, just press once more on the active touch button. The connected device will also no longer be connected to cameras, speakers or microphones. The lights will go back to show which ports are connected.



When all cables are disconneted, the status light will get back to idle mode.

Biamp strives to improve its products on a continual basis. Specifications are therefore subject to change without notice. Biamp and EasyConnect MPX 200 are either trademarks or registered trademarks of Biamp Systems, LLC in the United States and other countries.



A: 9300 S.W. Gemini Drive Beaverton, OR 97008 USA T: +1 503.641.7287

Use EasyConnect with Microsoft Teams Rooms



When in idle mode, EasyConnect MPX 200 has a uniform green halo light showing that it is available.



When connecting one of the USB-C cables to a device the light will glow up in that section and the other parts will dim down to show that the device is connected and charging.



When connecting more of the USB-C cables to other devices the light will continue to glow up in thoose sections.



When pressing one of the touch buttons on a connected port the connected device will start screen sharing through HDMI-Ingest. Cameras, microphones and speakers will still be connected to the MTR-device. The light in that section will turn blue and the light will turn off on the other sections.

Biamp strives to improve its products on a continual basis. Specifications are therefore subject to change without notice. Biamp and EasyConnect MPX 200 are either trademarks or registered trademarks of Biamp Systems, LLC in the United States and other countries



A: 9300 S.W. Gemini Drive Beaverton, OR 97008 USA T: +1 503.641.7287 W: v



When pressing another touch button on a connected port the screen sharing will switch to the other device. The light in that section will turn blue and the light will turn off in the other sections.

To access the cameras, speakers and microphones through a connected laptop, long press any button for 2 seconds to enter BYOM-mode. The complete circle will pulse red a couple of times to indicate the mode switch.



The light will now be red instead of blue with enabled access to cameras, microphones and speakers as well as screen sharing.



To switch back to HDMI-Ingest, long-press any button for 2 seconds. The circle will pulse blue a couple of times to indicate the mode switch and the he MTR-device will take over control of the cameras, speakers and microphones. You will still share the screen.

Biamp strives to improve its products on a continual basis. Specifications are therefore subject to change without notice. Biamp and EasyConnect MPX 200 are either trademarks or registered trademarks of Biamp Systems, LLC in the United States and other countries.



A: 9300 S.W. Gemini Drive Beaverton, OR 97008 USA T: +1 503.641.7287



To stop sharing, just press one more time on the active touch button. The lights will go back to show which ports are connected.



When disconnecting all cables you will get back to idle mode.

Biamp strives to improve its products on a continual basis. Specifications are therefore subject to change without notice. Biamp and EasyConnect MPX 200 are either trademarks or registered trademarks of Biamp Systems, LLC in the United States and other countries.

biamp.

9300 S.W. Gemini Drive Beaverton, OR 97008 USA T: +1 5



Biamp strives to improve its products on a continual basis. Specifications are therefore subject to change without notice. Biamp and EasyConnect MPX 200 are either trademarks or registered trademarks of Biamp Systems, LLC in the United States and other countries.



9300 S.W. Gemini Drive Beaverton, OR 97008 USA T: +1 503.641.7287