

CHANDELIER



QUESTIONS OR CONCERNS CONTACT CANARM AT: 1-800-265-1833 (English) 1-800-567-2513 (French) 1-800-267-4427 (USA)

Monday through Friday 8:00 AM to 5:00 PM E.S.T. **TOOLS AND MATERIALS REQUIRED:** INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS **READ ALL INSTRUCTIONS** Wiring supplies l⊕ as required by **IMPORTANT SAFETY** Phillips Wire Cutters electrical code Screwdriver **INSTRUCTIONS** SAVE THESE INSTRUCTIONS Pliers Wrench SAFETY PRECAUTIONS: 1. TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION OF LIGHT FIXTURE.

- 2. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- 3. CONNECT THE GROUND WIRES (BARE COPPER OR GREEN) FROM YOUR FIXTURE TO THE GROUND WIRE (BARE COPPER OR GREEN) OR GROUND SCREW IN THE ELECTRICAL OUTLET BOX. NOTE: Product May Not Look Exactly As Shown In Figures.





6. Feed power cord through nipple and tighten upper connector to nipple.

 \mathbb{Z}_{\circ} Connect the ground wires (bare copper or green) from your fixture to the ground wire (bare copper or green) or ground screw in the electrical outlet box. Connect the black wire (or wire marked "SPT-1") from the fixture to the black wire in the electrical box and connect the white wire from the fixture to the white wire in the electrical box.

8. Tuck electrical wires into electrical box. Slide canopy into position and tighten in place by sliding upper connector nut into position and tighten.

Screw the arms into the studs. position the arms in place.

10° Note: Refer to the style of assembly that matches the style of your fixture.

Style#1: Tighten the arm onto the screw by nut. Repeat for other arms.

Style#2: Set glass in pan. Slide the arms under the edge. Insert screw through the hole at the end of the arm. Tighten the screw through the arm and into the glass to lock the arm in place. Repeat for other arms.

11. Install proper bulb type and wattage (not included).

Imported By: CANARM LTD., 2157 Parkedale Ave., Brockville, Ontario, K6V 5V6, Tel: (613) 342-5424, Fax: (800) 263-4598