

### **General Info**

B&B Stock Number	A9158355
Year	2019
Make	Hitachi
Model	ZX50U
Serial Number	HCMAED60P00281062
Hour Meter Reading	5548hrs
Previous Application (e.g., earth moving, mining, demolition, etc)	used in civil construction

#### **Dimensions**

A. Length (ft and inches)	18ft 7in
B. Width (ft and inches)	6ft 7.5in
C. Height (ft and inches)	8ft 7in
Operational Weight (lbs)	11,434 pounds

### **Features and Configuration**


Travel System	Rubber Track Undercarriage
Bucket	Yes
Bucket Specs	0.3 yd3
Blade	Yes
Additional Attachment(s)	No
Hydraulic Coupler	No
Auxiliary Hydraulics	No
Hydraulic Thumb	Yes
Heat	No
A/C	No
Radio	No
Backup Camera	No
Grade Control System	No
OMM (Operator & Maintenance Manual)	No
Telematics	No

### **Exterior Walkaround Photos**

360 Walkaround & Operating Video

Walkaround Photos & Operating Video





### **General Appearance Inspection Points**

## **General Appearance**

## **General Appearance Photos**

Close-up Exterior Photos					
			The lower		
			section of the		
			wind shield is		
		82	missing.		
		No.			- A
	The door is				
	missing				
			HITAO		HUR
				The engine bay	
				door does not	
				latch closed.	
	EX-01				

#### **General Appearance Inspection Points**



Inspection Rating Criteria	Rating Scale	Explanation		
	1 - Service Required	Requires immediate repairs to function as expected.		
	2 - Above Average Wear & Tear	Exhibits greater wear than expected given age and usage. While operable, further diagnosis may be needed.		
	3 - Normal Wear & Tear	Exhibits wear that is consistent with age and usage. Operation is normal, and as expected.		
	4 - Very Light or Minimal Wear	Exhibits very minimal wear. Operation is better than expected given age and usage.		
	5 - Like New, Recently Replaced	Excellent condition, free of visible wear or damage. Operation is within factory specifications.		
Body Panels	2 - Above Average Wear &	Tear		
Body Panel Condition	Some panel misalignment observed, Visible chipped paint or dents, Areas of surface rust observed			
Comments	The engine bay does not la	The engine bay does not latch closed.		
Doors / Canopy Latches	1 - Service Required			
Doors / Canopy Latches Condition	Other (see comments)			
Comments	The door is missing			
Steps / Ladders	0			
Handrails	3 - Normal Wear & Tear			
Handrails Condition	Handrails are fully intact ar	nd appear structurally sound		
Glass	0			
Mirrors	1 - Service Required			
Mirror Condition	One or more mirrors are broken or missing			
Exterior Lights	3 - Normal Wear & Tear			
Exterior Lights Condition	One or more exterior lights are non-operational			
Overall Exterior	2 - Above Average Wear & Tear			
Comments	The bottom section of the windshield is missing, the door is missing and the engine bay does not latch closed.			

## **Control Station Inspection Points**

#### **Control Station**

### **Control Station Photos**

 Control Station Photos
 Image: Station Photos

 <th mage: Station Pho



Serial Number Plate	と な な の の の に の の の に の の の の の の の の の の
Hour Meter/Odometer	
Control Station Type	Enclosed Cab (EROPS)
Option List	Unable to Confirm
Seat	2 - Above Average Wear & Tear
Seat Condition	Seat(s) have minor surface staining or small tears, Seat adjustment controls have limited range of motion, Seat belt secures properly, Seat belt is intact and in good condition
Cabin Lights	0
Safety Lock Out / Stop	3 - Normal Wear & Tear
Safety Lock Out / Stop Condition	Safety lock out device is present, in good condition, and functional
Controls & Switches	2 - Above Average Wear & Tear
Controls & Switches Condition	One or more switches are inoperative or missing
Hour Meter Activity	2 - Above Average Wear & Tear
Hour Meter Condition	Hour meter is functional, with some minor wear and/or cosmetic damage, Other (see comments)
Comments	It is difficult to see the screen.
Other Gauge Activity	2 - Above Average Wear & Tear
Other Gauge Condition	One or more gauges are unreadable or not functioning (specify in comments)
Heater & A/C	0



Travel Alarm	0
Horn	3 - Normal Wear & Tear
Horn Condition	Horn is installed and functioning as expected
Backup Camera	0
Control Station Overall Rating	2 - Above Average Wear & Tear
Control Station Overall Condition	Minor cosmetic wear to cabin surfaces, floors, panels, and ceiling
Comments	The travel controls get stuck. So if the operator let's go of the travel controls the machine will keep traveling. The cause of this was not known.

## **Engine Inspection Points**

## Engine

#### **Engine Compartment Photos**

Engine Data Plate	
Engine Compartment Photos	
Engine Type (Make, Model, Cylinders, Hp)	Yanmar, 4TNV88, 39Hp
Emissions Tier	Undetermined
Engine Serial Number	unable to verify
Engine Fuel Type	Diesel
Blow-by (Visual Observation Check)	No
Unusual Noises (Upon Start-up, Idle, Shutdown)	No
Engine Smoke (Upon Start-up, Idle, Shutdown)	No
Engine Exhaust Color	Clear



Battery	3 - Normal Wear & Tear		
Battery Condition	Dusty & dirty appearance		
Radiator	3 - Normal Wear & Tear		
Radiator Condition	Radiator fins & components appear to be in good working order, no signs of damage or leaks		
Belts	3 - Normal Wear & Tear		
Belt Condition	Belts appear in good condition & alignment with proper tension		
Hoses	3 - Normal Wear & Tear		
Hose Condition	Firm, pliant hoses with no signs of wear or leaks		
Water Pump	3 - Normal Wear & Tear		
Water Pump Condition	No unusual pump noises heard		
Cooling System Leaks	No		
Coolant Appearance	3 - Normal Wear & Tear		
Coolant Appearance Notes	Normal Translucent appearance, no visual signs of contamination		
Oil Leaks	No		
Oil Appearance	3 - Normal Wear & Tear		
Oil Appearance Notes	Appropriate oil level, Very dark, black & burnt oil appearance		
Fuel Leaks	No		
Equipped with DPF (Diesel Particulate Filter)	Yes		
DPF Condition	3 - Normal Wear & Tear		
DPF Condition Notes	Filter housing is intact with no signs of damage or malfunction, DPF indicator is not illuminated		
Requires DEF (Diesel Exhaust Fluid)	No		
Overall Engine Rating	3 - Normal Wear & Tear		
Overall Engine Appearance	Dusty & dry		
Overall Engine Comments	The engine is in good working condition		

## **Drivetrain Inspection Points**

### Drivetrain

## **Drivetrain Inspection Points**

Drivetrain Photos	
Hydrostatic Transmission?	Yes
Speeds	Unable to Verify
Drive Type	N/A (Track Undercarriage)



Transmission Components	3 - Normal Wear & Tear		
Transmission Condition	Good forward and reverse function, No unusual noises or vibrations		
Drive Motors	3 - Normal Wear & Tear		
Parking Brake	3 - Normal Wear & Tear		
Parking Brake Function	Good brake function		
Overall Drivetrain Rating	2 - Above Average Wear & Tear		
Overall Drivetrain Comments	There is an issue with the travel controls to this machine. They controls get stuck after you let them go. The cause was not known.		

### **Chassis Inspection Points**

Chassis Photos	
Boom Condition	3 - Normal Wear & Tear
Stick Condition	3 - Normal Wear & Tear
Boom Base Pin & Bushings	3 - Normal Wear & Tear
Boom to Stick Pin & Bushings	3 - Normal Wear & Tear
Stick to Bucket Pin & Bushings	3 - Normal Wear & Tear
Turntable Bearing	3 - Normal Wear & Tear
Bottom Covers	3 - Normal Wear & Tear
Overall Chassis	3 - Normal Wear & Tear
Overall Chassis Comments	The chassis is in good working condition

### **Travel System Inspection Points**

#### Rubber Track Undercarriage

#### **Undercarriage Photos**

**Undercarriage Photos** 



#### **Inspection Points**

Track Width (inches)	15 3/4in
Track Length (inches)	8ft 2.5in
Roller Frames	3 - Normal Wear & Tear



Track Belt	3 - Normal Wear & Tear			
Rubber Belt Drive Lugs	3 - Normal Wear & Tear			
Track Tensioners	3 - Normal Wear & Tear			
Front Idlers	3 - Normal Wear & Tear			
Rear Idlers	3 - Normal Wear & Tear			
Track Rollers	3 - Normal Wear & Tear			
Sprockets	3 - Normal Wear & Tear			
Overall Undercarriage Rating	3 - Normal Wear & Tear			
Left Track Belt - Percent Remaining Estimate	50%			
Right Track Belt - Percent Remaining Estimate	50%			
Overall Comments	The undercarriage is in good working order			

#### Hydraulics Overall Inspection Points

## **Hydraulics Overall**

### Hydraulic System Inspection Points

Hydraulic System Photos				
Wet or Damp Hydraulic Lines / Fittings	No			
Hydraulic Lines/Fittings	3 - Normal Wear & Tear			
Hydraulic Lines / Fittings Condition	Hydraulic lines & fittings are clean and in good condition			
Hydraulic Pump(s)	3 - Normal Wear & Tear			
Unusual Noises	No			
Hydraulic Pump Notes	No unusual noises heard during operation			

## Hydraulic Cylinder Inspection Points

Hydraulic Cylinder Photos	
Mounting Pins	3 - Normal Wear & Tear
Cylinder Oil Leaks	Yes



Comments	Small leak seen on the boom cylinder		
Hydraulic System Overall	3 - Normal Wear & Tear		
Comments	The overall hydraulic system is in good working order		

## **Bucket Inspection Points**

Attachment Photos				
	worn teeth			
Bucket	3 - Normal Wear & Tear			
Bucket Teeth	2 - Above Average Wear & Tear			
Comments	The bucket teeth are worn			
Blade	3 - Normal Wear & Tear			
Blade Edge	3 - Normal Wear & Tear			

# Additional Attachment Inspection Points

## Additional Attachment(s)

#### **Additional Attachments**

Attachment Type	Thumb		
Attachment Make	Тад		
Attachment Size / Specs	1ft 4in wide, 2ft 5.5in		
Attachment Condition	3 - Normal Wear & Tear		
Attachment Photos			

## **Functional Test**

# **Functionality Assessment**

Engine	3 - Normal Wear & Tear			
Transmission/Drivetrain	3 - Normal Wear & Tear			
Travel (Forward/Reverse/Steering)	2 - Above Average Wear & Tear			
Comments	The machines pilot controls will stick after letting them go. causing the righthand side track to keep moving. The cause was not known.			
Brakes	3 - Normal Wear & Tear			
Hydraulic System	3 - Normal Wear & Tear			



Electric Operating System	0			
Controls	- Normal Wear & Tear			
Safety Systems	- Normal Wear & Tear			
Core Functions	3 - Normal Wear & Tear			
Attachments	3 - Normal Wear & Tear			
Overall Functional Test Comments	The controls to the machines travel system stick at times. If the operator let's go of the controls the tracks will continue to move. The cause of this was not known.			

## **Overall Assessment**

#### **Overall Assessment**

Inspection Rating Criteria	Rating Scale	Explanation		
	1 - Service Required	Requires immediate repairs to function as expected.		
	2 - Above Average Wear & Tear	Exhibits greater wear than expected given age and usage. While operable, further diagnosis may be needed.		
	3 - Normal Wear & Tear	Exhibits wear that is consistent with age and usage. Operation is normal, and as expected.		
	4 - Very Light or Minimal Wear	Exhibits very minimal wear. Operation is better than expected given age and usage.		
	5 - Like New, Recently Replaced	Excellent condition, free of visible wear or damage. Operation is within factory specifications.		
Exterior Rating	2 - Above Average Wear & Tear			
Interior Rating	2 - Above Average Wear & Tear			
Safety Rating	3 - Normal Wear & Tear			
Quality Rating	2 - Above Average Wear & Tear			
Functionality Rating	2 - Above Average Wear & Tear			
Overall Rating	2 - Above Average Wear 8	2 - Above Average Wear & Tear		
Summary Video	Click to Download			
What's Great About the Machine	The engine started right up without any issues. The machine is fully functional and it comes with a bucket, thumb, and a blade.			
What Needs Work	The travel controls get stuck at times. Causing the machine to continue moving after the operator let's the controls go.			
Any Additional Info from the Seller?	This machine was used in civil construction			
Date/Time	01-18-2024			
Inspector Name	Steven Mesa			