

User's Manual

90050B, 90051B, 90055B, 90056B
TC-K 温度プローブ

このたびは、温度プローブをお買い上げいただきましてありがとうございます。
この取扱説明書は、本器の仕様、取り扱いの注意などについて説明したものです。
ご使用前に本書をよくお読みいただき、正しくお使いください。

YOKOGAWA ◆
横河計測株式会社

All Rights Reserved. Copyright © 2017
Yokogawa Test & Measurement Corporation
Printed in Japan

IM 90050B-Z2
2022.1 3版 (YMI)

安全にご使用いただくために

本器は、専門知識のある方がご使用いただくことを前提に開発された製品です。
本器を正しく安全にご使用していただくため、本器の操作にあたっては下記以降の注意事項を必ずお守りください。このマニュアルで指定していない方法で使用すると、本器の保護機能が損なわれることがあります。
このマニュアルは製品の一部分として重要な内容を含んでいます。本器を廃棄するまで、本器を使用するときにご覧になれるところに、このマニュアルを大切に保存してください。なお、これらの注意に反したご使用により生じた故障や損害については、YOKOGAWAは責任と保証を負いかねます。

本器および本書では、安全に関する以下のようなシンボルマークを使用しています。

⚠ 警告

回避しないと使用者が死亡または重傷を負う危険が想定される場合に使用します。

⚠ 注意

回避しないと使用者が軽傷を負う危険が想定される場合、または製品など機器に物理的損害が発生する可能性が想定される場合に使用します。

■ 感電事故など、使用者の生命や身体に危険が及ぶ恐れがあるため、次の事項を必ずお守りください。

⚠ 警告

- このプローブは、温度計または温度コレクタに使用する熱電対のプローブです。これらの用途以外には使用しないでください。
- 注射針形の温度プローブの先端を人間に向けないでください。先端が鋭く尖っているためけがをする可能性があります。
- 使用する機種用のものが確認して使用してください。
- シースと内部回路は絶縁されていませんので、電位がある対象には使用しないでください。
- 劣化したり損傷したプローブやリードは使用しないでください。
- 測定直後は、プローブが高温になっている場合があります。火傷に注意してください。
- 表面用温度プローブは、センサ部の被覆に傷・はがれのないことを確認のうえご使用ください。センサ部の被覆に傷・はがれのある状態でのご使用は非常に危険です。

■ 感電事故など、使用者が障害を負ったり機器を損傷する恐れがあるため、次の事項を必ずお守りください。

⚠ 注意

- シース形 (90050B, 90051B) のプローブは、被測定物にあまり深く差し込むと握り部分が加熱して損傷する可能性があります。差し込みは 1/2 程度までとしてご使用ください。
- シース形のプローブは曲げないでください。損傷する可能性があります。
- プローブの握り部分や配線部分は、温度計の使用温度範囲内でご使用ください。(シース部分と異なり耐熱性が低くなっています。)
- 表面用温度プローブをご使用の際には、次の点にご注意ください。損傷する可能性があります。
 - 被測定物に接触した状態で測定面上を滑らせるように移動させないでください。
 - 被測定物の表面がザラついたところでのご使用はおやめください。(表面用温度プローブは、センサ部の被覆に傷・はがれを起こす可能性があり非常に危険です。)
 - 測定温度範囲を超えた状態でのご使用はおやめください。

仕様

形名	説明 (タイプ)	測定温度範囲	シース径	シース長	許容差
90050B	液体用標準温度	-50 ~ 600°C	φ 3.2 mm	200 mm	T < 375°C : ± 1.5°C 375°C ≤ T : ± 0.004 × T°C (JIS C 1605 クラス 1 相当)
90051B	液体用高速温度	-50 ~ 600°C	φ 1.6 mm	150 mm	
90055B	表面用標準温度	-20 ~ 250°C	感温部径 φ 15 mm		(T-Ts) < 333°C : +2.5°C 333°C ≤ (T-Ts) : +0.0075 × T°C (T-Ts) < 167°C : -2.5°C 167°C ≤ (T-Ts) : -0.015 × T°C T: -20°C ~ 500°C, Ts: 0°C ~ 40°C
90056B	表面用高温温度	-20 ~ 500°C			

熱電対の種類 : K

T : 測定温度、Ts : 周囲温度

⚠ 注意

表面用温度プローブ保護キャップ着脱時の注意

表面用温度プローブ先端のセンサ部 (接触部) は非常に精密にできています。保護キャップ着脱の場合は、接触部に直接力を加えないようにしてください。圧力により損傷 (変形) する可能性があります。

- 本書に記載した事項は予告なしに変更することがあります。
- 特注品につきましては、個別規定とさせていただきます。

■ アフターサービス

本器をご使用中、万一不具合が生じ、正常な動作を示さず修理を要する場合には、お買い上げいただいた販売代理店または当社までお申し付けください。

YOKOGAWA ◆
横河計測株式会社

〒192-8566

東京都八王子市明神町四丁目9番8号

国内営業部

電話: (042)690-8811 ファクシミリ: (042)690-8826

User's Manual

90050B, 90051B, 90055B, 90056B
TC-K Probe

Thank you for purchasing our Temperature Probe.
This manual describes the specifications and handling precautions of the probe.
Before using this product, thoroughly read this manual to understand how to use it properly.

YOKOGAWA ◆
Yokogawa Test & Measurement Corporation

All Rights Reserved. Copyright © 2017
Yokogawa Test & Measurement Corporation
Printed in Japan

IM 90050B-Z2
3rd Edition: January 2022 (YMI)

Regarding Safe Use of This Product

This product is designed to be used by a person with specialized knowledge.

When operating the instrument, be sure to observe the cautionary notes given below to ensure correct and safe use of the instrument. If you use the instrument in any way other than as instructed in this manual, the instrument's protective measures may be impaired.

This manual is an essential part of the product; keep it a safe place for future reference.

YOKOGAWA is by no means liable for any damage resulting from use of the instrument in contradiction to these cautionary notes.

The following safety symbols are used on the instrument and in the manual:

WARNING

Indicates a hazard that may result in the loss of life or serious injury of the user unless the described instruction is abided by.

CAUTION

Indicates a hazard that may result in an injury to the user and/or physical damage to the product or other equipment unless the described instruction is abided by.

- To prevent a potential hazard that may result in loss of life or injury, such as an electric shock, be sure to abide by the safety precautions below.

WARNING

- This thermocouple probe is for the thermometer or thermo-collector.
Do not use this probe for other purposes.
- Do not point the tip of an injection needle probe at anybody as it is very sharp and may result in injury.
- Check that the probe and thermometer match before use.
- Do not use a sheathed probe on an object containing electric potential since the sheath is not electrically insulated from the internal circuitry.
- Do not use a deteriorated probe or lead wire.
- Do not touch the probe immediately after measurement, as it may be extremely hot and result in a burn.
- For a Surface straight probe, ensure that there is no damage to or peeling of the sensor sheath.
Using such a probe is extremely dangerous.

- To prevent potential hazard that may result in injury or damage to equipment, such as an electric shock, be sure to abide by the safety precautions below.

CAUTION

- When using a sheathed probe (90050B and 90051B), be sure to insert only up to about half of its length into the measured object.
Do not insert it further, or the grip will become extremely hot, resulting in a damage.
- Do not bend a sheathed probe, as this may result in damage.
- Ensure that the grip and cable of a probe is kept within the operating temperature range during use.
They are less heat-resistant than the sheath.
- To prevent damage when using a surface probe, do NOT:
 1. Slide the tip against the surface of the measured object.
 2. Use it on a rough surface.
(For a surface straight, this is extremely dangerous since it may cause damage to or peeling of the sensor sheath.)
 3. Use it to measure temperatures exceeding the measurement range.

Specifications

Model	Description (Type)	Measurement Range	Sheath Diameter	Sheath Length	Tolerance
90050B	Rounded end	-50 to 600°C	3.2 mm dia.	200 mm	T < 375°C: ± 1.5°C 375°C ≤ T: ± 0.004 × T°C
90051B	Rounded end	-50 to 600°C	1.6 mm dia.	150 mm	
90055B	Surface straight	-20 to 250°C	Diameter of thermosensitive part 15 mm dia.		(T-Ts) < 333°C: +2.5°C 333°C ≤ (T-Ts): +0.0075 × T°C (T-Ts) < 167°C: -2.5°C 167°C ≤ (T-Ts): -0.015 × T°C T: -20°C to 500°C, Ts: 0°C to 40°C
90056B	Surface straight	-20 to 500°C			

Thermocouple type: K

T: measurement temperature, Ts: ambient temperature

CAUTION

Precautions when attaching/detaching the surface probe protection cap

The sensor (contact area) at the tip of the surface probe is a precision device.
Do not apply direct force to the contact area when attaching/detaching the protection cap.
Otherwise, the sensor may become damaged or deformed by mechanical pressure.

- The contents of this manual are subject to change without prior notice.
- Customized models are subject to application of their respective, separate specifications.

Contacts of Services

Overseas Sales Representatives

YOKOGAWA ◆

Yokogawa Test & Measurement Corporation

YOKOGAWA TEST & MEASUREMENT CORPORATION
Global Sales Dept.
4-9-8 Myojin-cho, Hachioji-shi, Tokyo 192-8566, Japan
Phone: +81-42-690-8810

Yokogawa Europe B.V. ¹
Euroweg 2, 3825 HD Amersfoort, The Netherlands
Phone: +31-88-4641830

Yokogawa United Kingdom Ltd. ²
Stuart Road, Manor Park, Runcorn, Cheshire WA7 1TR,
United Kingdom
Phone: +44-1-928-597200

¹ The importer for this product into the EU/EEA market via the YOKOGAWA sales channel

² The importer for this product into the Great Britain market via the YOKOGAWA sales channel