

# PROLON

# Hardware Guide

Boiler Controller C1000 Series

**Specifications and Operational Guide** 

www.proloncontrols.com info@proloncontrols.com

**REV 6.3** 

PL-HRDW-C1000BLR-C/F-EN-V63



# **Table of Contents**

GENERAL INFORMATION	. 3
PL-C1000 Boiler Controller	. 3
Description	3
General Behaviour	3
Operating Sequence	. 4
General	4
Parallel Pump Sequence	4
Follower Pump Sequence	5
COMPONENTS	. 6
Component Identification	. 6
LEDs	. 7
Address Configuration for Networking	. 8
Jumper to supply power to the RJ45 plug	. 8
Input and Output Identification	. 9
INPUTS	10
Temperature Sensors	10
Proof of Pump	11
OUTPUTS	12
Output Specifications	12
Configuration of Digital Outputs	13
Typical Connection of Digital Outputs	14
Typical connection of the analog output	15
POWER SOURCE / NETWORK	16
Power Source	16
Network Communication	16
Technical Specifications	17
Compliance	18
FCC User Information	18
Industry Canada	18
OVERALL DIMENSIONS	19

info@proloncontrols.com www.proloncontrols.com PRSLON 1-877-9PROLON

### <u>Montréal</u>



# **GENERAL INFORMATION**

# **PL-C1000 Boiler Controller**

# Description

The ProLon PL-C1000 Boiler controller is a microprocessor-based controller designed to operate staged boilers, as well as the associated pumps and valves. It features a variety of control strategies, including outside temperature reset, lead-lag sequences, pump exercise intervals and more.



### General Behaviour

Although fully configurable, the ProLon C1000 Boiler controller monitors dedicated inputs and uses preestablished control sequences to drive dedicated outputs to control standard Boiler equipment. These sequences can be fully optimized to obtain the best results for each type of system. Numerous parameters enable the modification or fine tuning of the pumps, the boilers, the target supply temperature, the proportional bands, integration times, differentials, operational ranges, setpoints and a whole range of limits and safeguards. The various programming options also allow the user to modify the lead-lag sequences, conditions for pump activity and the influence of schedules or other data received over the network. All these parameters can be accessed and modified by using the ProLon Focus software.

info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>



# **Operating Sequence**

### General

The ProLon C1000 Boiler controller receives readings from three different temperature sensors: outside air, supply water and return water. In addition to the temperature sensors, it also has an input for proof of operation of the pumps. It can receive data from ProLon master controllers such as outside temperature, occupancy, or the average heating request of the building. The controller then analyzes all the data and activates the appropriate outputs to respond accordingly, within parameters set by the temperature sensors and other safety limits.

# Parallel Pump Sequence

This sequence is intended for hydronic systems where there is a secondary pump that acts as a backup to the primary pump, with both pumps being installed in parallel. The primary pump is activated based on outside temperature or upon a call for heating, or both. The secondary pump will only be activated when there is no proof of operation of the primary pump after a configurable delay.

The pumps can be setup for various lead-lag sequences wherein they will alternate between primary and secondary roles. The pumps can also be exercised after configurable periods of inactivity.

The target supply temperature can be a fixed setpoint or instead follow a reset based on outside temperature. The target supply temperature can also be reduced in unoccupied mode or influenced by a network provided demand, usually representing an average heating request coming from the zones in the building.

Boiler activity is based on a call for heat (i.e. supply temperature is below the target), which can be interlocked with the outside temperature. The C1000 boiler controller can be configured to control up to two boiler stages. Boiler stages can also be set up for various lead-lag sequences that will cycle through the position of the lead boiler stage.

The C1000 boiler controller can also be used to control a three way valve, which it will modulate to attain the target temperature.

info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>

1989 rue Michelin Laval, QC H7L 5B7 TEL:(450) 973-5100 FAX: (450) 973-6186



# Follower Pump Sequence

This sequence is intended for hydronic systems where there is a primary and secondary loop. The primary pump is activated based on outside temperature or upon a call for heating, or both. The secondary pump will be activated simply when there is proof of operation of the primary pump.

The pumps can be exercised after configurable periods of inactivity.

The target supply temperature can be a fixed setpoint or instead follow a reset based on outside temperature. The target supply temperature can also be reduced in unoccupied mode or influenced by a network provided demand, usually representing an average heating request coming from the zones in the building.

Boiler activity is based on a call for heat (supply temperature is below the target), which can be interlocked with the outside temperature. The C1000 boiler controller can be configured to control up to two boiler stages. Boiler stages can also be set up for various lead-lag sequences that will cycle through the position of the lead boiler stage.

The C1000 boiler controller can also be used to control a three way valve, which it will modulate to attain the target temperature.

info@proloncontrols.com www.proloncontrols.com




<u>Montréal</u>



# COMPONENTS

# **Component Identification**



Legend:

- A = Addressing dipswitch
- **B** = Jumpers for terminating and bias resistors for the NET port (see  $\underline{J}$ )
- C = Jumpers for terminating and bias resistors for the INT port (see K)
- **D** = SOURCE/SINK dipswitch for Output 4 (Boiler Stage 2)
- *E* = SOURCE/SINK dipswitch for Output 3 (Boiler Stage 1)
- **F** = SOURCE/SINK dipswitch for Output 2 (Pump 2)
- G = SOURCE/SINK dipswitch for Output 1 (Pump 1)
- H = Reset Button
- *I* = Jumper to supply voltage to INT port (see <u>J</u>)
- J = INT port for RS485 communication (RJ45 jack)
- K = NET port for RS485 communication (terminal block)
- L = Inputs (4 total)
- M = Terminal Blocks for Outputs 1 to 5
- N = Terminal Blocks for 24 VAC

info@proloncontrols.com www.proloncontrols.com




### <u>Montréal</u>



7


LEDs

The C1000 has various LEDs which are linked to different functions and outputs of the controller. Each LED is individually identified to help the user make a quick visual diagnostic of the controller's activity and status.





# **Address Configuration for Networking**



A unique address on each controller must be configured by setting the first 7 switches on the addressing dipswitch to the desired value.

These switches are numbered from 1 to 7 and represent a binary value from 1 to 64 (1, 2, 4, 8, 16, 32, 64 respectively). The value of each switch that is in the ON position is added together to form the numerical address of the controller.

Figure 1: Addressing Dipswitches

The example on Figure 1 shows the switches 1, 2 and 4 on the ON position. So the corresponding values are 1, 2 and 8, giving an address sum of 11. (1+2+8=11)

The ProLon network allows a maximum of 127 addresses, therefore 127 controllers.

# Jumper to supply power to the RJ45 plug

The RJ45 jumper lets the user select the voltage that will appear on pin #7 of the RJ45 plug. This can be used to power a device attached to the RJ45 plug, such as a digital sensor or interface. <u>NOTE</u>: If multiple C1000 controllers are connected together through the RJ45 plug, <u>only one</u> C1000 should be supplying power onto the RJ45, otherwise you will be mixing your supply sources and possibly cause damage. The jumper setups are as follows:

• • •

24 VAC

••• No power



info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>

1989 rue Michelin Laval, QC H7L 5B7 TEL:(450) 973-5100 FAX: (450) 973-6186




# Input and Output Identification


All the inputs and outputs of the C1000 use pluggable screw type terminal blocks with elevator style clamping, which make connections easier and more secure.

The C1000 Boiler Controller has two separate communication ports offering the same functionality on each. Both act as ports for incoming Modbus communications from other ProLon devices or interfaces, such as a Network Controller or remote computer with ProLon Focus software.

The "INT" Port (see below) uses an RJ45 type connector. The RJ45 connector allows the use of premade CAT5 cables for simple plug-and-play RS485 communication. This RJ45 connector follows the Modbus pinout specification for RS485 communication.



**RJ45** Pinout



info@proloncontrols.com www.proloncontrols.com PRSLON 1-877-9PROLON

<u>Montréal</u>



info@proloncontrols.com

www.proloncontrols.com

# C1000 SERIES BOILER CONTROLLER HARDWARE GUIDE

# INPUTS

# **Temperature Sensors**

The C1000 Boiler controller has three analog inputs that monitor outside air, supply water and return water temperatures (see Figure 2) and will integrate these readings into its control sequence. The sensors used are standard 10k type thermistors that share a single common connection.

The outside air temperature can be also be provided by an alternate source. If a network controller is present on the network, it can retrieve the outside temperature reading from one controller and distribute it to any other controllers on the network.




Figure 2: Connecting the temperature sensors




<u>Montréal</u>

1989 rue Michelin Laval, QC H7L 5B7 TEL:(450) 973-5100 FAX: (450) 973-6186



# **Proof of Pump**

The C1000 has one digital inputs dedicated to the proof of pump signals. Please refer to Figure 3 see how to correctly connect it. To indicate proof of pump, the contact must be closed. If no proof of pump signal is available, you must short the corresponding input, or else the controller will interpret the absence of signal as a pump malfunction and no heating action will be taken.



### Figure 3: Connecting the proof of pump contacts to the controller

info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>



# OUTPUTS

The C1000 Boiler controller contains 5 customizable outputs; four triac ON/OFF outputs (24VAC) and one analog output (0-10VDC). Output configuration is performed via the ProLon Focus software.

An integrated resettable fuse protects **each** of the outputs of the C1000 against current surges and short circuits. This protection will cut the current to the output as soon as an overload condition is detected. The fuse is round and yellow-colored which, upon a short circuit condition, will heat up and change to orange. When the faulty wiring or circuit is fixed, the fuse will automatically reset and allow current to flow through the output again.

Output	Туре	Action	Application
DO 1	Triac source 24VAC Max Current:300 mA	On-or-Off	Pump Stage 1
DO 2	Triac source 24VAC Max Current:300 mA	On-or-Off	Pump Stage 1
DO 3	Triac source 24VAC Max Current:300 mA	On-or-Off	Boiler Stage 1
DO 4	Triac source 24VAC Max Current:300 mA	On-or-Off	Boiler Stage 2
AO 1	Configurable Analog Output: - 0 to 10 VDC - 2 to 10 VDC - 0 to 5 VDC Max Current: 40 mA	Modulating proportional	Three Way Valve or Modulating Boiler

# **Output Specifications**

info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>




13



The digital triac outputs are configurable (SOURCE/SINK) via a switch located on the board. Simply move the switch to obtain either a SOURCE active output (1) or a SINK passive output (2).

1) Switch position to obtain a SOURCE active output (see Figure 4):





# **Typical Connection of Digital Outputs**

Two types of configurations are possible:

1) Active output (SOURCE). The C1000 is actively powering the load. (see Figure 6)




Figure 6: Connection of active outputs 3 and 4

 Passive output (SINK). The C1000 opens and closes a contact to allow an external source to power the load (see Figure 7).




Figure 7: Connection of passive outputs 3 and 4

info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>



info@proloncontrols.com

www.proloncontrols.com

# C1000 SERIES BOILER CONTROLLER HARDWARE GUIDE

# Typical connection of the analog output

Two types of configuration are possible:

1) The C1000 powers the load and provides a control signal (see Figure 8)




Figure 8: Connecting the analog output (controller powered)

2) The C1000 only provides the control signal to the load, which is powered by an external source (see Figure 9)




Figure 9: Connecting the analog output (external power)



<u>Montréal</u>



# **POWER SOURCE / NETWORK**

# **Power Source**






Figure 10: Connecting the 24VAC power source

The ProLon C1000 controller is powered by a 24 VAC power source connected using the "COM" terminal and the "24 VAC" terminal (see Figure 10). The common for all inputs and outputs are the same as the power source's common (exception: when an output is set to passive, the common for this output will not correspond to the power source common). All output power sources also originate from the controller's power source.

# **Network Communication**

The ProLon C1000 controller works autonomously or networked. When networked, it will communicate in real-time with other controllers. The C1000 controller's default communication protocol is Modbus RTU over RS485. The addressing is done with the addressing dipswitch located on the C1000 card (see Figure 1). The network connections are made using the NET terminal block located on the ProLon C1000 controller (see Figure 11).





info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>

1989 rue Michelin Laval, QC H7L 5B7 TEL:(450) 973-5100 FAX: (450) 973-6186



# **Technical Specifications**

Supply: 24 VAC ±10%, 50/60 Hz, Class 2

Consumption: 5 VA

Inputs: Outside air - thermistor 10K

Return Water– 10 K thermistor

Supply Water- 10 K thermistor

Proof of pump - dry contact

Digital outputs: 4 triac outputs, 10-30 VAC source or dry contact, 300 mA max (resettable fuse)

Analog output: 1 output 0-10 VDC / 2-10 VDC / 0-5 VDC, 40 mA max (resettable fuse) for the valve

Indication lights (LED): State of each output / Communication / Supply / State of microprocessor

Microprocessor: PIC18F6722, 8 bits, 40 MHz, 128KB FLASH memory

Casing: Molded ABS

Communication: Modbus RTU (RS485), up to 127 nodes

Baud rate: 9600, 19200, 38400, 57600, 76800, 115200

Wiring: Removable screw-type terminal blocks (16 AWG max) and RJ45 modular jack

Dimensions: 157 mm x 133 mm (6.2" x 5.2" )

Environment: 0-50 °C (32-122 °F) Non-Condensing

The performance specifications are nominal and conform to acceptable industry standards. ProLon Inc. will not be liable for damages resulting from misapplication or misuse of its products.

info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>



# Compliance

- FCC Compliant to CFR47, Part 15, Subpart B, Class B
- Industry Canada (IC) Compliant to ICES-003, Issue 5: CAN ICES-3 (B)/NMB-3(B)
- RoHS Directive (2002/95/EC)

### **FCC User Information**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications not approved by ProLon can void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.


### **Industry Canada**

This Class (B) digital apparatus meets all the requirements of the Canadian Interference-Causing Equipment regulations. Cet appareil numérique de la Classe (B) respecte toutes les exigences du Réglement sur le matériel brouilleur du Canada.

info@proloncontrols.com www.proloncontrols.com



<u>Montréal</u>



info@proloncontrols.com

www.proloncontrols.com

1-877-9PROLON

Montréal