Specifications	OE425/525	OE455/555
Wavelength Range	500–870 nm / 460–870 nm (0.1 V/mW)	950–1630 nm / 800–1630 nm (0.1 V/mW)
Conversion Gain	0.5 V/mW	1.1 V/mW
Bandwidth	4.5 GHz (6 GHz optical)	3.5 GHz (4.5 GHz optical)
Equivalent Noise	2.2 μW rms	1.0 μW rms
Maximum Optical Power (at 5% saturation)	2.2 mW	1.0 mW
Rise Time (typical)	90 ps	108 ps
Maximum Safe Input	5.5 mW	2.5 mW
Temperature Drift	0.00275 dB/deg. C	
Frequency Response Ripple	1.1 dB	
Connector Type	FC/PC	
Temperature (Operating)	5 °C to 40 °C	
Temperature (Storage)	-20 °C to 60 °C	
Humidity (Operating):	5% to 80% RH (non-condensing), 50% RH above 30 °C	
Humidity (Storage)	5% to 95% RH* (non-condensing) * 75% RH above 30 °C and 45% RH above 40 °C	
Certifications	Conforms to EN61010-031/A1:2008 (Safety) and EN61326-1:2006 (EMC)	



**CAUTION**. Use only within operational environment listed. Do not remove probe casing. Observe all terminal ratings. Use product only as specified.

#### Calibration

The recommended calibration interval is one year. Calibration should be performed by qualified personnel only.


## Cleaning

Clean only the exterior of the converter with a soft cloth moistened with water or 75% isopropyl alcohol solution. Under no circumstances should moisture be allowed to penetrate the converter. The fiber connectors can be cleaned by blowing residue-free air into the connector to remove loose particles.



**CAUTION**. The converter's fiber connectors should be mated only to other well cleaned connectors.

# Typical Response vs. Frequency



© 2013 Teledyne LeCroy, Inc. All rights reserved.

Unauthorized duplication of Teledyne LeCroy documentation materials other than for internal sales and distribution purposes is strictly prohibited. Teledyne LeCroy, WavePro, and WaveMaster are registered trademark of Teledyne LeCroy, Inc Information in this publication supersedes all earlier versions. Specifications are subject to change without notice.



#### Application

The OE4x5 and OE5x5 are optical-to-electrical converters with multimode fiber inputs. They are specifically designed for the measurement of optical telecommunication signals. DC, AC, and impulse light intensities can be measured (with the oscilloscope automatically converting units to Watts) as cursor or parameter measurements are being made.

The OE4x5 and OE5x5 converters are compatible with Teledyne LeCroy WavePro® and WaveMaster® series oscilloscopes:

- OE4x5 models fit BNC (ProBus) connectors or ProLink connectors when using a BNC adapter (TPA-BNC).
- OE5x5 models fit ProLink connectors.



CAUTION. The fiber cable is fragile, handle with care.

### **Application as Optical Reference Receiver**

With the OE4x5 and OE5x5, you can filter the optical signal in a precise way, in accordance with ITU-T G.957 and other optical standards (such as IEEE802.3) so that the scope and probe chain will constitute an Optical Reference Receiver, per Annex B of G.957.

When used with a WaveMaster or WavePro series oscilloscope, the converters have a response vs. frequency that follows a 4th order Bessel-Thompson lowpass filter whose -3 dB cutoff frequency is set by the user-adjustable data rate. This filter adapts to the probe automatically, so it remains calibrated regardless of the channel on which it is used.

### **Quantity of Light**

What the scope displays is actually the voltage resulting from the conversion of the light signal by an optical-to-electrical converter. The efficiency of this conversion (V/W) depends on the wavelength of the incident light.

The OE4x5 and OE5x5 are designed to operate optimally over different wavelengths:

- OE455 and OE555 operate over the 950 to 1630 nm range
- OE425 and OE525 operate over the 500 to 870 nm range

The probes are calibrated at 1550 nm and 800 nm, respectively.

Therefore, when other wavelengths of light are measured, the power displayed by the scope will differ slightly from the actual value.

The detectors are "multimode"; they will remain accurate when used with either single or multimode optical fibers.

Another factor affecting the measurement of power is the insertion loss of cables chained between the light source and the probe. Each optical connection will typically cost between 0.3 and 0.5 dB (7% to 12%) of light output. Scope calibration is based on light at the probe FC connector.

### Measurements of Small Amounts of Light

Through "Enhanced Resolution" and "Averaging" of mathematical functions, it is possible to measure very small signals that represent minute amounts of light. However, the offsets generated by temperature changes can become significant. If the absolute amount of light is to be measured, you should plan for frequent scope re-calibrations, or minimize temperature variations. But if only the amplitude of light modulation is to be measured, this is not critical.

#### Operation with Oscilloscope

The OE4x5 probes use ProBus style connectors. Therefore, a BNC-BMA adapter is required when they are to be used with a WaveMaster oscilloscope.

The probe response can be read directly from the oscilloscope **Probe** dialog, which will have the same name as the connected converter. From the **Vertical** drop-down menu, select the channel to which the OE is connected, then click the <probe> tab. The probe information is listed at the right of the dialog and the reference receiver filter selection is shown at the left. The reference receiver is set to a given standard by selecting it from **Receiver Standard**.

You can also select a user-defined filter from **Receiver Standard**, then enter either the **Receiver Bandwidth** or **Data Rate** in the appropriate field. These two values are related in that the receiver bandwidth is 75% of the data rate. Only one of the two parameters need be entered; the other will be computed automatically.

A selection is also available for disabling the reference receiver filter.

When the probes are used with the WaveMaster or WavePro series oscilloscope in combination with the universal reference receiver, the probe response is automatically matched to the scope and channel, and the bandwidth response is adjusted to the user-selected data rate.

## **Optical Reference Receiver Background Information**

An Optical Reference Receiver has a filter that implements the transfer function:

$$\frac{105}{105 + 105y + 45y^2 + 10y^3 + y^4}$$

Where y is defined as:

$$2.114 \times \frac{2\pi f}{2\pi f_r}i$$

and fr is the reference frequency (chosen as 0.75f0) and f0 is the bit rate (for example, 2.4488 GHz for OC48/STM4). The form of the transfer function is the inverse of a Bessel Polynomial (see Krall, H. L. and Fink, O., "A New Class of Orthogonal Polynomials: The Bessel Polynomials," Trans. Amer. Math. Soc. 65, 100-115, 1948). Filters implementing Bessel polynomials as denominators of the transfer function are called Thompson filters, hence the name "fourth order Thompson-Bessel" for the transfer function. The order n Bessel polynomial is simply given by the formula:

$$\sum_{k=0}^{n} x^{k} \frac{(2n-k)}{2^{n-k} k! (n-k)!}$$

The factor 2.114 in Equation 2 simply ensures that the norm squared of the transfer function reaches (the "-3 dB point") at the reference frequency. The main property of the Bessel-Thompson filter is a minimal group delay distortion. The group delay is defined by the derivative of the phase delay with respect to the frequency of an input sine wave. When quoted in "UI," the group delay is normalized to the bit rate's period. The group delay of the fourth-order Bessel-Thompson filter at low frequencies is:

$$\frac{2.114}{1.5\pi f_0} = \frac{0.4486}{f_0}$$

The group delay diminishes monotonically, reaching 0.1512 UI at a frequency of two times the bit rate. The difference between the group delay at zero frequency and the group delay at a given frequency is called the group delay distortion. The conformity of the response to the specifications for the combination of probe and scope channel is verified in detail on a clean optical impulse at the factory.