INSTRUCTIONS

PAGE 1 OF 13

SAFETY INSTRUCTIONS

1. Do not use outdoors. 2. Equipment should be mounted securely in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel. 3. Do not mount near gas or electric heaters. 4. Cap unused wires with enclosed wire nuts or other approved method. 5. Do not use this equipment for anything other than its intended use. 6. The use of accessory equipment not recommended by the manufacturer will void product listing and warranty and may cause an unsafe condition. 7. Use caution when servicing batteries. 8. Any service on this equipment should be performed by qualified personnel only. 9. Make sure wire terminations are secure and leads are properly tucked in appropriate wire channels. CONSULT A QUALIFIED ELECTRICIAN BEFORE INSTALLING



Caution:


Disconnect AC power before servicing and installation. All electrical connections must be in accordance with NEC/CEC or your local code.



Caution:

Track system is polarized to accept power connectors only one way. This right hand connector will fit directly into the open end of the track system as shipped from the factory

SURFACE MOUNT TRACK SYSTEM







www.iuseelite.com


PAGE 2 OF 13

TRACK RAIL OVERVIEW



MOUNTING TRACK





*Tolerance -+1/4"





PAGE 3 OF 13

INSTRUCTIONS STEPS

1.

Raise track assembly to ceiling. Mark mounting hole locations. Track support points should be not more than 4' apart. Use support points as shown above.

2.

Drill ceiling holes suitable for the fasteners you intend touse. Toggle wings (supplied) require ½ inch holes..

3.

If additional holes in track are needed, drill 5/32" holes through the centerline of track (locate holes at least 6" in from track ends).

Insert bolts through track, and into the toggle wings, tighten 2 or 3 turns.

5.

Push toggle wings into ceiling holes. Do not fully tighten toggle bolts until all electrical connections are made.


FIELD CUTTING TRACK

Do not allow bus wires and insulation to protrude from the end and do not cut the wires and push insulation back into the track.




2.

Make a flush cut through track with a fine-toothed hacksaw. File any rough edges or flash. Brush out any remaining filings.



3.

Once the flush cut is made trim 1/4" off the end of the copper bus wire. This will allow sufficient clearance for the end cap for a mating connector. If not performed in this sequence the bus wires will be short and cause faulty contact.





4.

When mating to connector already at ceiling level make sure to support connectors at both ends.


Second Circuit Positioning

1.

Hold onto adapter box with one hand.

2.


Place the end of a flat head screw driver under the contact shown below or use a needle nose pliers and pullup the contact tab



Polarity


1-Circuit Track

2-Circuit Track




1 Circuit Vs 2 Circuit

1 Circuit Connection



2 Circuit Connection




1 Circuit Live End Connector

PAGE 4 OF 13

INSTRUCTIONS STEPS


1.

Install connector into track rail. Arrows on connector must be on same side as polarity groove on the track sections. Secure track to ceiling surface.




2.

Secure by tightening screw at the tip of the connector until snug. Do not over tighten since this may distir the track.



3.

Pull wires into live end connector and attach "HOT" wires to terminate marked "1" and "2". Attach neutral wire to "NEUT" terminal. Finally attach ground wire to green ground screw marked "GND" provided on back plate.





Circuit Floating Canopy

INSTRUCTIONS STEPS

1.

Fasten mounting strap to outlet box. Connect ground wire.

2.

Locate track below outlet box in desire position then:

- a) Rotate ground clip to accept track and push track into clip
- b) Fasten track to ceiling following instructions supplied with the track section
- c) Track ends must be terminated with either a dead end or a connector.

3.

Insert electrical adaptor into track, rotate 90 to locked position to make electrical contact.


Note:

- a) Polarity side of electrical adaptor (The side of grounding tab or marked "N") must point to track debossed polarity line.
- b) Center line of electrical adaptor must be set on center line of outlet box.

4.

Pull positive (Black) wire from outlet box and attach to brass screw terminal marked "P". Pull neutral (White) wire, on opposite of track, and attach to nickled-plated screw terminal marked "N". Push excess wire back into outlet box-wire must hug track side. Install cover and secure with screw.

INSTRUCTIONS



PAGE 5 OF 13


INSTRUCTIONS STEPS

1.

Remove the end cap and insert the mini coupler. Ground conductor must be on same side of sections of track rail being joined

2.

Secure by tightening screw at the tip of the connector until snug. Do not over tighten since this may distort the track.





ET108

1 Circuit "L" Connector with Power Entry

INSTRUCTIONS


INSTRUCTIONS STEPS


Note:

Ground contact (Silver) must be on the same side as the Polarity Groove of the track. If Polarity groove and Ground Contact does not line up remove 2-scres from cover, remove cover and adjust connector 180 as shown. Install cover and screws. (If used as a Power Feed DO NOT INSTALL COVER until wire connections are made as noted below).

1.

Insert ends of connector into ends of track (Ground Contact must line up with Polarity Groove of track.) Secure to track by tightening lock screws at the tip of connector until snug. DO NOT OVER TIGHTEN. This may distort track





Note:

If used as a Power Feed Point

1.

Remove plastic plug button from back plate pull supply wires through center connect power supply colored (Line) to brass screw marked "P" white (Neutral) to nickel plated screw marked "N". Ground to green screw when required.






1 Circuit Flex Connector to Connect Track at Any Angle

PAGE 6 OF 13

INSTRUCTIONS STEPS

1.


Locate small arrow on the flex connector body and align with polarity groove on the track.



2.


Insert into the open end of the track and push fully into place..

Secure by tightening screw near the arrow.



4.

Remove plastic end cap from the other track and install the other end of the ET110 in a similar manner making certain that polarity groove on the track sections are in line.




1 Circuit "T" Connector to Connect 3 Track Sections

PAGE 7 OF 13

INSTRUCTIONS STEPS (OPTION 1)

1.

To use as factory assembled inserts each end.of connector into end of each track making sure silver ground contact is on the same side as polarity groove in track. (Track and connector are polarized) secure connector to track by tightening lock screws on each end of connector




INSTRUCTIONS STEPS (OPTION 2)


Note:

If used as a Power Feed Point.

1.

Remove KO from back plate pull supply wires through center connect power supply colored (Line) to brass screw marked "P" white (Neutral) to nickel plated screw marked "N". Ground to green screw when required.






ET112 1 Circuit "X" Connector to Connect 4 Track Sections


PAGE 8 OF 13

INSTRUCTIONS STEPS (OPTION 1)

1.

To use as factory assembled inserts each end of connector into end of each track making sure silver ground contact is on the same side as polarity groove in track. (Track and connector are polarized) secure connector to track by tightening lock screws on each end of connector






INSTRUCTIONS STEPS (OPTION 2)


Note:

If used as a Power Feed Point.

1.

Remove KO from back plate pull supply wires through center connect power supply colored (Line) to brass screw marked "P" white (Neutral) to nickel plated screw marked "N". Ground to green screw when required.





Note:

If four seperate circuits are desired and feed wires are available from the outlet box remove jumpers and connect 1 circuit to each set of terminals.






PAGE 9 OF 13

INSTRUCTIONS STEPS

The ET115 allows the use of Elite extensions stems where track rail is mounted on a slope ceiling. The following weight limitations should be observed



The track rail itself may require reinforcing if multiple fixtures are used. To reinforce the track rail, Note:

drill additional holes in track rail and fasten with low profile connectors that will not interfere

with the Slope adapter or other lampholders

Caution: Ceiling and wall material may require special precautions to support the total weight.

1 Circuit Live End with 15 Foot Cord

PAGE 10 OF 13

INSTRUCTIONS STEPS

NOTE:


Polarity groove on track and ground conductor arrow on connector must be on same side

Insert ends of connector into ends of track (Polarity arrow must line up with Polarity Groove of track). Secure to track by tightening lock screw at tip of connector until snug. DO NOT OVER TIGHTEN, this may distort track.

Install track to wall or ceiling.

3.

Insert cord and plug into any convenient wall outlet.





T126
Circuit Conduit Connector

INSTRUCTIONS

INSTRUCTIONS STEPS

1.

Insert and of connector into the system. If connector does not slide easily into the track DO NOT FORCE. Track connector is polarized. Turn connector around and use opposite ends. Ground contact is on same side as polarity groove in track. Tighten lock screw at end of connector to secure to track.


2.

Remove covers A and B from conduit connectors. Attach 1/2" connectors (not supplied) and conduit to 7/8" diameter holes on end of track

3.

Feed wires through conduit. Strip 3/8" of wire insulator. Connect black wire to brass screws marked "P", white wire to nickel screws marked "N" and ground to green screw when required.

Install Covers A and B.



Strip 3/8" of wire insulator











J-Style Track Adapter

PAGE 11 OF 13




Note:

This is only the track adapter and it must be added to track head fixture, otherwise track head fixture will come with H-Style adapter.

INSTRUCTIONS STEPS

1


Insert the J-Style track adapter into the Juno track channel and rotate it 90 degrees.



2-Circuit Track Installation

1.

For a 2-Circuit track raised the tab with a flat head screw driver, or with a needle nose.



2. Repeat the steps as 1-Circuit Track.



ET172


_-Style Track Adapter


INSTRUCTIONS

INSTRUCTIONS STEPS

1.

Insert the L-Style track adapter into the Lytespan track channel and rotate it 90 degrees.






2-Circuit Track Installation

1.

For a 2-Circuit track raised the tab with a flat head screw driver, or with a needle nose.




2.

Repeat the steps as 1-Circuit Track.



Note:


This is only the track adapter and it must be added to track head fixture, otherwise track head fixture will come with H-Style adapter. Eutrac data adapters must be used with Eutrac data bus track channel (EUTRAC Track 238).



Overview

1.

Insert EUTRAC MultiAdapter into the Eutrac 238 track channel.




*Collar might change depending on the track head fixture

Instructions Steps

1

Insert EUTRAC MultiAdapter into the Eutrac 238 track channel.




2.

Turn Knob A clockwise 90 degrees to connect the adapter to the neutral circuit.

Turn Knob B counter clockwise 90 degrees to connect the adapter to circuit 1

Turn Knob B clockwise 90 to connect the adapter to the neutral circuit.



www.iuseelite.com

EUTRAC (2 Circuits)


Data Track Adapter for DMX/DALI/0-10V Protocol

PAGE 13 OF 13



Note:


This is only the track adapter and it must be added to track head fixture, otherwise track head fixture will come with H-Style adapter. Eutrac data adapters must be used with Eutrac data bus track channel (EUTRAC Track 233/244).



Overview

1.

Insert EUTRAC MultiAdapter into the Eutrac 233/244 track channel.




*Collar might change depending on the track head fixture

Instructions Steps

1

Insert EUTRAC MultiAdapter into the Eutrac 233/244 track channel.



2.

Turn Knob A clockwise 90 degrees for mechanical fixing.
Turn Knob B counter clockwise 90 degrees to connect the adapter to circuit 1

Turn Knob B clockwise 90 to connect the adapter to circuit 2.

