



**OPERATOR'S MANUAL
MANUEL de L'UTILISATEUR
MANUAL del OPERADOR**



ALBION 18V CORDLESS TWIN CARTRIDGE GUNS

PISTOLET À CARTOUCHE DOUBLE ALBION 18V SANS FIL

ALBION 18V PISTOLAS INALÁMBRICAS DE DOS CARTUCHOS

TO REDUCE THE RISK OF INJURY, USER MUST READ AND UNDERSTAND OPERATOR'S MANUAL.

AFIN DE RÉDUIRE LE RISQUE DE BLESSURES, L'UTILISATEUR DOIT LIRE ET BIEN COMPRENDRE LE MANUEL DE L'UTILISATEUR.

PARA REDUCIR EL RIESGO DE LESIONES, EL USUARIO DEBE LEER Y ENTENDER EL MANUAL DEL OPERADOR.

GENERAL DRIVE OPERATION






FONCTIONNEMENT GÉNÉRAL

OPERACIÓN DE ACCIONAMIENTO GENERAL


When trigger is released, the motor will run for a short time to release the rod. This prevents a drip.

Lorsque la gâchette est relâchée, le moteur fonctionnera pendant un court instant pour libérer la tige. Cela empêche un goutte à goutte.

Cuando se suelta el gatillo, el motor funcionará por un corto tiempo para liberar la varilla. Eso evita un goteo.



WARNING PINCH POINTS
AVERTISSEMENT POINTS DE PINCEMENT
ADVERTENCIA PUNTOS DE PELLIZCO



BATTERY OPERATION

FONCTIONNEMENT DE LA BATTERIE





FUNCIONAMIENTO DE LA BATERÍA




Remove the battery pack before starting any work on the machine.

Retirez la batterie avant de commencer tout travail sur la machine.

Retire la batería antes de iniciar cualquier trabajo en la máquina.



CHARGER OPERATION
FONCTIONNEMENT DU CHARGEUR
OPERACIÓN DEL CARGADOR



78-100%




55-77%




33-54%



10-32%



10%




GENERAL CARTRIDGE INSERTION FONCTIONNEMENT GÉNÉRAL OPERACIÓN DE ACCIONAMIENTO GENERAL


INSTALL
INSTALLER
INSTALAR



READY FOR DISPENSING
PRÊT POUR LA DISTRIBUTION
LISTO PARA DISPENSAR




REMOVE
RETIRER
RETIRAR



ALTERNATE CARRIAGE STYLES STYLES DE CHARIOT ALTERNATIFS | ESTILOS DE CARRO ALTERNATIVOS

BARREL






SIDE-LOAD






600ML SERIES EJECTOR SETUP
FONCTIONNEMENT GÉNÉRAL
OPERACIÓN DE ACCIONAMIENTO GENERAL

600ml 1:1 Setup




600ml 2:1 Setup




EJECTOR SETUP
Configuration de l'éjecteur
Configuración del eyector


825ml 10:1 Setup




900ml 2:1 Setup



380ml 4:1 Setup



380ml 10:1 Setup



NOTES

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

| MODEL NO | FEED FORCE | BATTERY VOLTAGE | WEIGHT According EPTA - Procedure 01/2003 (1.5 Ah) | |
|------------|------------------------------|-----------------|---|--------|
| E18T300 | 4226N (950 lb _f) | 18V | 8.0 lb | 3.6 kg |
| E18T375 | 4226N (950 lb _f) | 18V | 8.0 | 3.6 |
| E18C380X4 | 4226N (950 lb _f) | 18V | 7.7 | 3.5 |
| E18C380X10 | 4226N (950 lb _f) | 18V | 7.7 | 3.5 |
| E18T400 | 4226N (950 lb _f) | 18V | 7.5 | 3.4 |
| E18T400X4 | 4226N (950 lb _f) | 18V | 7.5 | 3.4 |
| E18T400X10 | 4226N (950 lb _f) | 18V | 7.5 | 3.4 |
| E18T585 | 4226N (950 lb _f) | 18V | 7.9 | 3.6 |
| E18T600 | 4226N (950 lb _f) | 18V | 8.5 | 3.8 |
| E18T600X2 | 4226N (950 lb _f) | 18V | 8.5 | 3.8 |
| E18T600X2L | 4226N (950 lb _f) | 18V | 10.3 | 4.7 |
| E18T600XL | 4226N (950 lb _f) | 18V | 10.3 | 4.7 |
| E18T825 | 4226N (950 lb _f) | 18V | 9.1 | 4.1 |
| E18T900 | 4226N (950 lb _f) | 18V | 9.1 | 4.1 |
| E18T1500 | 4226N (950 lb _f) | 18V | 10.1 | 4.6 |
| E18T1500X | 4226N (950 lb _f) | 18V | 11.0 | 5.0 |
| E18T1500XL | 4226N (950 lb _f) | 18V | 12.9 | 5.8 |

Noise/vibration information

Measured values determined according to EN 60745.

Typically, the A-weighted noise levels of the tool are:

Sound pressure level (Uncertainty K=3dB(A)).....68 dB (A)

Sound power level (Uncertainty K=3dB(A)).....79 dB (A)

Total vibration values (vector sum in the three axes) determined according to EN 60745.

Vibration emission value a_h < 2.5 m/s²

Uncertainty K= 1.5 m/s²

⚠ WARNING!

The vibration emission level given in this information sheet has been measured in accordance with a standardized test given in EN 60745 and may be used to compare one tool with another. It may be used for a preliminary assessment of exposure.

The declared vibration emission level represents the main applications of the tool. However if the tool is used for different applications, with different accessories or poorly maintained, the vibration emission may differ. This may significantly increase the exposure level over the total working period.

An estimation of the level of exposure to vibration should also take into account the times when the tool is switched off or when it is running but not actually doing the job. This may significantly reduce the exposure level over the total working period.

Identify additional safety measures to protect the operator from the effects of vibration such as: maintain the tool and the accessories, keep the hands warm, organization of work patterns.

⚠ WARNING! Read all safety warnings and all instructions, including those given in the accompanying brochure. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury. **Save all warnings and instructions for future reference.**

SAFETY INSTRUCTIONS

Read and understand the charger operator's manual packaged with your charger.

Always wear goggles when using the machine.

Remove the battery pack before starting any work on the machine.

Do not dispose of used battery packs in the household refuse or by burning them. Milwaukee Distributors offer to retrieve old batteries to protect our environment.

Do not store the battery pack together with metal objects (short circuit risk).

Use only System C18 chargers for charging System C18 battery packs. Do not use battery packs from other systems.

Never break open battery packs and chargers and store Only in dry rooms. Keep dry at all times.

To reduce the risk of injury, electric shock, and damage to the tool, never immerse your tool in liquid or allow a liquid to flow inside the tool.

Battery acid may leak from damaged batteries under extreme load or extreme temperatures. In case of contact with battery acid wash it off immediately with soap and water. In case of eye contact rinse thoroughly for at least 10 minutes and immediately seek medical attention.

WARNING! To reduce the risk of fire, personal injury, and product damage due to a short circuit, never immerse your tool, battery pack or charger in fluid or allow a fluid to flow inside them. Corrosive or conductive fluids, such as seawater, certain industrial chemicals, and bleach or bleach containing products, etc., Can cause a short circuit.

SPECIFIED CONDITIONS OF USE

The caulking gun is intended to apply tube or sausage pack caulks and adhesives to surfaces. In case of doubt, please read the caulk or adhesive manufacturers' instructions.

Do not use this product in any other way as stated for normal use.

BATTERIES

New battery packs reach full loading capacity after 4-5 chargings and dischargings. Battery packs which have not been used for some time should be recharged before use.

Temperatures in excess of 50°C (122°F) reduce the performance of the battery pack. Avoid extended exposure to heat or sunshine (risk of overheating).

The contacts of chargers and battery packs must be kept clean.

For an optimum life-time, the battery packs have to be fully charged, after used.

To obtain the longest possible battery life remove the battery pack from the charger once it is fully charged.

For battery pack storage longer than 30 days:

Store the battery pack where the temperature is below 27°C and away from moisture.

Store the battery packs in a 30% - 50% charged condition.

Every six months of storage, charge the pack as normal.

BATTERY PACK PROTECTION LI-ION BATTERY

The battery pack has overload protection that protects it from being overloaded and helps to ensure long life. Under extreme stress the battery electronics switch off the machine automatically. To restart, switch the machine off and then on again. If the machine does not start up again, the battery pack may have discharged completely. In this case it must be recharged in the battery charger.

ADVICE FOR OPERATION

Anti-Drip and Rod Release

The caulk gun features an automatic anti-drip to prevent drips after the trigger is released. When the trigger is released, the motor will run for a short time to release the rod.

When a tube is emptied, the motor will run for a short time to release the rod, then shut off. Release the trigger and change the tube.

Overload

When an overload occurs, the tool will reach the maximum drive force and continue to hold this maximum force until the user releases the trigger. If material is not dispensing, make sure that:

- Nozzle tip is cut
- Inner seal in the caulk tube is broken
- Hardened material is removed from the nozzle
- Caulk tube is not damaged or frozen
- Rod is free of caulk/adhesive materials

MAINTENANCE

CAUTION! Carriage and rod must remain clean and free of caulk and adhesive materials. Clean off materials according to caulk/adhesive manufacturer's recommendations.

Use only Albion accessories and spare parts. Should components need to be exchanged which have not been described, please contact Albion Engineering.

Please Contact one of our Albion engineering service agents directly for model specific components.

For Albion Specific tools contact: Albion Engineering Company
1250 N Church Street
Moorestown, NJ 08057-1102 USA
www.albioneng.com

EC-DECLARATION OF CONFORMITY

Albion Engineering Company declares that the product(s) described under "Technical Data" fulfills all the relevant regulations and the directives 2011/65/EU (RoHS), 2014/30/ EU, 2006/42/EC, and the following harmonized standards have been used:

EN 60745-1:2009 + A11:2010
EN 55014-1:2006 + A1:2009 + A2:2011
EN 55014-2:2015
EN 50581:2012
3-29-2019

Joseph B. Hanni

Joseph B. Hanni
Engineering Director

Albion Engineering Company
1250 N Church Street
Moorestown, NJ 08057-1102 USA
www.albioneng.com

SYMBOLS



CAUTION! WARNING! DANGER!



Always disconnect the plug from the socket before carrying out any work on the machine.



Please read the instructions carefully before starting the machine.



Always wear goggles when using the machine.



Do not dispose electric tools, batteries/ rechargeable batteries together with household waste material.

Electric tools and batteries that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility.

Check with your local authority or retailer for recycling advice and collection point.



European Conformity Mark



National mark of conformity Ukraine



EurAsian Conformity Mark.

Copyright 2019

ALBION ENGINEERING COMPANY

1250 North Church Street | Moorestown, NJ, U.S.A. 08057-1102

(856) 235-6688 | service@albioneng.com | www.albioneng.com