

SERVICE SCHEDULE

Maintenance Intervals

Maintenance work must be done at regular intervals. Failure to do so will result in excessive wear and early failures.

The service schedule is a guide for correct maintenance of the Bobcat telescopic handler.

During service, record:

- The machine operating hours.
- Maintenance procedures that are performed.

WARNING

AVOID INJURY OR DEATH

Instructions are necessary before operating or servicing machine. Read and understand the **Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.**

W-2003-0807

Every 10 Hours (Before Starting The Telescopic Handler)

- **Engine Oil** - Check level and add as needed. Do not overfill. Check engine for oil leaks. (See page 166.)
- **Engine Air Filters and Air System** - Service only when required. Check for leaks and damaged components. (See page 159.)
- **Engine Cooling System** - Check oil cooler, radiator and air conditioner condenser. Check coolant level cold in reservoir. Add premixed coolant as necessary. (See page 169.) Check cooling system for leaks.
- **Exhaust System** - Check exhaust system and exhaust aftertreatment components for leaks.
- **Hydraulic Fluid** - Check fluid level and add as needed. (See page 178.)
- **Fuel Filter** - Check display panel. Remove the trapped water. (See page 163.)
- **Seat Belt** - Check the condition of seat belt. Clean or replace seat belt retractors as needed. Clean dirt and debris from moving parts. (See page 94.) and (See page 152.)
- **Back-up Alarm** - Check for proper function. Service as necessary. (See page 72 and page 156.)
- **Service Brakes** - Check for function. Service as necessary.
- **Parking Brakes** - Check for function. Adjust or service as necessary.
- **Tyres** - Check for wear or damage. Inflate to correct pressure. Be sure all tyres are inflated to the same pressure. Use only approved tyres. (See page 190.)
- **Wheel Nuts** - Perform every 8 hours or daily for the first week, then as scheduled. Check for loose wheel nuts and tighten to correct torque. (See page 190.)
- **Safety Signs and Safety Treads and Mirrors** - Check for damaged signs (decals), safety treads and mirrors. Replace any signs, safety treads or mirrors that are damaged or worn. (See page 30.)
- **Tilt Cylinder Rod End** - Lubricate with multipurpose lithium based grease. (See page 192.)
- **Attachment Carrier Pins** - Lubricate with multipurpose lithium based grease. (See page 192.)

Every 50 Hours

- **Fuel Filter** - Replace filter element the first time, then as scheduled. (See page 163.)
- **Engine Cooling System** - Clean debris from radiator, air cooler, hydraulic fluid cooler, air conditioning condenser (if equipped), and grille. (See page 169.)
- **Engine Oil and Filter** - Replace oil and filter the first time, then as scheduled. (See page 167.)
- **Hydraulic / Hydrostatic Fluid Filter** - Replace the filter element the first time, then as scheduled. Use a genuine Bobcat filter. (See page 180.)
- **Air Conditioning Belt (if equipped)** - Check condition. Replace as needed. (See page 188.)
- **Articulation Pins, Axle Oscillation (Front / Rear), Boom Pivot, Lift Cylinder, Self Levelling Cylinder** - Lubricate with multipurpose lithium based grease. (See page 192.)
- **Telescopic Boom Wear Pads** - Lubricate with multipurpose lithium based grease. (See page 192.)
- **Hydraulic Hoses, Tubelines and Connections** - Check for leaks. Repair or replace as needed.
- **Harnesses** - Check condition. Repair or replace as needed.

SERVICE SCHEDULE (CONT'D)

Maintenance Intervals (Cont'd)

Every 100 Hours

- **LLMC System** - Test the LLMC calibration the first time, then as scheduled. (See page 153.)
- **Wheel Nuts** - Check for loose wheel nuts and tighten to correct torque. (See page 190.)
- **Planetary Carriers** - Replace the fluid the first time, then as scheduled. (See page 182.)
- **Axle and Differential Fluid** - Replace the fluid the first time, then as scheduled. (See page 183 and page 184.)
- **Reduction Box Fluid** - Replace the fluid the first time, then as scheduled. (See page 185.)

Every 250 Hours Or Every 12 Months

- **LLMC System** - Test the LLMC calibration (See page 153.)
- **Planetary Carriers** - Check level. (See page 182.)
- **Axle and Differential Fluid** - Check level. (See page 183 and page 184.)
- **Reduction Box Fluid** - Check level. (See page 185.)
- **Alternator Belt** - Check belt tension. (See page 186.)

Every 500 Hours Or Every 12 Months

- **Engine Air Filters and Air System** - Service only when required. Check for leaks and damaged components. (See page 159.)
- **Fuel Filter** - Replace fuel filter element. (See page 163.)
- **Engine Oil and Filter** - Replace oil and filter. (See page 167.)
- **Engine Cooling System** - Check coolant concentration (with a refractometer). Replace as needed. (See page 169.)
- **Air Conditioning Belt (if equipped)** - Check condition. Replace as needed. (See page 188.)
- **Hydraulic / Hydrostatic Fluid Filter** - Replace the filter element. Use a genuine Bobcat filter. (See page 180.)
- **Hydraulic Tank Breather** - Replace the hydraulic tank breather. (See page 181.)
- **Axle and Differential Fluid** - Replace the fluid. (See page 183 and page 184.) Maximal service time is 800 hours.
- **Reduction Box Fluid** - Replace the fluid. (See page 185.) Maximal service time is 800 hours.
- **Telescopic Boom Wear Pads** - Check for wear. Replace as necessary.
- **Service Brake Pedal Spring** - Lubricate with multipurpose lithium based grease. (See page 192.)
- **Cab Air Filter** - Check filter condition. Check for damage. Clean or replace as necessary. (See page 157.)
- **A/C System Water Condensate Rubber Valves** - Clean the rubber valves. (See page 157.)

Every 750 Hours Or Every 12 Months

- **Planetary Carriers** - Replace the fluid. (See page 182.)
- **Axle and Differential Fluid** - Replace the fluid. (See page 183 and page 184.)
- **Reduction Box Fluid** - Replace the fluid. (See page 185.)

Every 1000 Hours Or Every 12 Months

- **Battery and Cable Connectors** - Check voltage. Check terminals for good contact and presence of protective grease. (See page 174.)
- **Engine Mounts** - Tighten. Replace if damaged.
- **Engine Air Filter** - Service only when required. Check for leaks and damaged components. (See page 159.)
- **Charge Air Cooler** - Check entry area.
- **Alternator Belt** - Check condition. Replace as needed. (See page 187.)
- **Air Conditioning Belt (if equipped)** - Check condition. Replace as needed. (See page 188.)
- **Hydraulic Fluid** - Replace the fluid. (See page 179.)
- **Fastenings, Hose Unions and Clips** - Replace if damaged.
- **Engine Valve Clearance** - Check and adjust.

Every 3000 Hours

- **Alternator Belt** - Replace the belt. (See page 187.)
- **Diesel Exhaust Fluid (DEF) / AdBlue® Filter (if equipped)** - Replace the diesel exhaust fluid (DEF) / AdBlue® filter. (See page 161.)

SERVICE SCHEDULE (CONT'D)

Maintenance Intervals (Cont'd)

Every 24 Months

- **Coolant** - Replace the coolant. (See page 170.)

Inspection Checkbook

Maintenance work must be done at regular intervals. Failure to do so will result in excessive wear and early failures.

The service schedule is a guide for correct maintenance of the Bobcat telescopic handler.

The Inspection Checkbook contains the following information:

- Doosan Bobcat EMEA s.r.o. Warranty Policy
- Doosan Bobcat EMEA s.r.o. Extended Warranty Policy

The Inspection Checkbook has to be filled in by the Dealer for any maintenance and service work of your Bobcat machine. This book may be required anytime by an authorized dealer or by Bobcat Europe, should a breakdown occur on the Bobcat equipment. Your local dealer can order the Inspection Checkbook.

Part number: 7296478