


**SONNET CHARGING STATION  
AM/FM .9" LED CLOCK RADIO  
WITH AUX IN AMPLIFICATION AND  
2 USB PORTS AND 2 110 VOLT OUTPUTS**

**MODEL NO. R-1414**



**FUNCTION KEYS**

- |                             |                          |
|-----------------------------|--------------------------|
| 1. Radio Tuning Knob        | 10. Battery Compartment  |
| 2. Aux/AM/FM Selector       | 11. 110 v Output Socket  |
| 3. Red LED Display          | 12. USB Charging         |
| 4. Volume/Buzzer Controller | 13. Alarm Set/Off Button |
| 5. Snooze Button            | 14. Sleep Button         |
| 6. Minute Set Button        | 15. Alarm On Indicator   |
| 7. Hour Set Button          | 16. Speaker              |
| 8. Time Set Button          | 17. On/Off/Auto Button   |
| 9. Aux Cable                |                          |

**OPERATING INSTRUCTIONS**

1. Connect the AC plug to wall outlet.
2. Press the TIME SET button and simultaneously hold the HOUR and MINUTE buttons to set the current time.
3. Press the ALARM SET button and simultaneously hold the HOUR and MINUTE buttons to set the desired alarm time. Slide the ON/OFF/AUTO switch to AUTO and a glowing dot will appear on the lower left corner of the display indicating that the alarm is set and on.
4. Slide the ON/OFF/AUTO switch to turn radio ON, OFF or AUTO position. When the switch is on the AUTO position the alarm will be on. To wake to radio, set the alarm time as described above, turn the radio on to the desired station and volume. Slide the ON/OFF/AUTO switch to AUTO and the radio will turn on automatically at the selected alarm time.
5. Press the SLEEP SET button to display the number of minutes which the radio will be on before automatically turning off. The maximum number of minutes is 1 hour and 59 minutes for sleep set. If you wish to increase or decrease the sleep time, press the SLEEP SET button and simultaneously hold the HOUR or MINUTE button to set the desired duration. To turn the radio off before the sleep expiration, press the SNOOZE button.
6. Slide the AUX/AM/FM selector to AUX for aux in amplification or AM/FM for radio as desired. To amplify the sound from your MP3 player, iPod, iPhone or other portable device, plug the aux cable into the earphone jack of your device. Slide the AUX/AM/FM selector to the AUX position.
7. Use the VOLUME/BUZZER controller to adjust the desired volume level while playing radio or using the aux amplification. When the controller is off, the alarm preset will wake to buzzer.
8. Use the TUNING knob to set the desired AM or FM radio station.
9. Use the SNOOZE button for extra naps. The SNOOZE button will shut off the buzzer or radio from the alarm for approximately 5 to 10 minutes before the music or buzzer will sound again. This can repeated several times.
10. The clock has a battery backup feature in case of power failure. A 9 volt battery (not included) is required. You must put in a battery to ensure the backup feature is ready in case of power failure. If power fails, the backup battery will automatically continue operation of the clock and maintain actual time and alarm setting. The display will not be lit but when the power is restored, the display will show the correct time. The battery will maintain timekeeping for approximately 8 hours during power failure or interruption.