

## SPECS

- Dimension: L47.5mmxW16.9mm
- Weight: 65g
- Battery: Rechargeable, 3.7V, 580mAh
- Charging voltage: 5V DC
- Waterproof: IPX8
- 4 locating technologies: GPS, BLE, Wi-Fi, LBS

### TIP

GPS functionality may be unavailable or inaccurate in some locations (for example, availability or accuracy of GPS location may be impacted inside buildings, near tall buildings or tall features or underground).

- The watch also provides Wi-Fi, LBS positioning, when GPS is unavailable, it will switch to Wi-Fi and LBS for locating.
- The home Wi-Fi and beacons provide at home out of home information in addition to optimising watch battery life
- Please note Wi-Fi and LBS tracking service is not 100% accurate, it can be used to approximate your location only


### TIP

Please comply with the instructions to extend device life:


- Do not use and store the watch in dusty, hot, cold, electric or chemical areas. Please always keep the watch and accessories dry.
- Do not drop, shake or knock the watch. Rough handling can break it.
- Clean the watch with a dry cloth. Do not clean with chemicals or detergent.
- Do not disassemble or refit the watch as it will void your warranty
- Using other batteries will cause unwanted situations.
- To avoid accident, never play the watch while driving.
- Please turn off the watch in aircrafts and follow any restrictions. Wireless devices can cause interference in aircrafts.

# GPS LOCATEME WATCH

## USER GUIDE



## SWITCHING ON/OFF



- 1 To turn the device ON: Press the side button for 1 second.



- 2 To turn the device OFF: Scroll right to "Settings". Scroll down to select "System" and then tap "Power Off".


## BASIC FUNCTIONS

When the watch is turned on, slide leftwards or rightwards to view all available functions, it displays Watch Face, Weather, Heart Rate, Contact, Steps and Settings.



- 1 At watch face, you can see time, date, heart rate and steps.
- 2 There are two watch faces for your option. Sliding right to the end and click settings, select watch face and choose what you like by sliding left and right.

## CHARGING YOUR WATCH



- Connect the USB cable from charging base to the AC adaptor
- Place the watch into the charging base correctly, you will hear spoken confirmation "Your watch is charging".
- Please fully charge the battery daily for around two hours or when battery is low

## ACTIVATING SOS ALARM

There are two ways to activate the SOS alarm.



- 1 Pressing the side button for 3 seconds until you feel the watch vibrate




- 2 When the screen is on, long press the screen for 3 seconds until you feel the watch vibrate

- After an SOS alarm is activated, you will hear a voice prompt confirming the activation and allowing you approximately ten seconds to cancel the alarm. If the SOS is not cancelled in time an SOS alert is immediately sent through to our Monitoring Centre
- An operator will speak to you via two-way voice communication and confirm your location. You can speak to the operator through the watch microphone.

## FALL DETECTION

The watch can automatically detect a fall. When this occurs the watch will give a warning message to the user.



- Some daily activities like sports or even sitting down abruptly can trigger the fall alarm.
- The wearer has a short time to cancel a fall alarm by clicking the Cancel on the watch. If the alarm is not cancelled, an alert will be sent through to our Monitoring Centre.

## HEART RATE MEASUREMENTS



- Wear the watch on the left hand and click heart rate, after several seconds checking, the screen will display your heart rate BPM.