

# Master Your Comfort: Adjusting the Y2 Advanced Syncro-Tilt Control

Chair Model: Ignition® 2.0



## Left Side - When Sitting:

**Tilt Lock Knob:** Twist the knob forward to lock the chair back in position, and backward to unlock the recline. The Y2 control allows the back to be locked in multiple positions.



**Seat Depth Lever:** While lifting the lever, slide the seat forward or backward to align with your leg length.



## Right Side - When Sitting:

**Tilt Tension Knob:** Twist the knob forward to increase resistance when reclining, and backward to decrease resistance.




**Seat Height Lever:** Lift the lever to raise or lower the seat. This helps align your hips, knees, and elbows for ergonomic posture at your desk.



# Your Chair, Your Way: Adjusting the Y1 Syncro-Tilt with Seat Slider Control

Chair Model: Ignition® 2.0



## Left Side - When Sitting:

**Seat Depth Lever:** While lifting the lever, slide the seat forward or backward to align with your leg length.



## Right Side - When Sitting:

**Tilt Lock Lever:** Pull the lever out to unlock the recline of the chair back. Push the lever in to lock in the upright position.



**Seat Height Lever:** Lift the lever to raise or lower the seat. This helps align your hips, knees, and elbows for ergonomic posture at your desk.



**Tilt Tension Knob:** When sitting, turn the knob underneath your seat to adjust how much resistance you feel when reclining.




**Clockwise:** Loosens tension

**Counterclockwise:** Tightens tension

# Effortless Ergonomics: Adjusting the Y0 Synchro-Tilt Control

Chair Model: Ignition® 2.0




## Right Side - When Sitting:

**Tilt Lock Lever:** Pull the lever out to unlock the recline of the chair back. Push the lever in to lock in the upright position.



**Seat Height Lever:** Lift the lever to raise or lower the seat. This helps align your hips, knees, and elbows for ergonomic posture at your desk.



**Tilt Tension Knob:** When sitting, turn the knob underneath your seat to adjust how much resistance you feel when reclining.




**Clockwise:** Loosens tension

**Counterclockwise:** Tightens tension

# The Perfect Sit: Adjusting the W2 Weight-Activated with Seat Slider Control

Chair Model: Ignition® 2.0





## Right Side - When Sitting:

**Tilt Lock Lever:** Pull the lever out to unlock the recline of the chair back. Push the lever in to lock in the upright position.



**Seat Height Lever:** Lift the lever to raise or lower the seat. This helps align your hips, knees, and elbows for ergonomic posture at your desk.



## Left Side - When Sitting:

**Seat Depth Lever:** While lifting the lever, slide the seat forward or backward to align with your leg length.



**Tilt Tension:** Automatically adjusts to you as you recline.


# Keeping it Simple: Adjusting the W0 Weight-Activated Control

Chair Model: Cofi™




## Right Side - When Sitting:

**Tilt Lock Lever:** Pull the lever out to unlock the recline of the chair back. Push the lever in to lock in the upright position.



**Seat Height Lever:** Lift the lever to raise or lower the seat. This helps align your hips, knees, and elbows for ergonomic posture at your desk.



**Tilt Tension:** Automatically adjusts to you as you recline.