


KYOTA[®]

The World's Most
Advanced Massage Chairs[®]




User Manual

**Nokori M980
Massage Chair**



Your Chair

External Structure



Welcome to

KYOTA[®]

Thank you, and congratulations on purchasing your very own Kyota Massage Chair product - you've made a great buying decision. Welcome to the Kyota family.

Please review the entire manual, including all safety information, before assembling or using your chair. If you are assembling the chair yourself, please see the Assembly Guide next and reference the online assembly video.

For convenience, we've also created a Quick Start Guide. Use it as a tool to get to know all the features of your new chair.

Sit back, relax, and enjoy your new Kyota massage chair!

Warranty Registration

Register your product at www.kyotamassagechairs.com/warranty/registration to ensure it is in our system. This will simplify the warranty process should you ever need it.

Alternatively, **scan the QR code** to go directly to the URL above.



SCAN CODE

Assembly Video

Before assembling your chair, watch an assembly video at: www.kyotamassagechairs.com/assembly-tutorials

Alternatively, **scan the QR code** to go directly to the URL above.



SCAN CODE

Chair Features

Syner-D® Back Massage Mechanism
Flex-D Massage Track
Tablet Remote
Intelligent Voice Command + Control
Complete Calf™ Kneading + Oscillation
Wireless Charging Pad
USB Charging Station
Weightless Zero Gravity Recline
Chromatherapy Programs
Premium Bluetooth Speakers
SootheMe™ Sound Therapy
Quick Access Control Panel
Zero Wall Fit™ Space-saving Technology
Total Sole Foot Reflexology Rollers
MyMassage™ Memory Programs
Lumbar Heat
Truefit™ Body Scanning
TrueFit™ Footrest Extension
Air Ionizer
Airbag Compression Therapy

Table of Contents

Preparation

Installation Site	6
Clearance Space for the Chair	6
Floor Protection	6
Move Methods	7
Connect to Power	7

Chair Setup

Main Power Switch	8
Adjust Pillow	8
Increase the Intensity of your Massage - Manually	8
Truefit™ Body Scanning	8
Getting out of the Chair	9
Chair Entry and Exit Hazards	9
Tablet Remote Layout	10
Tablet Remote Operation	11

Getting Started

Auto Programs	12
Truefit™ Body Scanning	12
In-Use Screen	12
Auto Program Descriptions	13

Personalize Experience

Custom Selections from Auto Programs	14
Focus Zone	14
Syner-D® Technology	14
Maximum 4D Level	15
Calf Rollers & Oscillation	15
Time Remaining	15
Air Settings	15
Max Air Intensity	15
Total Sole Foot Reflexology Rollers	15
Back Heat	15
Adjustments	16
LED Themes	16
LED Lights	16
LED Brightness	17
Calf Rollers & Oscillation	17
Back/ Foot/ Leg Extension	17
Zero Gravity Recline	17

Time Remaining	17
SootheMe™ Sound Therapy	18
Volume Level	18
Quick Access Panel + Joystick Control	19
Intelligent Voice Command + Control	20
Turn Off Listening	20
Turn On Listening	20
Activating Voice Control	20
MyMassage™ Memory Programs	21
Saving a Memory Program	21
Running a Memory Program	21
Wireless Charging Pad + USB Charging Station	21

Settings

Sleep Mode	22
Voice Demo	22
Air Ionizer	22
Bluetooth	23
USB Charging	23
Voice Control	23
Display Brightness	23
Language	23
Firmware Version	23
Help	23

Create a Massage

Manual Settings	24
Massage Technique	24
Focus Zone	25
Massage Width	25
Maximum 4D Level	25
Massage Speed	25
Air Settings	25
Max Air Intensity	25
Total Sole Foot Reflexology Rollers	25
Back Heat	25

Staying Safe

Fixing Issues


Troubleshooting	29
Specifications	29
Frequently Asked Questions	30

Preparation

Installation Site

Clearance Space for the Chair

- 4" clearance for the recline of the backrest; 24" clearance for the extension of footrest and sliding forward of the chair.
- Keep it 3 feet away from the TV, radio or other audio & video appliance to avoid signal interference.




- Keep the distance between the power socket and power switch within 60" to avoid damage of power cord while massage chair sliding forward.
- Straighten the power cord while in use to avoid tangle or damage.



- To avoid serious injury or death, before sliding chair forward or backward check to make sure area is clear of children, pets, or obstacles.

Floor Protection


We recommend to place a piece of thin carpet or soft mat underneath it to avoid damaging the floor.



- Do not use the massage chair in high moisture environment such as near a swimming pool or bathroom to prevent electric shock accident.
- Please keep the massage chair away from heated surfaces to prevent fire hazard or damage to the product.

Move Methods

Apply pressure to the back of the massage chair from behind to pivot on the Castors. Have a second person up front to guide the Footrest until in the correct position. Maintain clearances as mentioned above. Gently lower into place. Do not pull on the side arms.



- Do not move the chair when there is user inside.
- Chair is heavy. Use caution and get assistance when lifting to avoid injury. Do NOT lift chair by footrest or armrests to avoid damage to product.

Connect to Power

Plug into a 110V grounded outlet.



WARNING

Grounding Instructions


To avoid risk of electrical shock, turn power switch off before plugging unit into electrical outlet. Use only with properly grounded outlet (3 prong). Do not plug into ungrounded outlet.

WARNING – Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product – if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This product is for use on a nominal 120-V circuit and has a grounding plug that looks like the plug illustrated. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.

Earthing

This massage chair is a Class 1 electrical appliance. Make sure to use a grounded outlet to the grounded power supply circuit and a properly installed earth grounding rod with ground connection, to avoid electric shock.




Chair Setup

Getting Comfortable

Main Power Switch


To power up the chair, flip the main power switch located on the back of the base of the chair to ON. Ensure the electrical cord is connected to a 110V grounded outlet and plugged into the power cord port located on the back of the base of the chair.



- To avoid possible damage to product or injury to unsupervised children, always turn off power switch and unplug massage chair from electrical outlet immediately after use.
- When not in use for a long period of time, we recommend that the chair be covered, the power cord be coiled and that the unit be placed in an environment free of dust and moisture.

Adjust Pillow

Take a seat in the chair and take note of where the neck pillow rests on your neck. Adjust the pillow so that it rests comfortably in the arch of your neck, flip it up out of the way, or use the zipper to remove it all together.



Increase the Intensity of your Massage - Manually


To make the massage more intense, you can **remove the pillow pad or the pillow pad and the pillow** to remove cushioning between you and the massage mechanism in the seat back.

Truefit™ Body Scanning

Select any auto program. The chair will automatically begin scanning your body, mapping your back, shoulders, and neck. During this process it is important to remain seated back into the chair without lifting your head.

The scan can be viewed on the Tablet Remote screen. If fine tuning is needed just after your body scan, wait for the **shoulder adjust prompt** to appear and then use the **Back Adjustment** buttons to move the massage rollers up or down for the perfect shoulder kneading position.

Truefit™ Body Scanning



Getting Out of The Chair


To easily exit the chair at any time, tap the **POWER** button on the top right of the home display, on the Tablet Remote to restore the chair to the upright position. Alternatively, you can also press and hold the joystick power button, found on the right arm panel next to the Quick Access Control Panel, until the chair starts resetting.




WARNING! Check to make sure children and pets are clear of chair **before** tapping power button to return chair to upright position.

Chair Entry and Exit Hazards


WARNING! The areas under the footrest and behind the back rest are potentially dangerous for a child or pet. The chair back is heavy and reclines with force. A small child or pet located behind the chair could be crushed as chair is reclined resulting in serious injury or death. When chair is reclined, small children or pets who have crawled under the leg rest may not be visible to the user and could be crushed when leg rest is lowered or when chair is returned to upright position. **To avoid serious injury or death, check these areas carefully before reclining, lowering leg rest, or returning chair to upright position.**



Make sure to check for children or pets **between the chair back and the base of the chair** before entering zero gravity recline.




Make sure to check for children or pets **underneath the footwell** before exiting zero gravity recline and returning to upright position.



Make sure to check for children or pets **between the footrest and the chair body** before lowering the legrest.

Chair Setup

Tablet Remote Layout



Tablet Remote Operation

1. Home Page – After turning on your chair, this is the first screen you will see on your Tablet Remote. Use this screen to navigate all menu options. To select, simply tap the screen with your finger.

2. Auto Programs – Select from 12 pre-set auto programs. To select simply tap the auto program you wish to run.

3. MyMassage™ Memory – After creating your massage program you have the ability to save to memory and then access whenever you want.

4. Adjustments – While your massage program is running, use this screen to make adjustments to time, lighting, the chromotherapy programs or chair angles.

Note: You may only choose colors in Solid and Breathe themes. You may only choose brightness in Solid and Multi Rotate themes.

5. Sound – Use this screen to select and control the SootheMe™ Sound Therapy feature of your chair. The selected sound will play from the Intersound™ speakers. To turn SootheMe™ nature sounds off, de-select the activated sound.

6. Manual Settings – Have a particular spot that needs more work? Take the power of massage into your own hands with Manual Settings. Use this screen to fully customize your own massage and find the perfect treatment for you. If you slide on the control panel lock, this screen will not revert back to the In-Use screen so you can make continuous adjustments.

7. System Settings – Use this screen to adjust and personalize your chair and Tablet Remote settings.

Getting Started

Auto Programs

From the home display, tap the **AUTO** button to enter Auto Program Menu. Choose from **Flex, Stretch, Gentle, Deep Breathe, Energize, Rest & Recover, Upper Body, Neck & Spine, Lower Body, Tension Release, Full Body or Demo**. To enter the program you desire tap the screen. Selected program will show on the In-use screen.




Truefit™ Body Scanning

After a Massage program is selected, you will be taken to the Body Scanning screen. Here you can use the arrows to adjust the back mechanism up and down to match your specific shoulder height. After the countdown timer has elapsed, your massage will start.



In-Use Screen

After adjusting your shoulder height, you will be taken to the In-use screen where you can observe all current settings and session information.



- Do not spill liquids on Tablet Remote and avoid placing heavy objects on Tablet Remote or power cord to avoid damage or malfunction.

Program	What For?	Description
Flex	Soothe muscles after sports	Targeted airbag compression provides a full body stretch while the double back-mechanism performs a combination of massage techniques to help awaken and ignite your muscles for the day ahead.
Stretch	Great for a quick midday break to relieve any built up morning stress.	A revitalising massage that is ideal for a mid-day boost. Full body kneading relieves built up stress, reduces fatigue, and improves metabolism so you can finish your day off strong.
Gentle	Reduce built up tension carried in the body or unwinding after a stressful day.	Designed to clear the mind and increase blood circulation. Breath in deeply and exhale your stress while this rhythmic massage program works to alleviate your tired muscles and reinvigorate your spirit.
Deep Breathe	Best for those who prefer a more intense massage, and for soothing muscles after physical activity	Performs a strong massage with deep, penetrating massage techniques to alleviate your aches and pains, improve circulation, and recuperate the body after intense physical activity.
Energize	Try this program as you prepare your body to rest for the night.	A progression of mild massage techniques and chair movements brings harmony to your body. This program helps you unwind from a long day, and prepares you for a restful night's sleep.
Rest & Recover	Those looking for a softer, less intense massage.	As the lowest intensity massage, this series of massage techniques is perfect for those who are more sensitive, or looking for a light kneading motion on the back, waist and hips.
Upper Body	Soothing pain and tension in the neck and shoulders.	A powerful combination of kneading, grabbing, and pressing massage techniques target the neck, shoulder, and upper back to help ease unwanted pain and stiffness.
Neck and Spine	Helps to relax, recover, and revitalize the main back muscles along your spine.	Designed to be an incredible injury prevention program, this massage focusses on the lumbar vertebra with targeted massage to loosen rigid muscles, relieve tension, improve circulation, and revitalize your energy levels.
Lower Body	Improve hip mobility and reduce lower back pain.	Designed to stimulate the waist, hips and buttock, this sequence of massage and air bag compression can help to improve your range of motion, and reduce lower back pain so you can return to your feet feeling renewed.
Tension Release	This program is the best choice to re-invigorate stiff muscles and boost energy levels.	Inspired by traditional Thai massage techniques, this strong series of grab, hold and stretch progressions gently extends the body to help re-adjust the skeletal structure, increase flexibility, and re-balance your body's energy
Full Body	This program is the best choice to re-energize tired muscles and reset your mind.	This program is designed to relax the body both physically and emotionally. A unique combination of varying intensities brings the mind into a peaceful state, while specific massage techniques increase circulation to help relieve muscular tension, and reduce recovery time
Demo	A quick way to feel all the massage techniques and chair movements in a brief 8 minute session.	A quick show of massage chair's features and functions that can be accompanied by an explanatory voice over. To turn off voice over, toggle the volume to off in Sounds menu.


Personalize Experience

Custom Selections from Auto Programs


To personalize your massage to your exact needs, swipe left on the Tablet Remote from the In-Use Screen to be taken to the **Custom Selections** screen.

The **Custom Selections** screen can be used to tailor your massage exactly to your needs. Here you will have complete control over the duration, airbag settings/Intensity, foot rollers, and back/leg heat. To return to the In-use screen, simply swipe right or tap the arrow on the Tablet Remote screen, which will take you to the home page, and then tap *'massage running screen'* at the top center of your screen.

If you slide on the **Control Panel Lock** (top right corner of screen), this screen will not revert back to the In-Use screen so you can make continuous adjustments. Slide off to unlock again.



Swipe Right from In-Use Screen



Focus Zone

Controls the range of motion of the back mechanism, **Whole** travels the entire length of the track, **Partial** travels a short distance and reverses direction for focused relief, **Point** stops on the track for targeted relief. Tap screen to select setting.

Adjust: Partial and Point location can be fine tuned by using the Adjust Setting. Press and hold arrow up or arrow down buttons to control the location of the back mechanism.

Syner-D® Technology

Syner-D® tandem back mechanisms mimic the human hands of 2 professional massage therapists, in choreographed rhythm from your neck to your glutes. Utilizing 2D, 3D and 4D technologies in Harmony for the most advanced chair massage available today.

Maximum 4D Level

Use this control to increase or decrease the maximum intensity of the 4D back mechanism that works the back and shoulder regions. All auto massages are pre-programmed to have varying 4D intensity, this setting will set the upper limit of these fluctuations. **1 = light, 5 = firm, or Off.** Tap screen to select setting.

Calf Rollers & Oscillation

Toggles on/off Calf Rollers & Oscillation feature. Rollers combine with oscillating movement and compression air cells to simulate hands gently relieving tension and pain in the calf region of each leg. Tap screen to select setting.

Time Remaining

Tap screen to select your desired massage timer length; **10 minutes, 20 minutes, or 30 minutes.** 20 minutes is the default setting. The massage chair will turn off automatically and reset after the timer is up.

Air Settings

Choose your desired airbag region/s: **Full, Shoulders (+Arms), Back, Hips, or Legs (+Feet).** Tap screen to select setting. To turn a particular airbag region off, de-select the activated region. Selecting **Full** will over ride any selections and ALL airbags become active.

Max Air Intensity

Increase or decrease maximum intensity of airbag massage. All auto massages are pre-programmed to have varying levels of airbag intensity, this setting will set the upper limit of these fluctuations. **1 = light, 5 = firm, or Off.** Tap screen to select setting.

Foot Rollers

Control Total Sole Reflexology™ Rollers and choose your desired foot roller speed: **1 = slow, 2, 3 = fast, or Off** (deactivate foot rollers). Tap screen to select setting.

Back Heat


Activate back heat and choose your desired heat intensity level: **1 = low, 2, 3 = high, or Off** (deactivate back heat). Tap screen to select setting.

Personalize Experience

Adjustments

Tap Adjustments to enter the Adjustments display screen. While your massage program is running, use this screen to make adjustments to lighting, chair angles, or time.

To return to the In-use screen, simply swipe right or tap the arrow on the Tablet Remote screen, which will take you to the home page, and then tap '*massage running screen*' at the top center of your screen.



LED Themes

Your massage chair has pre-programmed chromotherapy themes which vary the functionality of the LED lights. Use this option to select your desired light theme: **Solid**, **Breathe**, **Wake Up**, **Wind Down**, **Multi-Wave**, or **Multi-Rotate**. Tap screen to select desired theme. To turn lights off select '*Light Off*'.

Solid: Single color light.

Breathe: Single color that dims and brightens on a loop.

Wake Up: Blue enriched lights - gradually increasing brightness.

Wind Down: Colors of sunset - gradually decreasing brightness.

Multi-wave: All the colors of the rainbow morphing into each other.

Multi-rotate: Colors rotate from one to another.

LED Lights

Your massage chair has chromotherapy lights located underneath the speaker and on the outside of the chair body. Tap screen to select desired light color; **Red**, **Orange**, **Yellow**, **Lime**, **Green**, **Blue**, **Purple**, or **White**. To turn lights off de-select the activated light theme or select off.

LED Brightness

Select your desired light brightness: **1 = dim, 2, 3, 4, 5 = bright**. Tap screen to select desired brightness setting.

Note: You may only choose light color in solid and multi-rotate themes.

Calf Rollers & Oscillation

Toggles on/off Calf Rollers & Oscillation feature. Rollers combine with oscillating movement and compression air cells to simulate hands gently relieving tension and pain in the calf region of each leg. Tap screen to select setting.

Back/ Foot/ Leg Extension

These controls enable you to fine tune the length and fit of specific parts of your chair. Tap + hold screen to adjust settings.

Back – controls the recline angle of the seat back.

Foot – controls the angle of the footrest.

Leg Extension – allows the chair to customize to your leg length.

Zero Gravity Recline

Use this control to enter Weightless Zero Gravity Recline. Zero Gravity elevates your feet up over your heart to improve overall circulation and reduces gravitational force on your spine for a sense of weightlessness. Zero Gravity position 1 will put the chair into a standard recline, Zero Gravity position 2 will recline the chair into complete Weightless Zero Gravity Recline


Time Remaining

Tap screen to select your desired massage timer length; **10 minutes, 20 minutes, or 30 minutes**. 20 minutes is the default setting. The massage chair will turn off automatically and reset after the timer is up.


Personalize Experience

Sounds

Tap **Sound** on the home display to enter the Sound display screen. Use this screen to select and control the SootheMe™ Sound Therapy feature of your chair. The selected sound will play from the speakers next to your head. To turn SootheMe™ Nature Sounds off, de-select the activated sound. *Note: Bluetooth must first be turned on in System screen (see page 23).*



Tap Sound button



Volume Level


Increase or decrease volume of SootheMe™ Nature Sounds. **1 = low, 9 = high, or Off.** Tap screen to select setting.

Sounds	What is it?
White Noise	A constant, even loop of pure white noise to mask out distractions
Ocean Surf	Soothing ocean waves rolling onto the shore
Crickets	Night time in the suburbs. Churping Crickets, water trickling from a pond, and faint traffic noises
Rain	Quiet, light, refreshing rain falling to the ground
Nature	Refreshing sounds of small birds peacefully singing along a tranquil stream.
Air Plane	A Cessna propeller airplane motor idling
Car Ride	Calming inner-city traffic featuring cars, trucks, and motorcycles
Fireplace	Crackling of fire in a fireplace
Thunderstorm	Heavy rainstorm with thunder
Windy Night	Heard from inside a cabin, a howling wind blows constantly outside

Note: Bluetooth must be **ON** for sounds to work. (See page 23).

Quick Access Panel + Joystick Control

The Quick Access Panel + Joystick Control allows you to turn the chair on and off, control chair angles, turn on lights and sounds, adjust volume, pause your massage, select auto program's, and set and select your favorite message programs.



Joystick Control:

- **Turn dial** left or right to recline/upright the massage chair.
- **Long Press** of **power** button turns massage chair on/off. **Short Press** of **power** button cycles through six different auto programs. Name of program is announced through speakers.

Pause – Press to pause massage program. Press again to resume massage program.

Zero Gravity – Press to enter Zero Gravity position 1, press again to enter Zero Gravity position 2, press again to return to upright position. Light color indicates current zero gravity position. White/green = Zero Gravity position 1, Blue = Zero Gravity position 2.

Heat – Press to turn on lumbar heat. Press again to increase heat level. Press again to turn heat off. Light color indicates current heat level. White = off, yellow = low heat, Red = high heat.

LED – Press to turn on LED lights located next to your head on the speakers, and on the outside of the arm panels. Press once to turn on, press again to turn off. LED lights will resume the last settings you selected.

Sound – Press to turn on SootheMe™ Sound Therapy. Each additional press will cycle you through the 10 SootheMe™ sounds. The last press after cycling through the tenth sound will turn SootheMe™ Sound Therapy off.

Volume Up – Press to turn volume up. Button will appear blue once maximum volume is reached.

Volume Down – Press to turn volume down. Button will appear blue once minimum volume is reached.

Favorite Auto Programs (1-4) – Press and hold to set current massage program as favorite. Once set, press to start the favorite massage program. Change the program by repeating and the new favorite will overwrite the old.

Personalize Experience

Intelligent Voice Command + Control

Turn Off Listening

You can turn off intelligent voice control listening by using the tablet remote. Tap **System** from Home display, then toggle **Voice Control** to **Off**. Tap screen to select setting. Intelligent voice control will now no longer activate until turned back on. Your chair comes with built in intelligent voice command + control. This feature allows you to control your chair and massage experience completely hands-free by using one of the many voice commands.

Turn On Listening

To turn on the intelligent voice control function, tap **System** from Home display, then toggle **Voice Control** to **On**. Tap screen to select setting.

Activating Voice Control

To activate, simply say *'Activate Voice Control'*. You may now give your chair any of the commands to the right **within 5 seconds**. Alternatively, you can touch the voice command button on the left speaker, located beside your head to activate, and then speak your command within 5 seconds. Make sure to speak clearly and slowly. After 5 seconds the Intelligent Voice Command function will go to sleep automatically and must be awakened again.

Say Phrase


"Activate Voice Control"

Then speak one of the following
Commands

Turn Off Massage Chair
Flex Massage
Stretch Massage
Gentle Massage
Deep Breathe Massage
Energize Massage
Rest & Recover Massage
Upper Body Massage
Neck & Spine Massage
Lower Body Massage
Tension Release Massage
Full Body Massage
Demo Massage
Start Foot Rollers
Foot Rollers Off
Start Heat
Heat Off
Increase the Volume
Turn Volume Down

MyMassage™ Memory Programs

Your chair has the ability to save your favorite customized massage programs to memory. To create a custom MyMemory program, you first need to set up the chair for what it is you want to record. To do this, use Manual Settings to create a manual massage program with all of your desired air, heat, speed, and intensity settings.



Tap MyMemory button

Saving a Memory Program

To save a massage program, select **MyMemory** from Home Display, then tap the save button to save the current massage settings to memory. There are 3 MyMemory storage slots.

Running a Memory Program

Once a memory program is saved, tap the **'Run'** button on the screen underneath the program you wish to run. If you hit save in a MyMemory program with a program already saved, it will record over the previous setting.


Wireless Charging Pad + USB Charging Station

Your massage chair has an in-built **Wireless Charging Pad** which allows you to charge your smart devices* simply by placing them on the pad located on the left arm panel. In addition, your chair also has a **USB Port**, which you can use to charge your smart devices with your own USB charging cord. The USB port can be found on the left arm panel at the end of the wireless charging pad, directly underneath the tablet remote.

*Note: If the chair is powered on the charging always works. If the system setting for **charging** is set to **off**, then when the chair is powered down the wireless charging pad/USB will also shut off. If **charging** is set to **on**, the charging pad and USB can still be used even when the tablet power is switched to off.*

If the main switch at the base is turned off, charging will not work regardless of the system setting.


**Requires phone with wireless charging capabilities.*




Settings

System

Tap **System** on the home display to enter the system display screen. Use this screen to adjust and personalize your chair and Tablet Remote settings. Swipe up to see the additional settings not visible on the screen, swipe down to go back to the top.



Tap System button



Sleep Mode

Toggle your desired sleep mode setting: **On or Off**. Tap screen to select setting. When sleep mode is **on** the chair will stop in the reclined position after Auto Programs, when sleep mode is **off** the chair will return to a fully upright position after each Auto Program.

Voice Demo

Voice demo talks you through the functionality of the chair in the Demo auto program. Toggle your desired voice demo setting: **On or Off**. Tap screen to select setting.

Air Ionizer

The chair contains a small vent near the speaker to facilitate healthy oxygen intake by emitting negatively charged ions to reduce intake of pollutants. Toggle your chair's Air Ionizer **On**, or **Off**. Tap screen to toggle setting.

Bluetooth

Toggle your chair's Bluetooth® setting: **On or Off**. Tap screen to toggle setting. Open Bluetooth from audio device and pair with **Nokori M980** to play music.

In order to use the chair app, play in-built sounds from your chair, or to play music from your Bluetooth® enabled audio device, Bluetooth® must first be turned **on**.

Charging

Your massage chair has an in-built wireless charging pad and USB Charging Station. Either place your smart device on the wireless charging pad, or connect your smart device using your own USB charging cord. Use this control to toggle this charging feature: **On or Off**. Tap to change setting.

*Note: You can charge your device even when the chair is powered down, provided the main switch on the base is powered **on**. Make sure the System setting for **Charging** is set to **on**.*

**Requires Phone with wireless charging capabilities.*

Voice Control


Toggle your chair's Intelligent Voice Command + Control listening: **On**, or **Off**. Tap screen to select setting.

Display Brightness


Control your desired Tablet Remote screen brightness setting: **1 = dimmest, 5 = brightest**. Tap + or - buttons on screen to change setting.

Language

Tap **Language** to enter the language selection screen. Select your desired language by tapping: **English** or **Chinese**. Swipe left or tap back arrow in top left corner to return to System display screen.



Press Language button



Firmware Version

Indicates the latest software installed on your device.

Help

Tap **Help** to be taken through to the help screen. Here you will be able to access where to find help and contact information if you are having any troubles with your Nokori M980 Massage Chair.


Create a Massage

Manual Settings


Have a particular spot that needs more work? Take the power of massage into your own hands with Manual Settings. Tap **Manual Settings** on the home display to enter the Manual Settings display screen. Use this screen to fully customize your own massage and find the perfect treatment for you.

Your first selection on this screen will start your massage and take you to the massage in-use screen. To return to the manual settings screen, tap the manual settings icon on the in-use screen (2nd button under **More Options**). To return to the In-use screen, simply swipe right or tap the arrow on the Tablet Remote screen, which will take you to the home page, and then tap *'massage running screen'* at the top center of your screen.


If you slide on the **Control Panel Lock** (top right corner of screen), this screen will not revert back to the In-Use screen so you can make continuous adjustments. Slide off to unlock again. Use this screen to build your favorite sequences then save using the MyMassage™ Memory setting on the Home display screen (see page 21).



Tap Manual Settings button



Note: appears when a feature is not available.



Return to Manual Settings screen from In-use screen:
Tap Manual Settings button under more options

Massage Technique

Controls the massage technique of the back mechanism. Select from: **Knead, Tap, Knock, Shiatsu, Sync, or 4D Shiatsu**. Tap screen to select.

Focus Zone

Controls the range of motion of the back mechanism, **Whole** travels the entire length of the track, **Partial** travels a short distance and reverses direction for focused relief, **Point** stops on the track for targeted relief. Tap screen to select setting.

Adjust: Partial and Point location can be fine tuned by using the Adjust setting. Use the arrow up or arrow down buttons to control the location of the back mechanism.

Massage Width

Increase or decrease width of back mechanism. Choose from: **Narrow, Medium, or Wide** (Width can't be adjusted when in Kneading, or Sync modes). Tap screen to select setting.

Maximum 4D Level

Use this control to increase or decrease the maximum intensity of the 4D back mechanism that works the neck and shoulder region. This setting will set the upper limit of the 4D fluctuations throughout your massage. **1 = light, 5 = firm, or Off.** Tap screen to select setting.

Massage Speed

Increase or decrease speed of back mechanism. **1 = slow, 5 = fast** (massage speed can't be adjusted when in Shiatsu Manual mode). Tap screen to select setting.

Air Settings

Choose your desired airbag region/s: **Full, Shoulders (+Arms), Back, Hips, or Legs (+Feet).** Tap screen to select setting. To turn a particular airbag region off, de-select the activated region. Selecting **Full** will over ride any selections and ALL airbags become active.

Max Air Intensity

Increase or decrease maximum intensity of airbag massage. All auto massages are pre-programmed to have varying levels of airbag intensity, this setting will set the upper limit of these fluctuations. **1 = light, 5 = firm, or Off.** Tap screen to select setting.

Back Heat

Activate back heat and choose your desired heat intensity level: **1 = low, 2, 3 = high, or Off** (deactivate back heat). Tap screen to select setting.

Foot Rollers

Turn on Foot Reflexology Rollers and choose your desired foot roller speed: **1 = slow, 2, 3 = fast, or Off** (deactivate foot rollers). Tap screen to select setting.

Calf Rollers & Oscillation

Turn on calf rollers & oscillation and choose your desired calf roller speed: **1 = slow, 2, 3 = fast, or Off** (deactivate calf rollers & oscillation). Tap screen to select setting.

Staying Safe

Safety Information

To ensure safe use of the massage chair and avoid injury or unsafe conditions, please read and follow all instructions before using product.

WARNING

USE NOT RECOMMENDED FOR CERTAIN PERSONS

Use of massage chair may not be safe or suitable for persons with certain medical conditions and could cause serious injury or death in some circumstances. If you have any of the following conditions, please consult a physician before using the massage chair:

- Use of implanted electronic medical devices (such as a cardiac pacemaker)
- Pregnancy
- Cancer, malignant tumors, or other growths
- Osteoporosis or spinal fracture
- Other fractures or musculoskeletal injuries
- Loss of or reduced sensitivity to heat
- Implanted medical fixation devices such as rods, pins, etc.
- Recent surgery or sutures
- Skin diseases or skin injury
- High fever
- Certain pulmonary or breathing conditions
- Impaired circulation

WARNING

To avoid possible death or serious injury to user or others, please read and follow these instructions:

- **The areas under the footrest and behind the back rest are potentially dangerous for a child or pet. The chair back is heavy and reclines with force. A small child or pet located behind the chair could be crushed as chair is reclined resulting in serious injury or death. When chair is reclined, small children or pets who have crawled under the leg rest may not be visible to the user and could be crushed when leg rest is lowered or when chair is returned to upright position. To avoid serious injury or death, check these areas carefully before reclining, lowering leg rest, or returning chair to upright position.**
 - **Chair should not be used by children under age 14.** Small children could be trapped or injured by airbags, heating mechanism, or moving parts. When chair is not in use, unplug unit and secure chair so that children cannot accidentally power on and operate chair.
- Children over age 14, persons with reduced physical, sensory, or mental capabilities, and elderly or frail persons should exercise caution and use massage chair only when supervised or assisted by a person over 16 years of age.
- Chair has a heated surface and could cause burns, particularly in persons with reduced sensitivity to heat. Such persons should use the chair only after consulting with a physician and should use extreme caution during any physician-approved use.

CAUTION

To avoid the risk of minor injury or discomfort, or damage to the massage chair or other property, please read and follow these instructions for safe use of massage chair:

- Do not stand or stack heavy objects on footrest.
- Do not operate heating features of chair while under a blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- To avoid pinching or crushing, please do not place body parts, especially fingers and toes, between parts of chair and keep clear of moving parts.
- To avoid overheating, injury or discomfort from overuse, do not fall asleep while using massage chair and do not use for extended periods of time (longer than 20 minutes).
- Avoid use while under the influence of alcohol, medications or other substances that may cause drowsiness, disorientation, or impairment of judgment or motor skills.
- Do not use the massage chair right after a meal, as it may cause discomfort.
- If you feel any abnormal discomfort during the operation of the massage chair, turn off the power immediately and discontinue use.
- Do not use this appliance when ambient temperature is over 40 C (104 F).
- Do not use this appliance in humid or dusty environment, or when any part of the body is in contact with plumbing or any similar ground.
- Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair, dust and the like.
- Do not use outdoors.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- Place the product on a flat, level floor to reduce risk of tipping or overturning.
- Do not use or store near heat or open flame.
- Intended only for users who weigh below 300 lbs.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Massage chair intended only for use by one person. Do not use by two or more persons at the same time to avoid damage to the product.
- Do not allow children to stand, jump, or play on or around massage chair, even when it is not powered on or in use.
- Remove personal accessories from arms and empty pockets while using the massage features of the chair.
- Check the upholstery under the cushions and other spots for damage or loose objects that may cause injury or damage chair while operating. If any damage is present, do not use the massage chair and refer to a qualified service professional for servicing.
- To avoid damage to chair, walls, or other objects, make sure there are no obstacles behind the chair and there is enough clearance before adjusting the backrest or leg rest angle.
- Please be seated properly while using the product.

Staying Safe

- To avoid damage to chair or floors, do not drag or push the chair or roll its casters on wood floor or carpet. See instructions on p.6 for safely moving chair.
- If massage chair is not working properly, has been dropped or damaged, or has been dropped into water or exposed to flooding, return the appliance to a service center for examination and repair before attempting to use.
- Do not drop or insert any object into any openings in chair.

WARNING

Read and follow these instructions concerning safe use of the power cord and power unit to avoid possible electric shock, fire hazard, use of chair by and injury to unattended children, or damage to chair or other property.

- To avoid risk of electric shock, connect this unit to a properly grounded outlet only. See Grounding Instructions on pg. 7.
- Always unplug massage chair from the electrical outlet immediately after use and before cleaning. An appliance should never be left unattended when plugged in. To disconnect, turn all controls to the off position, then remove plug from outlet.
- Do not use massage chair and unplug from outlet during thunder or lightning storms, and before putting on or taking off parts.
- To ensure safe operation, power must be supplied only at standard 110 voltage, to the specifications of the appliance. Confirm that the power voltage stated on the rating label corresponds to your local electricity supply.
- The massage chair should be used only with the power supply unit provided. Do not use with any other power source
- Do not use a wet or damp hand to unplug the cord to avoid electric shock.
- Do not pull on the power cord to unplug. Grip by plastic end nearest outlet to unplug power cord.
- Do not squeeze, over bend, pull hard, or twist the power cord. - Keep the power cord away from heated surfaces.
- Do not carry or drag the chair by power cord or use cord as a handle.
- If there is any smoke or unusual smell while using massage chair, stop using immediately and unplug the power cord.
- Never operate the chair if it has a damaged power cord or plug. If the power cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person to avoid a hazard.

Do not disassemble, dismantle or attempt to repair massage chair. Such actions, as well as misuse of product, may cause damage to or failure of massage chair and may void the manufacturer's warranty. For repairs, please contact an authorized dealer or repair agent at 800-242-0761. For additional details concerning terms, conditions and limitations of warranty, see <https://kyotamassagechairs.com/warranty-info>.

Fixing Issues

Trouble Shooting

Symptoms	Possible Causes	Possible Solution
Noise is heard while in use	These noises are normal and arise from friction between the massage rollers and the leather cover	No need to take any measures
Message Chair does not start	The power cord is not secured into the socket Not switched ON The fuse is blown	Insert the power plug properly into the power socket Turn on the switch found on chair side. Then push power button on remote Replace only with a fuse of same type and rating
No music comes from the speaker	The volume is turned to the lowest setting	Adjust the speaker volume from the mobile device. Make sure Bluetooth setting on chair and phone are both ON
Backrest or footrest can not raise or recline	Excessive load has been pressed on the backrest or legrest	Replace the load and try again
Airbag malfunction	The air hose is blocked	Straighten the air hose and clear out the blockage

Specifications

Model	Nokori M980
Dimension of Main Body (in)	63 x 32 x 50 (L x W X H)
Necessary Clearance to Wall (in)	4"
Net Weight (lbs)	364
Shipping Weight (lbs)	406
Max. User Weight (lbs)	300
Voltage	110-120V~
Rated Current	2.2A
Power Consumption	242W

Fixing Issues

Frequently Asked Questions

Q: I find the chair is too intense to be comfortable. What can I do?

A: Your body needs to become acclimated to therapeutic massage. To be effective, the massage techniques must compress the tissue in your body. We recommend the following steps to help get started. Then over time as your body acclimates you can increase the intensity by reducing the layers between you and the chair.

1. Use Pillow and Pillow pad to reduce upper body intensity.
2. From the In-Use screen, swipe left to get to the **Custom Selections** screen.
 - If airbag pressure is too intense, use the Max Air Settings control to lower airbag intensity
 - If a specific airbag is too intense, use the Air Settings control to turn off particular regions.
3. Adjust the recline on the remote. More upright will be less intense. Weightless Zero Gravity Recline will be more intense.
4. If after adjustments and attempt to acclimate, you still experience discomfort, discontinue use and consult a physician.

Q: I'm not a foot massage person, what should I do?

A: Turn off Foot Reflexology Rollers. From the In-Use screen, swipe left to get to the **Custom Selections** screen. Use the Foot Rollers control to deactivate the Foot Reflexology Rollers. You may also want to use the Airbag Setting control to turn off the Leg/Foot airbags.

Q: My chair is not performing as expected. What should I do?

A: Your Kyota massage chair is an amazing combination of programming and robotics. On occasion the chair just may need to be rebooted. To do this power down the chair and unplug from the wall for 5 minutes then plug back in and power back up to see if it self-healed. If you are still having an issue, give Kyota a call at 800-242-0761.

Q: I can never seem to get in my Kyota Massage chair, someone is always in it.

A: We know. It happens. Tell your friends to get their own Kyota Chair.



KYOTA[®] | **The World's Most
Advanced Massage Chairs[®]**

72 Stard Road, Seabrook, NH 03874

Toll Free #: (800) 242-0761

www.kyotamassagechairs.com

Version 1.3