

Voice Commands

- 1) Check to make sure the Microphone shows lit under the words **Voice Control** on the display. If not, tap the Voice Control button to turn on listening.
- 2) Say “Hi Kyoto” or “Hey Kyoto” to activate voice control and let the chair know you’re giving a voice command.
- 3) You only have a few seconds to speak the command after the activation word. Speak any **Voice Command** below:

Actions		
Turn ON	Heat Level 3	Zero Gravity 1
Power OFF	Heat OFF	Zero Gravity 2
Pause Massage	Roller Speed Level 1	Zero Gravity OFF
Resume Massage	Roller Speed Level 2	Rocking ON
Heat Level 1	Roller Speed Level 3	Rocking OFF
Heat Level 2	Foot Roller OFF	


Auto Programs		
Revitalize	Chinese Massage	Neck Massage
Energize	Thai Massage	Shoulder Massage
Renewal	Healthy Breath	Back Massage
Stress Relief	Demo 1	Waist Massage
Back & Spine	Demo 2	Hip Massage
Waist & Hip	Stretch	Leg Massage
	Neck & Shoulder	

Massage Techniques		
Kneading Massage	Shiatsu Massage	Sync Massage
Tapping Massage	Rubbing Massage	Knocking Massage

KYOTA | The World's Most Advanced Massage Chairs®
72 Stard Road, Seabrook, NH 03874 | 603-910-5333
www.kyotamassagechairs.com
Version 1.0

KYOTA®

Quick Start Guide



Alternatively, scan the **QR code** to watch a remote tutorial video.

Zenyu M338 Massage Chair

- Full Body** - The programs are Revitalize, Energize, and Renewal.
- Demo** - The programs are Demo (with audio) and Demo (without audio).
- Pain Relief** - The programs are Stress Relief, Back & Spine, Waist & Hip.
- Stretch** - A program that combines massage with stretching.
- Therapeutic** - The programs are Chinese Massage, Thai Massage, and Healthy Breath.
- Neck & Shoulder** - A program focused on relieving stress and tension.
- Upper Body** - The programs are Neck Massage, Shoulder Massage, and Back Massage.
- Lower Body** - The programs are Waist Massage, Hip Massage, and Leg Massage.
- Zero Gravity** - Press to change the angle of the chair; Zero Gravity 1 and 2, press again to turn off.
- Rocking** - Press to turn on rocking mode and gently rock the chair back and forth. Press again to turn it off.
- Voice Guide** - Press to turn on voice guide or press again to turn off.
- Voice Control** - Press to activate voice commands or press again to turn off. Remember to say “Hi Kyoto” or “Hey Kyoto”.

Auto Programs - Choose from 8 categories and cycle through 19 preset auto programs with each press.

KYOTA®



Time - Press to increase time in increments of 10 minutes, 20 minutes, and 30 minutes.

Play/Pause - Press to pause or resume your massage session.

Power Button - Press to turn on your massage chair, press and hold to power off the massage chair.

Foot Roller - Press to change the speed of the foot roller, 1 = slow, 2 = medium, 3 = fast, or off.

Heating - Press to change the intensity of the lumbar heat, 1 = warm, 2, 3 = hot or off.

Mech Up/Down- Press and hold to move the mech up or down, release the button to stop.

Backrest Up/Down- Press and hold to move your backrest up or down. Release to stop.

Technique - Cycle through different massage styles; kneading, knocking, shiatsu, rubbing, sync, and tapping.

Whole/Point/Partial - Choose between whole massage, partial massage, or point massage.

Airbag Focus - Choose between upper body, lower body, or whole body.

Width - Press to toggle narrow, medium, or wide coverage of the 4-node back rollers.

Sleep - Enable Sleep Mode to keep your chair comfortably reclined without automatically returning upright.

Bluetooth - Connect your favorite capable device and stream music. Press to turn on or off.

Volume - Control the sound level of your tablet controller. Press to increase in increments.

Air Intensity - Change the intensity level of your airbags. Press to cycle through options.

Speed - Press to change the massage speed of the rollers, 1 = slow, 2, 3, 4, 5 = fast.