

BLUFLAME

Troubleshooting BT Connection

To start: please ensure that no USB cable is connected

1. Start the analyzer

- Press the context button
- Select the extras menu
- Select Settings
- Scroll all the way to Bluetooth AND SELECT IT
- Change to Android

Switch analyzer off – wait at least 5 seconds

2. Start the analyzer

- Press the context button
- Select the extras menu
- Scroll all the way down to DEFAULT SETTINGS AND SELECT IT

Switch analyzer off – wait at least 5 seconds

3. Start the analyzer

- Press the context button
- Select the extras menu
- Scroll all the way down to DEVICE INFO AND SELECT IT
- Press the context buttons and select Bluetooth
- Press the context button and select Init

Switch analyzer off – wait at least 5 seconds

4. Start the analyzer

- Press the context button
- Select the extras menu
- Scroll all the way down to Bluetooth and select it
- Change to iOS

Switch analyzer off – wait at least 5 seconds

5. Start the analyzer

- Press the context button
- Select the extras menu
- Scroll the the way down DEVICE INFO and select it
- Press the context button and select Bluetooth
- Press the context button and select Init

Now you should be able to connect your phone

