

AC-SYNC

Charge and Sync Operations

Anywhere **CART**




Mode Selection Switch




Main Power Switch




Host Connection Indicator



Host / Master Port
(USB-B)



Device Status Indicator



CHARGE MODE
Indicators are OFF.

SYNC MODE
Indicators are GREEN.

FAULT MODE
Indicators are RED.



Helpful Hints:

While in CHARGE mode, no LEDs will be illuminated, but the fan inside the SYNC Station will be operational.

While in SYNC mode, LEDs on USB ports which have devices attached will illuminate GREEN when operating correctly. An LED which illuminates RED means the cable or device port may be defective. Turn off power, replace cable and try again.

Touchboards

205 Westwood Ave, Long Branch, NJ 07740
 Phone: 866-94 BOARDS (26273) / (732)-222-1511
 Fax: (732)-222-7088 | E-mail: sales@touchboards.com

To CHARGE devices:

1) With the main power switch OFF, open the rear panel door on your AC-SYNC cart.



2) Locate the MODE Switch on the SYNC Station and move to "CHARGE" mode.



3) Locate the main power switch on side of AC-SYNC cart and move to the "I" position.



NEVER add or remove devices while in SYNC mode.

To SYNC devices:


1) With the main power switch OFF, open the rear panel door on your AC-SYNC cart.



2) Locate the MODE Switch on the SYNC Station and move to "SYNC" mode.



3) Locate the HOST SYNC port on the outside of AC-SYNC cart, plug in your host device & turn the device on



4) Locate the main power switch on side of AC-SYNC cart and move to the "I" position.



5) Verify the HOST status indicator is illuminated GREEN and individual DEVICE status indicators are GREEN.



HELPFUL HINTS

The use of OEM cables is HIGHLY RECOMMENDED.

While in CHARGE mode:

- Devices can be added or removed any time.
- There should be no LED indicators illuminated.

While in SYNC mode:

- For best results, make sure your HOST device has the latest version of your preferred SYNC software.
- All devices need to be turned on in order to SYNC.
- USB ports which don't have devices attached, won't illuminate.
- Always check connections before use.

TROUBLESHOOTING:

- **Unit does not turn on?** Check all power cords going into the power strip / SYNC Station and verify they are plugged in.
- **No HOST status LED in SYNC mode?** Turn OFF Main power switch, then Re-seat or replace HOST cable and repeat from step 1.
- **RED or FLASHING LEDs in SYNC mode?** Turn OFF Main power switch, then Re-seat or replace DEVICE cable and repeat from step 1.
- **Devices won't show up in iTunes?**
 - a) Close iTunes and reopen it.
 - b) Make sure both the HOST and DEVICES have the latest version of iTunes.
 - c) Restart the HOST device.
 - d) Repeat from step 1.