

# BWPK Series

## Ultra-Flat (Width 10mm) Picking Sensor

### ■ Features

- Plastic injection case
- Slim body (W30×H140×T10mm)
- Long/Short sensing distance mode  
(sensing distance selection function)
- Mutual interference prevention (frequency switching function)
- Selectable Light ON/Dark ON operation mode by switch
- Picking indicator includes
- Protection structure IP40 (IEC standard)



**⚠ Please read "Caution for your safety" in operation manual before using.**



### ■ Specifications

|                         |                           |  |
|-------------------------|---------------------------|--|
| Model                   | NPN open collector output | <b>BWPK25-05</b>   |
|                         | PNP open collector output | <b>BWPK25-05P</b>  |
| Sensing type            |                           | Through-beam   |
| Sensing distance        | Long distance mode        | 0.1 to 3m  |
|                         | Short distance mode       | 0.05 to 1m   |
| Sensing target          |                           | Opaque materials of min.Ø35mm  |
| Optical axis pitch      |                           | 25mm   |
| Number of optical axis  |                           | 5EA  |
| Sensing width           |                           | 100mm  |
| Power supply            |                           | 12-24VDC ±10% (Ripple P-P : Max. 10%)  |
| Current consumption     |                           | Emitter : Max. 60mA, Receiver : Max. 60mA  |
| Control output          |                           | NPN or PNP open collector output<br>• Load voltage : Max. 30VDC • Load current : Max. 150mA<br>• Residual voltage - NPN : Max. 1V, PNP : Min.2.5V                                    |
| Operation mode          |                           | Selectable Light ON/Dark ON by switch  |
| Response time           |                           | Max. 30ms  |
| Light source            |                           | Infrared LED (850nm modulated)   |
| Interference protection |                           | Interference protection by transmission frequency selection  |
| Protection circuit      |                           | Reverse power polarity, Output short-circuit (Overcurrent) protection  |
| External picking input  |                           | Non-contact or contact input<br>• NPN open collector output : Lighting (0-2V), Light out (5-30V or open)<br>• PNP open collector output : Lighting (4-30V), Light out (0-3V or open) |
| Environment             | Ambient illumination      | Sunlight : Max. 10,000lx, Incandescent lamp : Max. 3,000lx (received light side illumination)  |
|                         | Ambient temperature       | -10 to 55°C, storage : -20 to 60°C   |
|                         | Ambient humidity          | 35 to 85%RH, storage : 35 to 85%RH   |
| Insulation resistance   |                           | Min. 20MΩ (at 500VDC megger)   |
| Noise resistance        |                           | ±240V the square wave noise (pulse width: 1μs) by the noise simulation   |
| Dielectric strength     |                           | 1,000VAC 50/60Hz for 1minute   |
| Vibration               |                           | 1.5mm amplitude or 300m/s <sup>2</sup> at frequency of 10 to 55Hz (for 1 min.) in each X, Y, Z direction for 2 hours   |
| Shock                   |                           | 500m/s <sup>2</sup> (approx. 50G) in each X, Y, Z direction for 3 times  |
| Protection structure    |                           | IP40 (IEC standard)  |
| Material                |                           | Case : PC/ABS, Sensing part: PMMA  |
| Cable                   |                           | Ø4.0mm, 4-wire, Length : 2m (Emitter : Ø4.0mm, 3-wire, Length : 2m)<br>(AWG 22, Core diameter : 0.08mm, Number of cores : 60, Insulator out diameter : Ø1.25)                        |
| Approval                |                           | <b>CE</b>  |
| Weight <sup>※1</sup>    |                           | Approx. 220g (approx. 180g)  |

※1: The weight includes packaging. The weight in parentheses is for unit only.


※ The temperature or humidity mentioned in Environment indicates a non freezing or condensation environment.

# Area Sensor


## ■ Dimensions

(unit: mm)

### <Emitter>




### <Receiver>




### <Bracket>: sold separately


#### • Flat bracket (BK-BWPK-ST)



#### • L-shaped bracket (BK-BWPK-L)



#### • Protection bracket (BK-BWPK-P)




## ■ Feature Data

| Parallel shifting characteristic |      | Angle characteristic |      |
|----------------------------------|------|----------------------|------|
| Measuring method                 | Data | Measuring method     | Data |
|                                  |      |                      |      |

- (A) Photoelectric Sensors
- (B) Fiber Optic Sensors
- (C) Door/Area Sensors
- (D) Proximity Sensors
- (E) Pressure Sensors
- (F) Rotary Encoders
- (G) Connectors/ Sockets
- (H) Temperature Controllers
- (I) SSRs / Power Controllers
- (J) Counters
- (K) Timers
- (L) Panel Meters
- (M) Tacho / Speed / Pulse Meters
- (N) Display Units
- (O) Sensor Controllers
- (P) Switching Mode Power Supplies
- (Q) Stepper Motors & Drivers & Controllers
- (R) Graphic/ Logic Panels
- (S) Field Network Devices
- (T) Software

# BWPK Series

## Structure




### Operation mode switch


| No | Function                                   | Switch OFF         | Switch ON          |
|----|--|--------------------|--------------------|
| ①  | Selection of transmission frequency        | Frequency A        | Frequency B        |
| ②  | Selection of operation indicator           | Lighting indicator | Flashing indicator |
| ③  | Emitter Selection of sensing distance mode | Long mode          | Short mode         |
|    | Receiver Selection of operation mode       | Light ON           | Dark ON            |

## Input/Output Circuit And Connection Diagram


### NPN open collector output




※1: Picking input (P.I) : Contact or transistor is ON, and picking indicator operates.



### PNP open collector output




※1: Picking input (P.I) : Contact or transistor is ON, and picking indicator operates.



※Picking indicator: When external picking input (P.I) is short-circuited with OUT (Black), it is operated same as ON/OFF status of control output.

## Operation Timing Diagram



※The above diagram is the state of operation for Light ON, but in case of Dark ON, it is opposite operation against Light ON.

※Picking indicator is operated by connecting picking input line and output line. (If not connecting these, picking indicator is OFF regardless of operation mode.)

## ■ Operation Indicator

| Item                 | Emitter   |       |                            | Receiver  |     |                            | Control output |
|----------------------|-----------|-------|----------------------------|-----------|-----|----------------------------|----------------|
|                      | Indicator |       |                            | Indicator |     |                            |                |
|                      | Green     | Green | Picking indicator (yellow) | Green     | Red | Picking indicator (yellow) |                |
| Power on             |           |       | —                          | —         | —   | —                          | —              |
| FREQ. A operation    |           |       | —                          | —         | —   | —                          | —              |
| FREQ. B operation    |           |       | —                          | —         | —   | —                          | —              |
| Stable light ON      | —         | —     |                            |           |     |                            | ON             |
| Flashing function ON | —         | —     |                            |           |     |                            | ON             |
| Unstable light ON    | —         | —     |                            |           |     |                            | ON             |
| Unstable light OFF   | —         | —     |                            |           |     |                            | OFF            |
| Stable light OFF     | —         | —     |                            |           |     |                            | OFF            |
| Overcurrent          | —         | —     |                            |           |     |                            | OFF            |

|  |                                     |
|--|-------------------------------------|
|  | Light ON                            |
|  | Light OFF                           |
|  | Flashing by 0.3 sec.                |
|  | Flashing simultaneously by 0.3 sec. |

※The operations of 'Operation indicator' and 'Picking indicator (Red)' for stable light ON level, unstable light ON level, unstable light OFF level, and stable light OFF level are for Light ON. (In case of overcurrent, control output is OFF regardless of operation mode.)

## ■ Function

### ◎ Switching of Long/Short mode (selectable sensing distance)

The rated sensing distance is 3m for Long mode, 1m for short mode. It minimizes interference setting as short mode when using more than 3 sets closely together.

|            | Operation mode switch (Emitter) | Rated sensing distance |
|------------|---------------------------------|------------------------|
| Long mode  | Long                            | 3m                     |
| Short mode | Short                           | 1m                     |

### ◎ Interference protection

In case of using 2 pcs of sensor in serial or parallel in order to extend sensing width, it may cause sensing error because of light interference.

This function is operating a sensor in transmission frequency A and another sensor in transmission frequency B to avoid these sensing errors by the light interference.

|  | Operation mode switch (Emitter+Receiver) | Frequency A, B indicator (Emitter)         |
|--|--|--|
| Sensor (A)<br>(Transmission frequency A) | FREQ.A                                   | Frequency A (green)<br>Frequency B (green) |
| Sensor (B)<br>(Transmission frequency B) | FREQ.B                                   | Frequency A (green)<br>Frequency B (green) |

### ◎ Light ON/Dark ON mode

The control output is ON when it is light ON in Light ON and the control output is ON when it is light OFF in Dark ON. It is available to select with user's preference.

|          | Operation mode switch (Receiver) | Control output operation       |
|----------|----------------------------------|--------------------------------|
| Light ON | Light ON                         | It is ON when it is light ON.  |
| Dark ON  | Dark ON                          | It is ON when it is light OFF. |

### ◎ Switching of Lighting/Flashing of Picking indicator

Picking indicator is lighting or flashing to make out work sensing operation more easily.

|          | Operation mode switch (Emitter+Receiver) | Picking indicator operation |
|----------|--|-----------------------------|
| Lighting | Lighting                                 | Lighting indicator          |
| Flashing | Flashing                                 | Flashing indicator          |

(A) Photoelectric Sensors

(B) Fiber Optic Sensors

(C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure Sensors

(F) Rotary Encoders

(G) Connectors/Sockets

(H) Temperature Controllers

(I) SSRs / Power Controllers

(J) Counters

(K) Timers

(L) Panel Meters

(M) Tacho / Speed / Pulse Meters

(N) Display Units

(O) Sensor Controllers

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

(R) Graphic/Logic Panels

(S) Field Network Devices


(T) Software

# BWPK Series

## ■ Installation


### ◎ For direction of installation

Emitter and receiver should be installed as same up/down position.



### ◎ For reflection from the surface of wall and flat


When installing it as below the light reflected from the surface of wall and flat will not be shaded. Please, check whether it operates normally or not with a sensing target before using. (Interval distance : Min. 0.3m)




### ◎ For prevention of interference

It may cause interference when installing more than 2 sets of the sensor. In order to avoid the interference of the sensor, please install as following figures and use the interference protection function.


#### ● Transmission direction should be opposite between 2 sets



#### ● Baffle should be installed between 2 sets.



#### ● It should be installed out of the interference distance



## ■ Troubleshooting

| Malfunction   | Cause   | Troubleshooting                                       |
|---|---|---|
| Non-operation   | Power supply  | Supply rated power.                                   |
|   | Cable incorrect connection or disconnection   | Check the wiring.                                     |
|   | Rated connection failure  | Use it within rated sensing distance.                 |
| Non-operation in sometimes                                      | Pollution by dirt of sensor cover   | Remove dirt by soft brush or cloth.                   |
|   | Connector connection failure  | Check the assembled part of the connector.            |
| Control output is OFF even though there is not a target object. | Out of rated sensing distance   | Use within rated sensing distance.                    |
|   | There is an obstacle to cut off the light emitted between emitter and receiver                          | Remove the obstacle.                                  |
|   | There is a strong electric wave or noise generated by motor, electric generator, high voltage line etc. | Put away the strong electric wave or noise generator. |
| LED displays for over current                                   | Control output line is shorten  | Check the wiring.                                     |
|   | Over load   | Check the rated load capacity.                        |