

PRODUCT DESCRIPTION

Programmable regulators with Ethernet connection are designed to measure temperature, relative humidity and barometric pressure of air in non-aggressive environment, to alarm indication and to control of external devices. Three galvanic no isolated binary inputs are intended for detection of binary signals. Regulators are available in wall-mount version or with probe on a cable. Type H3531P is designed for measurement the temperature and relative humidity of compressed air.

The function of two output relays can be set from regulator keyboard (or from computer) and using the jumpers (see „Electrical wiring“). You can assign one of measured or computed value (dew point temperature, absolute humidity, specific humidity mixing ratio and specific enthalpy) to each relay. The setting of delay, hysteresis and audible alarm is enabled for each relay. The status of output relays can be controlled remotely via Ethernet too. The instrument may send a warning message if the measured value goes out of adjusted limits. Devices are equipped with four button keyboard and LCD display.

The formats of Ethernet communication that are supported: www pages with user-design possibility, Modbus TCP protocol, SNMPv1 protocol and SOAP. For setting of all parameters you can use *TSensor* software (it is free to download at www.cometsystem.com).

type *	measured values	version	mounting
H0530	T	ambient air	wall
H4531	T	external probe Pt1000/3850 ppm	wall
H3530	T + RH + CV	ambient air	wall
H3531	T + RH + CV	probe on a cable	wall
H3531P	T + RH + CV	probe on a cable – pressure up to 25 bars	wall
H7530	T + RH + P + CV	ambient air	wall
H7531	T + RH + P + CV	probe on a cable	wall

* models marked HxxxxZ are custom - specified devices

T...temperature, RH...relative humidity, P...barometric pressure, CV...computed values

INSTALLATION , OPERATION AND CONFIGURATION

The mounting holes and connection terminals are accessible after unscrewing the four screws in the corners of case and removing the lid. Place the device on a flat surface, pass the cables through released glands and connect wires according to the diagram. For device connection choose cables with external diameter 4 to 6.5 mm and wire cross-section 0.14 to 1.5 mm². Shielded cable have to be used for two-state sensor and external probe connection (maximum cable length of 10 m). Insert attached plugs into unused cable glands too. The all cables should be located as far as possible from potential interference sources. Pay attention to device mounting, because incorrect choice of working position or place of measuring could adversely affect accuracy and long-term stability of measured values.

Actual parameters settings of each relay can be displayed by pressing of „▲“ key. To change any parameter press the „Set“ key, enter password (default 0000) and set required value. Then click on „Set“ and by pressing of "ESC" key leave the setup mode. Extended setting mode (see manual for devices at www.cometsystem.com) you can use to setting new password and to modifying of all other parameters (acoustic alarm, computed value selection etc.).

For network device connection it is necessary to know new suitable IP address (you can get it automatically from DHCP server or from your network administrator) and to have *TSensor* software installed. After you connect external probe, Ethernet cable and power adapter, you run *TSensor* program, set the new IP address, configure the device in accordance with your requirements and finally store the settings. The default IP address of each device is preset to **192.168.1.213**.

Devices don't require special maintenance. We recommend you periodic calibration for measurement accuracy validation.

ERROR STATES

Device continuously checks its state during operation and if an error appears, it is displayed relevant code: **Err 1** – measured or calculated value is over the upper limit, **Err 2** – measured or calculated value is below the lower limit or pressure measurement error occurred, **Err 0**, **Err 3** a **Err 4** – it is a serious error, please contact distributor of the device, **Err5**, **Err6** - there is problem with assigned value to output relay, **Err9** – inserted password is not valid.

SAFETY INSTRUCTIONS



- Humidity and temperature sensors of the regulator can not be operate and store without a filter cap.
- Temperature and humidity sensors have not to be exposed to direct contact with water and other liquids.
- Take care when unscrewing the filter cap as the sensor element could be damaged.
- Use only the power adapter according to technical specifications and approved according to relevant standards.
- Do not connect or disconnect devices while power supply voltage is on.
- Do not install or remove the probe of H3531P regulator under pressure.
- Installation, electrical connection and commissioning should be performed by qualified personnel only.
- Devices contain electronic components, it needs to liquidate them according to currently valid conditions.
- **To complement the information in this data sheet** read the manuals and other documentations that are available in the Download section for a particular device at www.cometsystem.com.

Technical specifications

Device type	H44531	H0530	H3530, H7530	H3531	H7531	H3531P
Common parameters	Supply voltage: 9 to 30Vdc Binary inputs: low level input voltage ... 0 to 0.5V, high level input voltage ... 3 to 30V, auxiliary power supply +U ... 9 to 30 Vdc	Power consumption of the device: ~ 1W Relay outputs: max. switching voltage ... 50V, max. switching current ... 2A, max. switching power ... 60VA				
Temperature measuring range	-200 to 600°C	-30 to +80°C	-30 to +80°C	-30 to +105°C	-30 to +105°C	-30 to +105°C
Accuracy of temperature measurement	±0.2°C (without probe)	± 0.4°C	± 0.4°C	± 0.4°C	± 0.4°C	± 0.4°C
Relative humidity (RH) measuring range	—	0 to 100%RH	0 to 100%RH	0 to 100%RH	0 to 100%RH	0 to 100%RH
Accuracy of humidity measurement from 5 to 95 %RH at 23°C	—	± 2.5 %RH	± 2.5 %RH	± 2.5 %RH	± 2.5 %RH	± 2.5 %RH
Barometric pressure measuring range	—	600 to 1100 hPa (H7530)	±1.3hPa (H7530)	—	600 to 1100 hPa	—
Accuracy of barometric pressure measurement at 23°C	—	—	—	—	—	—
Other calculated humidity variables (dew point temperature, ...)	—	—	—	—	—	—
Recommended calibration interval of the device *	2 years	2 years	1 year	1 year	1 year	yes
Protection class of the case with electronics	IP40	IP40	IP40	IP40	IP40	IP40
Protection class of the sensors cover	—	IP40	IP40	IP40	IP40	IP40
Temperature operating range of the case with electronics **	-30 to +80°C	-30 to +80°C	-30 to +80°C	-30 to +80°C	-30 to +80°C	-30 to +80°C
Temperature operating range of the sensing element (sensors)	—	-30 to +80°C	-30 to +80°C	-30 to +105°C	-30 to +105°C	-30 to +105°C
Humidity operating range	0 to 100%RH	0 to 100%RH	0 to 100%RH	0 to 100%RH	0 to 100%RH	0 to 100%RH
Mounting position	any position	sensor cover downwards	sensor cover downwards	any position ***	any position ***	any position ***
Storage temperature range (0 to 100%RH, no condensation)	-30 to +80°C	-30 to +80°C	-30 to +80°C	-30 to +80°C	-30 až +80°C	-30 to +80°C
Electromagnetic compatibility according to	EN 61326-1	EN 61326-1	EN 61326-1	EN 61326-1	CSN EN 61326-1	EN 61326-1
Weight	340 g	340 g	360 g	410 (450, 530) g	410 (450, 530) g	460 (500, 560) g
Dimensions [mm]						
Electrical wiring						

* Recommended calibration intervals: relative humidity - 1 year, temperature - 2 years, pressure - 1 year
 ** It is recommended to switch off the LCD display at ambient temperature above 70°C.
 *** if it can lead to long term condensation of water, it is necessary to use the probe at position with sensor cover downwards