

Static Field Meter & Ionization Test Kit Operation and Maintenance



Made in the
United States of America



Figure 1. Desco 19432 Static Field Meter



Figure 2. Desco 19433 Ionization Test Kit

Description

The Desco 19432 Static Field Meter indicates surface voltage and polarity on objects. The rechargeable meter has a measurement range of 0 to ± 40.0 kV. A Time-of-Flight (ToF) distance sensor determines distances from 1 to 200 mm to automatically adjust measured electrostatic voltages. It utilizes a chopper-stabilized sensor for use in both normal and ionized environments. The meter has a dissipative enclosure, and it requires no manual zeroing when held by a grounded operator. Automatic Snapshot Hold freezes the measurement on the display when the meter is moved away from the targeted object. Up to 10 measurements may be stored in memory and downloaded via its USB-C port.

The Desco 19433 Ionization Test Kit includes and utilizes the 19432 Static Field Meter to measure the offset voltage (balance) and charge decay of ionization equipment. The Ionization Test Kit also includes a charger used to place a $\pm 1,000$ V charge on the conductive plate, making it possible to also measure the discharge times of air ionization equipment per ANSI/ESD SP3.3 Periodic Verification of Air Ionizers.

The Ionization Test Kit may be used to perform periodic verifications of ionizer performance per ANSI/ESD SP3.3 Periodic Verification of Air Ionizers and ESD TR53 Compliance Verification of ESD Protective Equipment and Materials. Desco recommends using the Prostat® CPM-766 Charged Plate Monitor should an ionizer require testing per ANSI/ESD STM3.1 for evaluation and qualification.

All Static Field Meters and Ionization Test Kits are calibrated to NIST standards.

“When any object becomes electrostatically charged, there is an electrostatic field associated with that charge. If an ESDS (ESD sensitive) device is placed in that electrostatic field, a voltage may be induced on the device. If the device is then momentarily grounded, a transfer of charge from the device occurs as a CDM (Charged Device Model) event. If the device is removed from the region of the electrostatic field and grounded again, a second CDM event will occur as charge (of opposite polarity from the first event) is transferred from the device.” (Handbook ESD TR20.20 section 2.7.5 Field Induced Discharges)

The Static Field Meter, Ionization Test Kit, and their accessories are available as the following item numbers:

Item	Description
19432	Static Field Meter
19433	Ionization Test Kit
19434	Belt Clip Holster
19440	Conductive Plate and Charger
19441	Conductive Plate

Packaging

19432 Static Field Meter

- 1 Static Field Meter
- 1 USB-C Charge Cable, 1 m

19433 Ionization Test Kit

- 1 Static Field Meter
- 1 Conductive Plate
- 1 Charger
- 1 USB-C Charge Cable, 1 m
- 1 Carrying Case

19440 Conductive Plate and Charger

- 1 Conductive Plate
- 1 Charger
- 1 9 V Alkaline Battery
- 1 Carrying Case



Figure 3. Desco 19432 Static Field Meter packaging contents



Figure 4. Desco 19433 Ionization Test Kit and Carrying Case

Features and Components

STATIC FIELD METER




Figure 5. Static Field Meter features and components

A. Electrostatic Field Sensor: Point 1 to 200 mm away from the measured object.

B. Memory Location: There are 10 memory locations (M0 to M9). When storing or viewing data, this indicator will show the memory location being utilized.

C. Battery Icon: Indicates the rechargeable battery's power level.

D. Electrostatic Field Voltage: Displays the measured voltage in volts (V) or kilovolts (kV).

E. Mode Icon: Indicates the mode of operation. A gauge icon indicates Measure Mode. A notepad icon indicates Memory Mode.

F. Distance Indicator: Displays the distance between the meter's sensor and targeted object. This information is used to calculate the electrostatic field voltage. The meter's distance range is 1 to 200 mm.

G. ON/MEASURE Button: Short press powers the meter ON and sets it to Measure Mode. Short press while in Measure Mode to toggle the meter between Standard Mode and Conductive Plate Mode (CPM). Use Conductive Plate Mode when the Conductive Plate is installed onto the meter. Use Standard Mode otherwise. Long press powers the meter OFF.

H. MEMORY Button: Short press sets the meter to Memory Mode. Long press while in Measure Mode stores the displayed measurement into the displayed memory location.

I. USB-C Port: Use the included USB-C cable to charge the battery and download data from the meter's memory.

J. Output Contact: The output contact is connected to an internal power source. When the touch plate located underneath the unit is connected to ground, the output contact will provide a charge of the indicated polarity. The charger is designed so that an operator can press the rocker switch and touch the plate simultaneously with the fingers of the same hand.

K. Rocker Switch: Press and hold to select the polarity that will be provided at the Output Contact.

L. Touch Plate: Make contact with the touch plate while pressing down the rocker switch to provide voltage to the Output Contact. The operator must be properly grounded during use.

M. Battery Compartment: Slide the cover down to open the 9 V battery compartment.

CHARGER




Figure 6. Charger features and components

Operation

STATIC FIELD METER

Setting the Date and Time

The Static Field Meter can store up to 10 measurements in memory, each time and date stamped for downloading via the USB-C port.

To access the Date and Time screen, short press both the ON/MEASURE and MEMORY buttons at the same time. Once in the Date and Time screen, use the MEMORY button to navigate through the values and change them. Long press the MEMORY button to advance the cursor. Short press the MEMORY button to increment the highlighted digit. Short press the ON/MEASURE button at any time to save the settings and return to Measure Mode.

Grounding

The Static Field Meter's enclosure is conductive. The instrument senses the difference in potential between the enclosure and the tested surface. The meter must be grounded by the hand of a grounded operator to achieve accurate measurements. Manual zeroing is not required.

Performing a Measurement

The Static Field Meter incorporates an advanced Time-of-Flight (ToF) distance sensor. This technology uses invisible, eye-safe laser pulses to precisely measure the distance to a target. This allows the firmware to automatically adjust the voltage measurement and ensure accurate readings across a dynamic range of 1 to 200 mm. Measurements are no longer limited to a fixed 1-inch (25 mm) distance.

The measurement accuracy depends on both a stable ground reference and the aspect ratio between the size of the measured object and the measurement distance. For best accuracy, the aspect ratio should be at least 4:1 — meaning the measured surface should be at least a 4-inch (102 mm) square when measuring from a 1-inch (25 mm) distance. Measuring an object smaller than the recommended 4:1 aspect ratio will result in a lower reading on the meter.



Figure 7. Using the Static Field Meter to measure foam

Snapshot Hold

When measuring, quickly pull or flick the meter away from the object. The last measurement will remain on the screen as long as the meter is not pointed at another measurable object within 200 mm (8 inches). This allows time to read the measurement and store it into memory if desired.

Memory Mode

The Static Field Meter stores up to 10 measurements in memory. Short press the MEMORY button to enter Memory Mode. The Mode Icon will change to a notepad to indicate Memory Mode. While in Memory Mode, short press the MEMORY button to toggle through the 10 memory locations. Set the desired memory location for the next stored measurement to save. Long press the MEMORY button, and the meter will clear the selected memory location. Short press the ON/MEASURE button to return to Measure Mode.

Downloading Stored Measurements

Use a USB-C cable to connect the Static Field Meter to a Windows PC. Press the ON/MEASURE button to power the meter ON.



Figure 8. Connecting the USB-C cable to the Static Field Meter

The meter will appear as a USB serial device, and Windows will assign it a COM port (e.g. COM5). To find the COM port number, open Windows Device Manager. Look under “Ports (COM & LPT)” to find the USB Serial Device.




Figure 9. Locating the Static Field Meter in Windows Device Manager

Open a serial terminal application of choice. Examples include PuTTY, Tera Term, and MobaXterm. The following screenshots are for PuTTY.

Configure the connection settings as follows:

- **Connection Type:** Serial
- **Serial Line:** The COM port from the prior step
- **Speed (Baud Rate):** 115200




Figure 10. Session settings using PuTTY

For correct output visibility, click the Terminal settings and enable "Implicit CR in every LF". Click the Open button to establish the connection.




Figure 11. Terminal settings using PuTTY

Use the keyboard to type "m" into the terminal. The meter's 10 values stored in memory will appear on the display. This text may then be copied and pasted into another document. Memory locations without measurements will appear as 0 V, 0 mm.




Figure 12. Downloading stored measurements

IONIZATION TEST KIT

The Ionization Test Kit is designed to match the compact size of the Static Field Meter. Use the following procedures to verify the offset voltage (balance) and discharge times of air ionization equipment. They will help determine if the ionizer is working within the manufacturer's specifications or user requirements. It is important that ionizers be checked regularly for offset voltage (balance) and discharge times. An ionizer operating in an out-of-balance state can place a charge on sensitive electronic components or assemblies.

Installing the Conductive Plate

The Static Field Meter's case has two slots along its sides. The top slot is closest to the face of the instrument. Slide down the tabs of the Conductive Plate into the top slot of the Static Field Meter's case as far as they go. Short press the ON/MEASURE button to configure the meter to Conductive Plate Mode. This mode is indicated when "CPM" is displayed on the bottom right corner.



Figure 13. Sliding the Conductive Plate onto the Static Field Meter

Performing Offset Voltage (Balance) Measurements

While grounded, hold the Static Field Meter so the ionized airflow touches the top of the Conductive Plate at the appropriate distance from the device under test. The Static Field Meter will display the offset voltage (balance).



Figure 14. Measuring the offset voltage (balance) of an ionizer with the Ionization Test Kit

Performing Discharge Time Measurements

Use the Charger to apply both positive and negative charges onto the Conductive Plate, so discharge time measurements can be performed. Follow the procedures listed below. The operator and Static Field Meter must be properly grounded for the Charger to work properly.

Positive Discharge Time Measurements

Position the Static Field Meter with Conductive Plate in the airflow of the ionizer. To provide a POSITIVE voltage output, touch the metal button located on the backside of the Charger, and rock the switch towards the + symbol at the same time. Momentarily touch the Charger's output terminal to the Conductive Plate attached to the Static Field Meter. The Static Field Meter will display a voltage greater than +1.00 kV. Use a stop watch to estimate the time needed for the voltages to decrease from +1.00 kV to +100 kV. This is considered the positive discharge time.



Figure 15. Using the Charger to apply a positive charge onto the Conductive Plate

Negative Discharge Time Measurements

Position the Static Field Meter with Conductive Plate in the airflow of the ionizer. To provide a NEGATIVE voltage output, touch the metal button located on the backside of the Charger, and rock the switch towards the - symbol at the same time. Momentarily touch the Charger's output terminal to the Conductive Plate attached to the Static Field Meter. The Static Field Meter will display a voltage greater than -1.00 kV. Use a stop watch to estimate the time needed for the voltages to decrease from -1.00 kV to -100 kV. This is considered the negative discharge time.

Maintenance

The Static Field Meter is factory calibrated and no maintenance is required. Contact Desco Customer Service should the product behave abnormally. Any unauthorized service will void the warranty and result in additional repair charges.

NOTE: This Static Field Meter is a precision instrument and should not be subjected to dropping as that would void the warranty.

Batteries

The Static Field Meter operates using a lithium-ion battery. The battery can be recharged 300 to 500 times before noticeable performance degradation. The battery is accessible and replaceable if necessary. Battery life is more than 20 hours under normal use. The meter has a battery indicator. To recharge the battery, connect the meter to any standard USB-C charger or laptop via a USB-C cable.

The battery in the Charger should be replaced annually or when it is unable to provide approximately $\pm 1100V$. Always replace the batteries with a 9 V alkaline battery.

Cleaning

The area around the aperture of the Static Field Meter must be kept clean to ensure accurate, drift-free readings. Never touch the aperture. Use low-pressure instrument-grade air to remove dust or other debris. To remove more severe contamination, spray or flush with the smallest practical amount of clean technical-grade of isopropyl alcohol. Allow the instrument to air dry for several hours afterward.

Keep the insulators on the Conductive Plate clean and free of contaminants that may cause surface leakage. To test the performance of the Conductive Plate, charge the plate and note the discharge rate in a non-ionized area. The self discharge rate to 10% of original voltage should be greater than five minutes.

Calibration

Functionality of the Static Field Meter may be verified using a calibrated Charge Plate Monitor (CPM). Utilizing the CPM controls, apply approximately 1,000 volts to the charge plate and position the static meter approximately 25 mm (1 inch) away from the plate. The meter should read the applied voltage $\pm 5\%$. A significant difference in reading indicates that the Static Meter is out of calibration and it should be returned to Desco for repair and/or calibration.

Specifications

STATIC FIELD METER

Display	OLED display, 128 x 64
Ports	USB-C supports USB 2.0 and USB 3.1
Battery	Lithium-Ion 1080 Mah, 3.7 V, 3.99 Wh. UN 38.3 certified
Battery Life	Approximately 60 hours of continuous operation
Size	2.4" W x 4.2" L x 1.3" D (61 x 107 x 33 mm)
Weight	4 oz. (109 g) with battery
Operating Conditions	Operates at 0 to 50° C and 0 to 85% RH (non-condensing). Accuracy unaffected by air ionization.
Measurement Range	-40.0 kV to +40.0 kV
Distance Range	1 to 200 mm
Resolution	1 V for 0 to 999 V, 10 V for 1.00 kV to 9.99 kV, 100 V for 10.0 kV and above
Accuracy	$\pm 5\%$
Country of Origin	United States of America

IONIZATION TEST KIT

Conductive plate Assembly	Aluminum bracket, bare aluminum plate and teflon spacers isolate plate from bracket
Voltage Output	1/10,000 of measured voltage
Conductive plate Area	2.95" W x 1.18" L (7.5 x 3.0 cm)
Conductive plate Assembly Weight	2.4 oz. (68 g)
Charger Dimensions	1.1" H x 2.6" W x 4.5" L (2.8 x 6.6 x 11.4 cm)
Charger Weight	5 oz. (140 g) with battery
Charger Power Requirements	One 9-volt alkaline battery
Charger Output (using Static Sensor with conductive plate)	1.1 kV minimum for \pm voltage
Country of Origin	United States of America

Limited Warranty, Warranty Exclusions, Limit of Liability and RMA Request Instructions

See the Desco Warranty - [Desco.com/Limited-Warranty.aspx](https://www.desco.com/Limited-Warranty.aspx)