

# Technical Reference



## DPO3000 Series Digital Phosphor Oscilloscopes Specifications and Performance Verification

**071-2423-01**

The Tequipment.net logo features a large red "T" on the left. To its right is a small American flag with the word "USA" in blue. Below the "T" and the flag, the word "equipment" is written in blue, and ".net" is written in red. A blue horizontal line is positioned below "equipment".

205 Westwood Ave  
Long Branch, NJ 07740  
1-877-742-TEST (8378)  
Fax: (732) 222-7088  
E-mail: [salesteam@Tequipment.NET](mailto:salesteam@Tequipment.NET)

This document supports firmware version 1.00 and above for DPO3000 Series instruments.

### **Warning**

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supercedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX, TEK, and TekVPI are registered trademarks of Tektronix, Inc.

Tektronix is an authorized licensee of the CompactFlash® trademark.

## **Contacting Tektronix**

Tektronix, Inc.  
14200 SW Karl Braun Drive  
P.O. Box 500  
Beaverton, OR 97077  
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit [www.tektronix.com](http://www.tektronix.com) to find contacts in your area.

# Table of Contents

<b>General Safety Summary</b> .....	<b>iii</b>
<b>Specifications</b> .....	<b>1-1</b>
<b>Performance Verification</b> .....	<b>2-1</b>
Upgrade the Firmware .....	2-2
Test Record .....	2-3
Performance Verification Procedures .....	2-17

## List of Tables

<b>Table 1-1: Analog channel input and vertical specifications</b> .....	<b>1-1</b>
<b>Table 1-2: Horizontal and acquisition system specifications</b> .....	<b>1-7</b>
<b>Table 1-3: Sample rate range detail</b> .....	<b>1-8</b>
<b>Table 1-4: Trigger specifications</b> .....	<b>1-9</b>
<b>Table 1-5: Display specifications</b> .....	<b>1-15</b>
<b>Table 1-6: Input/Output port specifications</b> .....	<b>1-15</b>
<b>Table 1-7: Power source specifications</b> .....	<b>1-16</b>
<b>Table 1-8: Data storage specifications</b> .....	<b>1-16</b>
<b>Table 1-9: Environmental specifications</b> .....	<b>1-16</b>
<b>Table 1-10: Mechanical specifications</b> .....	<b>1-17</b>
<b>Table 1-11: Safety certification</b> .....	<b>1-18</b>
<b>Table 1-12: Electromagnetic compatibility (EMC)</b> .....	<b>1-18</b>
<b>Table 2-1: Maximum Bandwidth Frequency worksheet</b> .....	<b>2-22</b>
<b>Table 2-2: Gain Expected worksheet</b> .....	<b>2-24</b>



# General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it.

To avoid potential hazards, use this product only as specified.

*Only qualified personnel should perform service procedures.*

## To Avoid Fire or Personal Injury

**Use Proper Power Cord.** Use only the power cord specified for this product and certified for the country of use.

**Connect and Disconnect Properly.** Do not connect or disconnect probes or test leads while they are connected to a voltage source.

**Ground the Product.** This product is grounded through the grounding conductor of the power cord. To avoid electric shock, the grounding conductor must be connected to earth ground. Before making connections to the input or output terminals of the product, ensure that the product is properly grounded.

**Observe All Terminal Ratings.** To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product.

Connect the probe reference lead to earth ground only.

Do not apply a potential to any terminal, including the common terminal, that exceeds the maximum rating of that terminal.

**Power Disconnect.** The power cord disconnects the product from the power source. Do not block the power cord; it must remain accessible to the user at all times.

**Do Not Operate Without Covers.** Do not operate this product with covers or panels removed.

**Do Not Operate With Suspected Failures.** If you suspect there is damage to this product, have it inspected by qualified service personnel.

**Avoid Exposed Circuitry.** Do not touch exposed connections and components when power is present.

**Do Not Operate in Wet/Damp Conditions.**

**Do Not Operate in an Explosive Atmosphere.**

**Keep Product Surfaces Clean and Dry.**

**Provide Proper Ventilation.** Refer to the manual's installation instructions for details on installing the product so it has proper ventilation.

**Terms in this Manual**

These terms may appear in this manual:



---

**WARNING.** *Warning statements identify conditions or practices that could result in injury or loss of life.*

---



---

**CAUTION.** *Caution statements identify conditions or practices that could result in damage to this product or other property.*

---

**Symbols and Terms on the Product**

These terms may appear on the product:

- DANGER indicates an injury hazard immediately accessible as you read the marking.
- WARNING indicates an injury hazard not immediately accessible as you read the marking.
- CAUTION indicates a hazard to property including the product.

The following symbols may appear on the product:



# Specifications

This chapter contains specifications for the DPO3000 series oscilloscopes. All specifications are guaranteed unless noted as “typical.” Typical specifications are provided for your convenience but are not guaranteed. Specifications that are marked with the ✓ symbol are checked in *Performance Verification*.

All specifications apply to all DPO3000 models unless noted otherwise. To meet specifications, two conditions must first be met:

- The oscilloscope must have been operating continuously for twenty minutes within the operating temperature range specified.
- You must perform the Signal Path Compensation (SPC) operation described in the *DPO3000 Series Digital Phosphor Oscilloscopes User Manual* prior to evaluating specifications. If the operating temperature changes by more than 10 °C (18 °F), you must perform the SPC operation again.

**Table 1-1: Analog channel input and vertical specifications**

Characteristic	Description
Number of input channels	<i>DPO3052, DPO3032, DPO3012</i>   <i>DPO3054, DPO3034, DPO3014</i>
	2 analog, digitized simultaneously   4 analog, digitized simultaneously
Input coupling	DC, AC, or GND  GND coupling approximates ground reference by measuring the CVR output set to GND. The signal being measured on the BNC is not disconnected from the channel's input load.
Input resistance selection	1 MΩ, 50 Ω, or 75 Ω
✓ Input impedance, DC coupled	1 MΩ ±1% in parallel with 11.5 pF ±2 pF  50 Ω ±1% DPO305x: VSWR ≤ 1.5:1 from DC to 500 MHz, typical DPO303x: VSWR ≤ 1.5:1 from DC to 350 MHz, typical DPO301x: VSWR ≤ 1.5:1 from DC to 100 MHz, typical  75 Ω ±1% All models: ≤1.3:1 From DC to 60 MHz, typical

**Table 1- 1: Analog channel input and vertical specifications (Cont.)**

Characteristic	Description
Maximum input voltage (50 $\Omega$ and 75 $\Omega$ )	5 V <sub>RMS</sub> with peaks $\leq \pm 20$ V
Maximum input voltage (1 M $\Omega$ )	At front panel connector, 300 V <sub>RMS</sub> , Installation Category II; Apply UL specified voltages for 300 V CAT II
<100mV/div	Derate at 20 dB/decade above 100 kHz to 30 V <sub>RMS</sub> at 1 MHz, 10 dB/decade above 1 MHz
$\geq 100$ mV/div	Derate at 20 dB/decade above 3 MHz to 30 V <sub>RMS</sub> at 30 MHz, 10 dB/decade above 30 MHz
✓ DC Balance	<p>0.2 div with the input DC-50 <math>\Omega</math> coupled and 50 <math>\Omega</math> terminated</p> <p>0.25 div at 2 mV/div with the input DC-50 <math>\Omega</math> coupled and 50 <math>\Omega</math> terminated</p> <p>0.5 div at 1 mV/div with the input DC-50 <math>\Omega</math> coupled and 50 <math>\Omega</math> terminated</p> <p>0.2 div with the input DC-75 <math>\Omega</math> coupled and 75 <math>\Omega</math> terminated</p> <p>0.25 div at 2mV/div with the input DC-75 <math>\Omega</math> coupled and 75 <math>\Omega</math> terminated</p> <p>0.5 div at 1mV/div with input DC-75 <math>\Omega</math> coupled and 75 <math>\Omega</math> terminated</p> <p>0.2 div with the input DC-1 M<math>\Omega</math> coupled and 50 <math>\Omega</math> terminated</p> <p>0.3 div at 1 mV/div with the input DC-1 M<math>\Omega</math> coupled and 50 <math>\Omega</math> terminated</p>
Delay between channels, full bandwidth, typical	<p><math>\leq 100</math> ps between any two channels with input impedance set to 50 <math>\Omega</math>, DC coupling</p> <p><math>\leq 100</math> ps between any two channels with input impedance set to 75 <math>\Omega</math>, DC coupling</p> <p>Note: all settings in the instrument can be manually time aligned using the Probe Deskew function from -100 ns to +100 ns with a resolution of 20 ps</p>
Deskew range	-100 ns to +100 ns with a resolution of 20 ps
Crosstalk (channel isolation), typical	$\geq 100:1$ at $\leq 100$ MHz and $\geq 30:1$ at $>100$ MHz up to the rated bandwidth for any two channels having equal Volts/Div settings



**Table 1-1: Analog channel input and vertical specifications (Cont.)**

Characteristic	Description									
TekVPI Interface	<p>The probe interface allows installing, powering, compensating, and controlling a wide range of probes offering a variety of features</p> <p>The interface is available on all front panel inputs including Aux In. Aux In only provides 1 M<math>\Omega</math> input impedance and does not offer 50 <math>\Omega</math> or 75 <math>\Omega</math> as do the other input channels</p>									
Total probe power	<p>Three (DPO30x2) or five (DPO30x4) TekVPI compliant probe interfaces, 1 per channel</p> <p>20 W Internally available probe power</p> <p>Provision for 50 W external power from rear panel</p>									
Probe power per channel	<table border="1"> <thead> <tr> <th>Voltage</th> <th>Max Amperage</th> <th>Voltage Tolerance</th> </tr> </thead> <tbody> <tr> <td>5 V</td> <td>50 mA (250 mW)</td> <td><math>\pm 5\%</math></td> </tr> <tr> <td>12 V</td> <td>2 A (24 W)</td> <td><math>\pm 10\%</math></td> </tr> </tbody> </table>	Voltage	Max Amperage	Voltage Tolerance	5 V	50 mA (250 mW)	$\pm 5\%$	12 V	2 A (24 W)	$\pm 10\%$
	Voltage	Max Amperage	Voltage Tolerance							
	5 V	50 mA (250 mW)	$\pm 5\%$							
12 V	2 A (24 W)	$\pm 10\%$								
Number of digitized bits	<p>8 bits</p> <p>Displayed vertically with 25 digitization levels (DL) per division, 10.24 divisions dynamic range</p> <p>“DL” is the abbreviation for “digitization level.” A DL is the smallest voltage level change that can be resolved by an 8-bit A-D Converter. This value is also known as the LSB (least significant bit)</p>									
Sensitivity range (coarse)	<table border="1"> <thead> <tr> <th>1 M<math>\Omega</math></th> <th>50 <math>\Omega</math> and 75 <math>\Omega</math></th> </tr> </thead> <tbody> <tr> <td>1 mV/div to 10 V/div in a 1-2-5 sequence</td> <td>1 mV/div to 1 V/div in a 1-2-5 sequence</td> </tr> </tbody> </table>	1 M $\Omega$	50 $\Omega$ and 75 $\Omega$	1 mV/div to 10 V/div in a 1-2-5 sequence	1 mV/div to 1 V/div in a 1-2-5 sequence					
	1 M $\Omega$	50 $\Omega$ and 75 $\Omega$								
1 mV/div to 10 V/div in a 1-2-5 sequence	1 mV/div to 1 V/div in a 1-2-5 sequence									
Sensitivity range (fine)	<p>1 mV/div to 5 V/div: &lt;-50% to &gt;+50% of selected setting, 1 M<math>\Omega</math> 10 V/div: &lt;-50% to 0%, 1 M<math>\Omega</math></p> <p>1 mV/div to 500 mV/div: &lt;-50% to &gt;+50% of selected setting, 50 <math>\Omega</math> 1 V/div: &lt;-50% to 0%, 50 <math>\Omega</math></p> <p>1 mV/div to 500 mV/div: &lt;-50% to &gt;+50% of selected setting, 75 <math>\Omega</math> 1 V/div: &lt;-50% to 0%, 75 <math>\Omega</math></p> <p>Allows continuous adjustment from 1 mV/div to 10 V/div, 1 M<math>\Omega</math> Allows continuous adjustment from 1 mV/div to 1 V/div, 50 <math>\Omega</math> Allows continuous adjustment from 1 mV/div to 1 V/div, 75 <math>\Omega</math></p>									
Sensitivity resolution (fine), typical	$\leq 1\%$ of current setting									
Position range	$\pm 5$ divisions									

**Table 1-1: Analog channel input and vertical specifications (Cont.)**

Characteristic	Description				
✓ Analog bandwidth, 50 Ω	The limits stated below are for ambient temperature of ≤30 °C and the bandwidth selection set to FULL. Reduce the upper bandwidth frequency by 1% for each °C above 30 °C.				
	<i>Instrument</i>	10 mV/div to 1 V/div	5 mV/div to 9.98 mV/div	2 mV/div to 4.98 mV/div	1 mV/div to 1.99 mV/div
	DPO305x	DC to 500 MHz	DC to 400 MHz	DC to 250 MHz	DC to 150 MHz
	DPO303x	DC to 300 MHz		DC to 250 MHz	DC to 150 MHz
	DPO301x	DC to 100 MHz			
Analog bandwidth, 75 Ω, typical	The limits stated below are for ambient temperature of ≤30 °C and the bandwidth selection set to FULL. Reduce the upper bandwidth frequency by 1% for each °C above 30 °C.				
	<i>Model</i>	10 mV/div to 1 V/div	5 mV/div to 9.98 mV/div	2 mV/div to 4.98 mV/div	1 mV/div to 1.99 mV/div
	DPO305x	DC to 230 MHz	DC to 190 MHz	DC to 140 MHz	DC to 100 MHz
	DPO303x	DC to 250 MHz			
	DPO301x	DC to 100 MHz			
Analog bandwidth, 1 MΩ with P6139A 10X Probe, typical	The limits stated below are for ambient temperature of ≤30 °C and the bandwidth selection set to FULL. Reduce the upper bandwidth frequency by 1% for each °C above 30 °C.				
	<i>Model</i>	100 mV/div to 100 V/div	50 mV/div to 99.8 mV/div	20 mV/div to 49.8 mV/div	10 mV/div to 19.9 mV/div
	DPO305x	DC to 500 MHz	DC to 400 MHz	DC to 250 MHz	DC to 150 MHz
	DPO303x	DC to 300 MHz		DC to 250 MHz	DC to 150 MHz
	DPO301x	DC to 100 MHz			

**Table 1-1: Analog channel input and vertical specifications (Cont.)**

Characteristic	Description				
Calculated rise time, typical	The formula is calculated by measuring -3 dB bandwidth of the oscilloscope. The formula accounts for the rise time contribution of the oscilloscope independent of the rise time of the signal source.				
	<i>Model</i>	50 Ω: 1 mV/div to 1.99 mV/ div	50 Ω: 2 mV/div to 4.99 mV/ div	50 Ω: 5 mV/div to 5.98 mV/ div	50 Ω: 10 mV/ div to 1 V/div
	DPO305x	2 ns	1.2 ns	750 ps	700 ps
	DPO303x	2 ns	1.2 ns		
	DPO301x	3.5 ns			
	<i>Model</i>	75 Ω: 1 mV/div to 1.99 mV/ div	75 Ω: 2 mV/div to 4.98 mV/ div	75 Ω: 5 mV/div to 9.95 mV/ div	75 Ω: 10 mV/ div to 1 V/div
	DPO305x	3 ns	2.1 ns	1.6 ns	1.2 ns
	DPO303x	3 ns	2.1 ns	1.6 ns	1.2 ns
	DPO301x	3.5 ns			
	<i>Model</i>	1 MΩ: (P6139A probe): 1 mV/div to 1.99 mV/ div	1 MΩ: (P6139A probe): 2 mV/div to 4.98 mV/ div	1 MΩ: 5 mV/div to 9.95 mV/ div	1 MΩ: 10 mV/ div to 1 V/div
	DPO305x	2 ns	1.2 ns	750 ps	700 ps
	DPO303x	2 ns	1.2 ns		
	DPO301x	3.5 ns			
Analog bandwidth selections	20 MHz, 150 MHz and Full (all models)				
Lower frequency limit, AC coupled, typical	< 10 Hz when AC to 1 MΩ coupled  The AC coupled lower frequency limits are reduced by a factor of 10 when 10X passive probes are used.				
Upper frequency limit, 150 MHz bandwidth limited, typical	150 MHz, ±20% (all models)				
Upper frequency limit, 20 MHz bandwidth limited, typical	20 MHz, ±35% (all models)				

**Table 1- 1: Analog channel input and vertical specifications (Cont.)**

Characteristic	Description			
✓ DC gain accuracy	$\pm 2.5\%$ for 1 mV/Div, derated at 0.100%/°C above 30 °C $\pm 2.0\%$ for 2 mV/Div, derated at 0.100%/°C above 30 °C $\pm 1.5\%$ for 5 mV/Div, derated at 0.100%/°C above 30 °C $\pm 3.0\%$ Variable Gain, derated at 0.100%/°C above 30 °C			
DC voltage measurement accuracy	<i>Measurement type</i>	<i>DC Accuracy (in volts)</i>		
	Sample acquisition mode, typical	$\pm[\text{DC gain accuracy} \times  \text{reading} - (\text{offset} - \text{position})  + \text{Offset Accuracy} + 0.15 \text{ div} + 0.6 \text{ mV}]$		
	Delta volts between any two samples acquired with the same oscilloscope setup and ambient conditions	$\pm[\text{DC gain accuracy} \times  \text{reading}  + 0.15 \text{ div} + 1.2 \text{ mV}]$		
Average acquisition mode	Note: Offset, position, and the constant offset term must be converted to volts by multiplying by the appropriate volts/div term.			
	Average of $\geq 16$ waveforms	$\pm[\text{DC gain accuracy} \times  \text{reading} - (\text{offset} - \text{position})  + \text{Offset Accuracy} + 0.1 \text{ div}]$		
	Delta Volts between any two averages of $\geq 16$ waveforms acquired with the same oscilloscope setup and ambient conditions	$\pm[\text{DC gain accuracy} \times  \text{reading}  + 0.05 \text{ div}]$		
Note: Offset, position, and the constant offset term must be converted to volts by multiplying by the appropriate volts/div term.  The basic accuracy specification applies directly to any sample and to the following measurements: High, Low, Max, Min, Mean, Cycle Mean, RMS, and Cycle RMS. The delta volt accuracy specification applies to subtractive calculations involving two of these measurements.  The delta volts (difference voltage) accuracy specification applies directly to the following measurements: Positive Overshoot, Negative Overshoot, Pk-Pk, and Amplitude.				
Offset ranges	<i>Volts/div setting</i>	<i>Offset range</i>		
		<table border="1"> <tr> <td><i>1 MΩ input</i></td> <td><i>50 Ω and 75 Ω input</i></td> </tr> </table>	<i>1 MΩ input</i>	<i>50 Ω and 75 Ω input</i>
	<i>1 MΩ input</i>	<i>50 Ω and 75 Ω input</i>		
	1 mV/div to 99.5 mV/div	<table border="1"> <tr> <td><math>\pm 1 \text{ V}</math></td> <td><math>\pm 1 \text{ V}</math></td> </tr> </table>	$\pm 1 \text{ V}$	$\pm 1 \text{ V}$
	$\pm 1 \text{ V}$	$\pm 1 \text{ V}$		
100 mV/div to 995 mV/div	<table border="1"> <tr> <td><math>\pm 10 \text{ V}</math></td> <td><math>\pm 5 \text{ V}</math></td> </tr> </table>	$\pm 10 \text{ V}$	$\pm 5 \text{ V}$	
$\pm 10 \text{ V}$	$\pm 5 \text{ V}$			
1 V/div to 10 V/div <sup>1</sup>	<table border="1"> <tr> <td><math>\pm 100 \text{ V}</math></td> <td><math>\pm 5 \text{ V}</math></td> </tr> </table>	$\pm 100 \text{ V}$	$\pm 5 \text{ V}$	
$\pm 100 \text{ V}$	$\pm 5 \text{ V}$			
Input Signal cannot exceed Max Input Voltage for the 50 Ω input path. Refer to the Max Input Voltage specification for more information.				

**Table 1-1: Analog channel input and vertical specifications (Cont.)**

Characteristic	Description
Offset accuracy	$\pm[0.005 \times  \text{offset} - \text{position}  + \text{DC Balance}]$ Note: Both the position and constant offset term must be converted to volts by multiplying by the appropriate volts/div term.

<sup>1</sup> For 50  $\Omega$  path, 1 V/div is the maximum vertical setting.

**Table 1-2: Horizontal and acquisition system specifications**

Characteristic	Description
✓ Long-term sample rate and delay time accuracy	$\pm 10$ ppm over any $\geq 1$ ms time interval
Seconds/Division range	1 ns/div to 1000 s/div
Peak Detect or Envelope mode pulse response, typical	<i>Minimum pulse width</i> DPO305x: > 2.0 ns DPO303x: > 2.9 ns DPO301x: > 6.7 ns
Sample-rate range	See Table 1-3 for details
Record length range	5 M, 1 M, 100 k, 10 k, 1 k
Waveform Capture rate	Maximum triggered acquisition rate: 50,000 wfm/s
Aperture Uncertainty, typical	$\leq (3 \text{ ps} + 0.1 \text{ ppm} \times \text{record duration})_{\text{RMS}}$ , for records having duration $\leq 1$ minute
Number of Waveforms for Average Acquisition Mode	2 to 512 waveforms Default of 16 waveforms

**Table 1-3: Sample rate range detail**

Characteristic	Description					
	Time/Div	5 M record	1 M record	100 K record	10 K record	1 K record
Sample rate range	1 ns	2.5 GS/s				
	2 ns	2.5 GS/s				
	4 ns	2.5 GS/s				
	10 ns	2.5 GS/s				
	20 ns	2.5 GS/s				
	40 ns	2.5 GS/s				
	80 ns					1.25 GS/s
	100 ns	2.5 GS/s				
	200 ns	2.5 GS/s				500 MS/s
	400 ns	2.5 GS/s				250 MS/s
	800 ns				1.25 GS/s	
	1 μs	2.5 GS/s				100 MS/s
	2 μs	2.5 GS/s			500 MS/s	50 MS/s
	4 μs	2.5 GS/s			250 MS/s	25 MS/s
	8 μs			1.25 GS/s		
	10 μs	2.5 GS/s			100 MS/s	10 MS/s
	20 μs	2.5 GS/s		500 MS/s	50 MS/s	5 MS/s
	40 μs	2.5 GS/s		250 MS/s	25 MS/s	2.5 MS/s
	80 μs		1.25 GS/s			
	100 μs	2.5 GS/s		100 MS/s	10 MS/s	1 MS/s
	200 μs	2.5 GS/s	500 MS/s	50 MS/s	5 MS/s	500 KS/s
	400 μs	2.5 GS/s	250 MS/s	25 MS/s	2.5 MS/s	250 KS/s
	800 μs	1.25 GS/s				
	1 ms		100 MS/s	10 MS/s	1 MS/s	100 KS/s
	2 ms	250 MS/s	50 MS/s	5 MS/s	500 KS/s	50 KS/s
	4 ms	100 MS/s	25 MS/s	2.5 MS/s	250 KS/s	25 KS/s
10 ms	100 MS/s	10 MS/s	1 MS/s	100 KS/s	10 KS/s	
20 ms	25 MS/s	5 MS/s	500 KS/s	50 KS/s	5 KS/s	

**Table 1-3: Sample rate range detail (Cont.)**

Characteristic	Description					
	Time/Div	5 M record	1 M record	100 K record	10 K record	1 K record
Sample rate range (Cont.)	40 ms	10 MS/s	2.5 MS/s	250 KS/s	25 KS/s	2.5 KS/s
	100 ms	5 MS/s	1 MS/s	100 KS/s	10 KS/s	1 KS/s
	200 ms	2.5 MS/s	500 KS/s	50 KS/s	5 KS/s	500 S/s
	400 ms	1 MS/s	250 KS/s	25 KS/s	2.5 KS/s	250 S/s
	1 s	500 KS/s	100 KS/s	10 KS/s	1 KS/s	100 S/s
	2 s	250 KS/s	50 KS/s	5 KS/s	500 S/s	50 S/s
	4 s	100 KS/s	25 KS/s	2.5 KS/s	250 S/s	25 S/s
	10 s	50 KS/s	10 KS/s	1 KS/s	100 S/s	10 S/s
	20 s	25 KS/s	5 KS/s	500 S/s	50 S/s	5 S/s
	40 s	10 KS/s	2.5 KS/s	250 S/s	25 S/s	2.5 S/s
	100 s	5 KS/s	1 KS/s	100 S/s	10 S/s	
	200 s	2.5 KS/s	500 S/s	50 S/s	5 S/s	
	400 s	1 KS/s	250 S/s	25 S/s	2.5 S/s	
	1000 s	500 S/s	100 S/s	10 S/s		

**Table 1-4: Trigger specifications**

Characteristic	Description	
Aux In (External) trigger maximum input voltage	At front panel connector, 300 V <sub>RMS</sub> , Installation Category II; derate at 20 dB/decade above 3 MHz to 30 V <sub>RMS</sub> at 30 MHz, 10 dB/decade above 30 MHz	
Aux In (External) trigger input impedance, typical	1 M $\Omega$ $\pm$ 1% in parallel with 10 pF $\pm$ 2 pF	
Aux In (External) trigger bandwidth, typical	>200 MHz	
Trigger bandwidth, Edge, Pulse, and Logic, typical	DPO305x: 500 MHz DPO303x: 300 MHz DPO301x: 100 MHz	
Time accuracy for Pulse, Glitch, or Width triggering	<i>Time range</i>	<i>Accuracy</i>
	1 ns to 500 ns	$\pm$ (20% of setting + 0.5 ns)
	520 ns to 1 s	$\pm$ (0.01% of setting + 100 ns)

**Table 1-4: Trigger specifications (Cont.)**

<b>Characteristic</b>	<b>Description</b>	
Edge-type trigger sensitivity, DC coupled, typical	<i>Trigger Source</i>	
	Any input channel	<i>Sensitivity</i> 0.50 div from DC to 50 MHz, increasing to 1 div at oscilloscope bandwidth
	Aux in (External)	200 mV from DC to 50 MHz, increasing to 500 mV at 250 MHz
	Line	Fixed
Edge trigger sensitivity, not DC coupled, typical	<i>Trigger Coupling</i>	
	AC	<i>Typical Sensitivity</i> 1.5 times the DC Coupled limits for frequencies above 10 Hz. Attenuates signals below 10 Hz
	NOISE REJ	2.5 times the DC-coupled limits
	HF REJ	1.5 times the DC-coupled limit from DC to 50 kHz. Attenuates signals above 50 kHz
	LF REJ	1.5 times the DC-coupled limits for frequencies above 50 kHz. Attenuates signals below 50 kHz
Trigger level ranges	<i>Source</i>	
	Any input channel	<i>Sensitivity</i> ±8 divisions from center of screen, ±8 divisions from 0 V when vertical LF reject trigger coupling is selected
	Aux In (External)	±8 V
	Line	Not applicable
	The line trigger level is fixed at about 50% of the line voltage.	
	This specification applies to logic and pulse thresholds.	
Lowest frequency for successful operation of "Set Level to 50%" function, typical	45 Hz	
Trigger level accuracy, DC coupled typical	For signals having rise and fall times $\geq 10$ ns, the limits are as follows:	
	<i>Source</i>	<i>Range</i>
	Any channel	±0.20 divisions
	Aux In (external trigger)	±(10% of setting + 25 mV)
	Line	Not applicable
Trigger holdoff range	20 ns minimum to 8 s maximum	



**Table 1-4: Trigger specifications (Cont.)**

Characteristic	Description			
Video-type trigger sensitivity, typical	The limits for both delayed and main trigger are as follows:			
	<i>Source</i>		<i>Sensitivity</i>	
	Any input channel		0.6 to 2.5 divisions of video sync tip	
	Aux In (External)		Video not supported through Aux In (External) input	
Video-type trigger formats and field rates	Triggers from negative sync composite video, field 1 or field 2 for interlaced systems, on any field, specific line, or any line for interlaced or non-interlaced systems. Supported systems include NTSC, PAL, and SECAM.			
Logic-type or logic qualified trigger or events-delay sensitivities, DC coupled, typical	1.0 division from DC to maximum bandwidth			
Pulse-type runt trigger sensitivities, typical	1.0 division from DC to maximum bandwidth			
Pulse-type trigger width and glitch sensitivities, typical	1.0 division			
Logic-type triggering, minimum logic or rearm time, typical	For all vertical settings, the minimums are:			
	<i>Trigger type</i>	<i>Minimum pulse width</i>	<i>Minimum re-arm time</i>	<i>Minimum time between channels<sup>1</sup></i>
	Logic	Not applicable	2 ns	1 ns
	Time Qualified Logic	4 ns	2 ns	1 ns
	<sup>1</sup> For logic, time between channels refers to the length of time a logic state derived from more than one channel must exist to be recognized. For events, the time is the minimum time between a main and delayed event that will be recognized if more than one channel is used.			
Minimum clock pulse widths for setup/hold time violation trigger, typical	For all vertical settings, the minimums are:			
	<i>Minimum pulse width, clock active<sup>2</sup></i>		<i>Minimum pulse width, clock inactive<sup>2</sup></i>	
	User hold time + 2.5 ns <sup>3</sup>		2 ns	
	<sup>2</sup> An active pulse width is the width of the clock pulse from its active edge (as defined through the Define Inputs lower-bezel button and the Clock Edge side-bezel menu) to its inactive edge. An inactive pulse width is the width of the pulse from its inactive edge to its active edge.			
	<sup>3</sup> The User hold time is the number selected by the user through the Times lower-bezel button and the Hold Time side-bezel menu.			

**Table 1-4: Trigger specifications (Cont.)**

Characteristic	Description		
Setup/hold violation trigger, setup and hold time ranges	<i>Feature</i>	<i>Min</i>	<i>Max</i>
	Setup time	0 ns	8 s
	Hold time	4 ns	8 s
	Setup + Hold time	4 ns	16 s
Pulse type trigger, minimum pulse, rearm time, minimum transition time	Input coupling on clock and data channels must be the same.		
	For Setup time, positive numbers mean a data transition before the clock.		
	For Hold time, positive numbers mean a data transition after the clock edge.		
	Setup + Hold time is the algebraic sum of the Setup Time and the Hold Time programmed by the user.		
	<i>Pulse class</i>	<i>Minimum pulse width</i>	<i>Minimum rearm time</i>
	Glitch	4 ns	2 ns + 5% of glitch width setting
	Runt	4 ns	2 ns
Time-qualified runt	4 ns	8.5 ns + 5% of width setting	
Width	4 ns	2 ns + 5% of width upper limit setting	
Slew rate	4 ns	8.5 ns + 5% of delta time setting	
Transition time trigger, delta time range	For the trigger class width and the trigger class runt, the pulse width refers to the width of the pulse being measured. The rearm time refers to the time between pulses.		
	For the trigger class slew rate, the pulse width refers to the delta time being measured. The rearm time refers to the time it takes the signal to cross the two trigger thresholds again.		
Time range for glitch, pulse width, or time-qualified runt triggering	4 ns to 8 s		
B trigger after events, minimum pulse width and maximum event frequency, typical	4 ns, 500 MHz		

**Table 1-4: Trigger specifications (Cont.)**

<b>Characteristic</b>	<b>Description</b>
B trigger, minimum time between arm and trigger, typical	4 ns For trigger after time, this is the time between the end of the time period and the B trigger event. For trigger after events, this is the time between the last A trigger event and the first B trigger event.
B trigger after time, time range	4 ns to 8 s
B trigger after events, event range	1 to 9,999,999
Maximum serial trigger bits	128 bits

**Table 1-4: Trigger specifications (Cont.)**

Characteristic	Description
Standard serial bus interface triggering	<p>I<sup>2</sup>C</p> <p>Address Triggering: 7 and 10 bit user specified address, as well as General Call, START byte, HS-mode, EEPROM, and CBUS</p> <p>Data Trigger: 1 to 5 bytes of user specified data</p> <p>Trigger On: Start, Repeated Start, Stop, Missing Ack, Address, Data, or Address and Data</p> <p>Maximum Data Rate: 10 Mb/s</p>
	<p>SPI</p> <p>Data Trigger: 1 to 16 bytes of user specified data</p> <p>Trigger On: SS Active, MOSI, MISO, or MOSI and MISO</p> <p>Maximum Data Rate: 10 Mb/s</p>
	<p>CAN</p> <p>Data Trigger: 1 to 8 bytes of user specified data, including qualifiers of equal to (=), not equal to (&lt;&gt;), less than (&lt;), greater than (&gt;), less than or equal to (&lt;=), greater than or equal to (&gt;=)</p> <p>Trigger On: Start of Frame, Type of Frame, Identifier, Data, Identifier and Data, End of Frame, Missing Ack, or Bit Stuffing Error</p> <p>Frame Type: Data, Remote, Error, Overload</p> <p>Identifier: Standard (11 bit) and Extended (29 bit) identifiers</p> <p>Maximum Data Rate: 1 Mb/s</p>
	<p>RS-232/422/485/UART</p> <p>Data Trigger: Tx Data, Rx Data</p> <p>Trigger On: Tx Start Bit, Rx Start Bit, Tx End of Packet, Rx End of Packet, Tx Data, Rx Data, Tx Parity Error, or Rx Parity Error</p> <p>Maximum Data Rate: 10 Mb/s</p>
	<p>LIN</p> <p>Data Trigger: 1 to 8 Bytes of user-specified data, including qualifiers of equal to (=), not equal to (&lt;&gt;), less than (&lt;), greater than (&gt;), less than or equal to (&lt;=), greater than or equal to (&gt;=).</p> <p>Trigger On: Sync, Identifier, Data, Identifier &amp; Data, Wakeup Frame, Sleep Frame, or Error</p> <p>Maximum Data Rate: 1 Mb/s (by LIN definition, 20 kbit/s)</p>

**Table 1-5: Display specifications**

Characteristic	Description
Display type	9" WVGA LCD display with CCFL backlight Display Area - 196.8 mm (H) x 118.08 mm (V). 230 mm diagonal
Display resolution	800x480 pixels, each made up of 3 vertical stripe sub-pixels colored red, green, and blue
Luminance, typical	400 cd/m <sup>2</sup> at IBL = 5.0 mArms/lamp
Waveform display color scale	The TFT display can support up to 16 colors from a palette of 512. A subset of these colors are used for the scope display, of which all are fixed colors and not changeable by the customer

**Table 1-6: Input/Output port specifications**

Characteristic	Description						
Ethernet interface	Standard on all models: 10/100 Mb/s						
GPIB interface	Available as an optional accessory that connects to USB Device and USB Host port. with the TEK-USB-488 GPIB to USB Adapter Control interface is incorporated in the instrument user interface						
USB interface	1 Device and 2 Host connectors (all models)						
Device port	USB 2.0 High Speed; also supports Full Speed and Slow Speed Modes						
Host ports	Two USB 2.0 high speed ports; one on front, one on rear						
Video signal output	A 15 pin, SVGA RGB-type connector						
Probe compensator output voltage and frequency, typical	Output voltage: 0 V to 2.5 V $\pm$ 1% behind 1 k $\Omega$ $\pm$ 2% Frequency: 1 kHz $\pm$ 20%						
✓ Trigger (Auxiliary) output (AUX OUT)	LOW TRUE; LOW to HIGH transition indicates that the trigger occurred. The logic levels are:						
	<table border="1"> <thead> <tr> <th>Characteristic</th> <th>Limits</th> </tr> </thead> <tbody> <tr> <td>Vout (HI)</td> <td><math>\geq</math>3.25 V open circuit; <math>\geq</math>2.2 V into a 50 <math>\Omega</math> load to ground</td> </tr> <tr> <td>Vout (LO)</td> <td><math>\leq</math>0.4 V into a load of <math>\leq</math>4 mA; <math>\leq</math>0.30 V into a 50 <math>\Omega</math> load to ground</td> </tr> </tbody> </table>	Characteristic	Limits	Vout (HI)	$\geq$ 3.25 V open circuit; $\geq$ 2.2 V into a 50 $\Omega$ load to ground	Vout (LO)	$\leq$ 0.4 V into a load of $\leq$ 4 mA; $\leq$ 0.30 V into a 50 $\Omega$ load to ground
Characteristic	Limits						
Vout (HI)	$\geq$ 3.25 V open circuit; $\geq$ 2.2 V into a 50 $\Omega$ load to ground						
Vout (LO)	$\leq$ 0.4 V into a load of $\leq$ 4 mA; $\leq$ 0.30 V into a 50 $\Omega$ load to ground						

**Table 1-7: Power source specifications**

Characteristic	Description
Source voltage	100 V to 240 V $\pm$ 10%
Source frequency 100 V to 240 V 100 V to 132 V	50/60 Hz 400 Hz $\pm$ 10%
Fuse rating	T3.15 A, 250 V  The fuse is not customer replaceable

**Table 1-8: Data storage specifications**

Characteristic	Description
Nonvolatile memory retention time, typical	No time limit for front-panel settings, saved waveforms, setups, and calibration constants
Real-time clock	A programmable clock providing time in years, months, days, hours, minutes, and seconds

**Table 1-9: Environmental specifications**

Characteristic	Description
Temperature	Operating: 0 °C to +50 °C (+32 °F to +122 °F) Nonoperating: -40 °C to +71 °C (-40 °F to +160 °F)
Humidity	Operating: 5% to 95% relative humidity (% RH) at up to +30 °C, 5% to 45% RH above +30 °C up to +50 °C, non-condensing, and as limited by a Maximum Wet-Bulb Temperature of +38 °C (derates relative humidity to 45 % RH at +50 °C) Nonoperating: 5% to 95% RH (Relative Humidity) at up to +30 °C, 5% to 45% RH above +30 °C up to +50 °C, non-condensing, and as limited by a Maximum Wet-Bulb Temperature of +38 °C (derates relative humidity to 27% RH at +60 °C)
Pollution Degree	Pollution Degree 2, indoor use only
Altitude	Operating: 3,000 m (9,843 ft) Nonoperating: 12,000 m (39,370 ft)

**Table 1-10: Mechanical specifications**

<b>Characteristic</b>	<b>Description</b>	
Dimensions		
Height	<b>mm</b>	<b>In.</b>
Handle down	203.2	8.0
Handle up	254	10.3
Width	416.6	16.4
Depth	147.4	5.8
Weight	<b>kg</b>	<b>Lb.</b>
Stand alone, no front cover	4.2	9.2
With accessories and carry case	6.8	15.0
Packaged for domestic shipment	8.6	19.0

**Table 1- 11: Safety certification**

Characteristic	Description
Safety certification	U.S. Nationally Recognized Testing Laboratory (NRTL) Listing: UL61010-1-2004 Standard for Electrical Measuring
	Canadian Certification: CAN/CSA C22.2 No. 61010-1: 2004 Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use
	European Union Compliance: Low Voltage Directive 2006/95/EC, as Amended by 93/68/EEC EN61010-1 2001 Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use
	Additional compliance: IEC61010-1 2001 Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use

**Table 1- 12: Electromagnetic compatibility (EMC)**

European Union	<p>EC Council Directive 2004/108/EC;</p> <p>Demonstrated using:</p> <p>IEC 61326:1997 Electrical equipment for measurement, control, and laboratory use. Class A, Annex D<sup>1,2</sup></p> <p>Immunity</p> <ul style="list-style-type: none"> <li>IEC 61000-4-2:1999 Electrostatic Discharge (Perf. Crit. B)</li> <li>IEC 61000-4-3:2002 RF Electromagnetic Field (Perf. Crit. A) <sup>3</sup></li> <li>IEC 61000-4-4:2004 Electrical Fast Transient/Burst (Perf. Crit. B)</li> <li>IEC 61000-4-5:2005 Power Surge (Perf. Crit. B)</li> <li>IEC 61000-4-6:2003 Conducted RF (Perf. Crit. A) <sup>4</sup></li> <li>IEC 61000-4-11:2004 Voltage Dips and Interruptions (Perf. Crit. B)</li> </ul> <p>EN 61000-3-2:2000 AC Power Line Harmonic Emissions</p> <p>EN 61000-3-3:1995 Voltage Changes, Fluctuations, &amp; Flicker</p>
Australia	EMC Framework, demonstrated using EN61326:1997, in accordance with the ACMA.

- <sup>1</sup> Emissions that exceed the levels required by this standard may occur when this equipment is connected to a test object.
- <sup>2</sup> Use Low-EMI Shielded cables to maintain compliance.
- <sup>3</sup> The increase in trace noise, while subjected to the test field (3 V/m over the frequency range 80 MHz to 1 GHz with 80% amplitude modulation at 1 kHz), is not to exceed 8 major divisions peak-to-peak. Ambient fields may induce triggering when the trigger threshold is offset less than 4 minor divisions from ground reference.
- <sup>4</sup> The increase in trace noise, while subjected to the injected 3 V test signal, is not to exceed 2 major divisions peak-to-peak. Ambient fields may induce triggering when the trigger threshold is offset less than 1 major division from ground reference.



# Performance Verification

This chapter contains performance verification procedures for the specifications marked with the ✓ symbol. The following equipment, or a suitable equivalent, is required to complete these procedures.

Description	Minimum requirements	Examples
DC voltage source	3 mV to 4 V, $\pm 0.1\%$ accuracy	Fluke 9500 Oscilloscope Calibrator with a 9510 Output Module
Leveled sine wave generator	50 kHz to 1000 MHz, $\pm 4\%$ amplitude accuracy	
Time mark generator	80 ms period, $\pm 1$ ppm accuracy, rise time < 50 ns	An appropriate BNC-to-0.1 inch pin adapter between the Fluke 9500 and P6516 probe
Digital Multimeter (DMM)	0.1% accuracy or better	
One 50 $\Omega$ BNC cable	Male-to-male connectors	Tektronix part number 012-0057-01

You may need additional cables and adapters, depending on the actual test equipment you use.

These procedures cover all DPO3000 models. Please disregard any checks that do not apply to the specific model you are testing.

Photocopy the test record on the following pages and use it to record the performance test results for your oscilloscope.

---

**NOTE.** *Completion of the performance verification procedure does not update the stored time and date of the latest successful adjustment. The date and time are updated only when the adjustment procedures in the service manual are successfully completed.*

---

The performance verification procedures verify the performance of your instrument. They do not adjust your instrument. If your instrument fails any of the performance verification tests, you should perform the factory adjustment procedures as described in the *DPO3000 Series Service Manual*.

## Upgrade the Firmware

For the best functionality, you can upgrade the oscilloscope firmware. To upgrade the firmware, follow these steps:

1. Open a Web browser and go to [www.tektronix.com/software](http://www.tektronix.com/software). Use the Software and Firmware Finder to locate the most recent firmware upgrade.
2. Download the latest firmware for your oscilloscope onto your PC.
3. Unzip the files and copy the “firmware.img” file into the root folder of a USB flash drive.
4. Power off your oscilloscope.
5. Insert the USB flash drive into a USB Host port on the front or back of the oscilloscope.
6. Power on the oscilloscope. The oscilloscope automatically recognizes the replacement firmware and installs it.

If the instrument does not install the firmware, rerun the procedure. If the problem continues, contact qualified service personnel.

---

**NOTE.** *Do not power off the oscilloscope or remove the USB flash drive until the oscilloscope finishes installing the firmware.*

---

The oscilloscope displays a message when the installation is complete.

7. Power off the oscilloscope and remove the USB flash drive.
8. Power on the oscilloscope.
9. Push the **Utility** front-panel button.
10. Push the **Utility Page** lower-bezel button.
11. Turn multipurpose knob **a** and select **Config**.
12. Push the **About** lower-bezel button. The oscilloscope displays the firmware version number.
13. Confirm that the version number matches that of the new firmware.

## Test Record

Model number	Serial number	Procedure performed by	Date

Test	Passed	Failed
Self Test		

### Input Impedance

Performance checks	Vertical scale	Low limit	Test result	High limit
--------------------	----------------	-----------	-------------	------------

#### All models:

Channel 1 Input Impedance, 1 M $\Omega$	10 mV/div	990 k $\Omega$		1.01 M $\Omega$
	100 mV/div	990 k $\Omega$		1.01 M $\Omega$
Channel 1 Input Impedance, 75 $\Omega$	100 mV/div	74.25 $\Omega$		75.75 $\Omega$
Channel 1 Input Impedance, 50 $\Omega$	100 mV/div	49.5 $\Omega$		50.5 $\Omega$
Channel 2 Input Impedance, 1 M $\Omega$	10 mV/div	990 k $\Omega$		1.01 M $\Omega$
	100 mV/div	990 k $\Omega$		1.01 M $\Omega$
Channel 2 Input Impedance, 75 $\Omega$	100 mV/div	74.25 $\Omega$		75.75 $\Omega$
Channel 2 Input Impedance, 50 $\Omega$	100 mV/div	49.5 $\Omega$		50.5 $\Omega$

#### DPO3014, DPO3034, DPO3054:

Channel 3 Input Impedance, 1 M $\Omega$	10 mV/div	990 k $\Omega$		1.01 M $\Omega$
	100 mV/div	990 k $\Omega$		1.01 M $\Omega$
Channel 3 Input Impedance, 75 $\Omega$	100 mV/div	74.25 $\Omega$		75.75 $\Omega$
Channel 3 Input Impedance, 50 $\Omega$	100 mV/div	49.5 $\Omega$		50.5 $\Omega$

<b>Input Impedance (Cont.)</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
Channel 4 Input Impedance, 1 M $\Omega$	10 mV/div	990 k $\Omega$		1.01 M $\Omega$
	100 mV/div	990 k $\Omega$		1.01 M $\Omega$
Channel 4 Input Impedance, 75 $\Omega$	100 mV/div	74.25 $\Omega$		75.75 $\Omega$
Channel 4, Input Impedance, 50 $\Omega$	100 mV/div	49.5 $\Omega$		50.5 $\Omega$

<b>DC Balance</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
<b>All models:</b>				
Channel 1 DC Balance, 50 $\Omega$ , 20 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 1 DC Balance, 75 $\Omega$ , 20 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 1 DC Balance 1 M $\Omega$ , 20 MHz BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV

<b>DC Balance (Cont.)</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
Channel 1 DC Balance, 50 $\Omega$ , 150 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 1 DC Balance, 75 $\Omega$ , 150 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 1 DC Balance 1 M $\Omega$ , 150 MHz BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 1 DC Balance, 50 $\Omega$ , Full BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 1 DC Balance, 75 $\Omega$ , Full BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 1 DC Balance 1 M $\Omega$ , Full BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV

<b>DC Balance (Cont.)</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
Channel 2 DC Balance, 50 $\Omega$ , 20 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 2 DC Balance, 75 $\Omega$ , 20 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 2 DC Balance 1 M $\Omega$ , 20 MHz BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 2 DC Balance, 50 $\Omega$ , 150 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 2 DC Balance, 75 $\Omega$ , 150 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 2 DC Balance 1 M $\Omega$ , 150 MHz BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV

<b>DC Balance (Cont.)</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
Channel 2 DC Balance, 50 $\Omega$ , Full BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 2 DC Balance, 75 $\Omega$ , Full BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 2 DC Balance 1 M $\Omega$ , Full BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
<b>DPO3014, DPO3034, DPO3054:</b>				
Channel 3 DC Balance, 50 $\Omega$ , 20 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 3 DC Balance, 75 $\Omega$ , 20 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 3 DC Balance 1 M $\Omega$ , 20 MHz BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV

<b>DC Balance (Cont.)</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
Channel 3 DC Balance, 50 $\Omega$ , 150 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 3 DC Balance, 75 $\Omega$ , 150 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 3 DC Balance 1 M $\Omega$ , 150 MHz BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 3 DC Balance, 50 $\Omega$ , Full BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 3 DC Balance, 75 $\Omega$ , Full BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 3 DC Balance 1 M $\Omega$ , Full BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV



<b>DC Balance (Cont.)</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
Channel 4 DC Balance, 50 $\Omega$ , 20 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 4 DC Balance, 75 $\Omega$ , 20 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 4 DC Balance 1 M $\Omega$ , 20 MHz BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 4 DC Balance, 50 $\Omega$ , 150 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 4 DC Balance, 75 $\Omega$ , 150 MHz BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 4 DC Balance 1 M $\Omega$ , 150 MHz BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV

<b>DC Balance (Cont.)</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
Channel 4 DC Balance, 50 $\Omega$ , Full BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 4 DC Balance, 75 $\Omega$ , Full BW	1 mV/div	-0.5 mV		0.5 mV
	2 mV/div	-0.5 mV		0.5 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV
Channel 4 DC Balance 1 M $\Omega$ , Full BW	1 mV/div <sup>1</sup>	-0.3 mV		0.3 mV
	2 mV/div	-0.4 mV		0.4 mV
	10 mV/div	-2.0 mV		2.0 mV
	100 mV/div	-20.0 mV		20.0 mV
	1 V/div	-200.0 mV		200.0 mV

<sup>1</sup> Immediately after calibration, the specification is -0.2 div to 0.20 div. For performance verification testing, the specification is -0.3 to 0.3 div.

**Performance checks: Bandwidth**

<b>Band-width at Channel</b>	<b>Imped-ance</b>	<b>Vertical scale</b>	<b><math>V_{in-pp}</math></b>	<b><math>V_{bw-pp}</math></b>	<b>Limit</b>	<b>Test result <math>Gain = V_{bw-pp}/V_{in-pp}</math></b>
<b>All models:</b>						
1	50 $\Omega$	10 mV/div			$\geq 0.707$	
1	50 $\Omega$	5 mV/div			$\geq 0.707$	
1	50 $\Omega$	2 mV/div			$\geq 0.707$	
1	50 $\Omega$	1 mV/div			$\geq 0.707$	
2	50 $\Omega$	10 mV/div			$\geq 0.707$	
2	50 $\Omega$	5 mV/div			$\geq 0.707$	
2	50 $\Omega$	2 mV/div			$\geq 0.707$	
2	50 $\Omega$	1 mV/div			$\geq 0.707$	
<b>DPO3014, DPO3034, DPO3054:</b>						
3	50 $\Omega$	10 mV/div			$\geq 0.707$	
3	50 $\Omega$	5 mV/div			$\geq 0.707$	
3	50 $\Omega$	2 mV/div			$\geq 0.707$	
3	50 $\Omega$	1 mV/div			$\geq 0.707$	
4	50 $\Omega$	10 mV/div			$\geq 0.707$	
4	50 $\Omega$	5 mV/div			$\geq 0.707$	
4	50 $\Omega$	2 mV/div			$\geq 0.707$	
4	50 $\Omega$	1 mV/div			$\geq 0.707$	

<b>DC Gain Accuracy</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
<b>All models:</b>				
Channel 1 DC Gain Accuracy, 0 V offset, 0 V vertical position, 20 MHz BW, 1 M $\Omega$	1 mV/div	-1.5%		1.5%
	2 mV/div	-1.5%		1.5%
	4.98 mV/div	-3.0%		3.0%
	5 mV/div	-1.5%		1.5%
	10 mV/div	-1.5%		1.5%
	20 mV/div	-1.5%		1.5%
	49.8 mV	-3.0%		3.0%
	50 mV/div	-1.5%		1.5%
	100 mV/div	-1.5%		1.5%
	200 mV/div	-1.5%		1.5%
	500 mV/div	-1.5%		1.5%
	1 V/div	-1.5%		1.5%
	Channel 2 DC Gain Accuracy, 0 V offset, 0 V vertical position, 20 MHz BW, 1 M $\Omega$	1 mV/div	-1.5%	
2 mV/div		-1.5%		1.5%
4.98 mV/div		-3.0%		3.0%
5 mV/div		-1.5%		1.5%
10 mV/div		-1.5%		1.5%
20 mV/div		-1.5%		1.5%
49.8 mV		-3.0%		3.0%
50 mV/div		-1.5%		1.5%
100 mV/div		-1.5%		1.5%
200 mV/div		-1.5%		1.5%
500 mV/div		-1.5%		1.5%
1 V/div		-1.5%		1.5%

<b>DC Gain Accuracy (Cont.)</b>				
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
<b>DPO3014, DPO3034, DPO3054:</b>				
Channel 3 DC Gain Accuracy, 0 V offset, 0 V vertical position, 20 MHz BW, 1 M $\Omega$	1 mV/div	-1.5%		1.5%
	2 mV/div	-1.5%		1.5%
	4.98 mV/div	-3.0%		3.0%
	5 mV/div	-1.5%		1.5%
	10 mV/div	-1.5%		1.5%
	20 mV/div	-1.5%		1.5%
	49.8 mV	-3.0%		3.0%
	50 mV/div	-1.5%		1.5%
	100 mV/div	-1.5%		1.5%
	200 mV/div	-1.5%		1.5%
	500 mV/div	-1.5%		1.5%
	1 V/div	-1.5%		1.5%
	Channel 4 DC Gain Accuracy, 0 V offset, 0 V vertical position, 20 MHz BW, 1 M $\Omega$	1 mV/div	-1.5%	
2 mV/div		-1.5%		1.5%
4.98 mV/div		-3.0%		3.0%
5 mV/div		-1.5%		1.5%
10 mV/div		-1.5%		1.5%
20 mV/div		-1.5%		1.5%
49.8 mV		-3.0%		3.0%
50 mV/div		-1.5%		1.5%
100 mV/div		-1.5%		1.5%
200 mV/div		-1.5%		1.5%
500 mV/div		-1.5%		1.5%
1 V/div		-1.5%		1.5%

<b>DC Offset Accuracy</b>					
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Vertical offset <sup>2</sup></b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
<b>All models</b>					
Channel 1 DC Offset Accuracy, 20 MHz BW, 1 M $\Omega$	1 mV/div	700 mV	696.2 mV		703.8 mV
	1 mV/div	-700 mV	-703.8 mV		-696.2 mV
	2 mV/div	700 m	696.1 mV		703.9 mV
	2 mV/div	-700 mV	-703.9 mV		-696.1 mV
	10 mV/div	1 V	993 mV		1007 mV
	10 mV/div	-1 V	-1007 mV		-993 mV
	100 mV/div	10.0 V	9.930 V		10.07 V
	100 mV/div	-10.0 V	-10.07 V		-9.930 V
	1 V/div	100 V	99.30 V		100.7 V
	1 V/div	-100 V	-100.7 V		-99.30 V
	1.01 V/div	100 V	99.30 V		100.7 V
	1.01 V/div	-100 V	-100.7 V		-99.30 V
Channel 2 DC Offset Accuracy, 20 MHz BW, 1 M $\Omega$	1 mV/div	700 mV	696.2 mV		703.8 mV
	1 mV/div	-700 mV	-703.8 mV		-696.2 mV
	2 mV/div	700 mV	696.1 mV		703.9 mV
	2 mV/div	-700 mV	-703.9 mV		-696.1 mV
	10 mV/div	1 V	993 mV		1007 mV
	10 mV/div	-1 V	-1007 mV		-993 mV
	100 mV/div	10.0 V	9.930 V		10.07 V
	100 mV/div	-10.0 V	-10.07 V		-9.930 V
	1 V/div	100 V	99.30 V		100.7 V
	1 V/div	-100 V	-100.7 V		-99.30 V
	1.01 V/div	100 V	99.30 V		100.7 V
	1.01 V/div	-100 V	-100.7 V		-99.30 V

<sup>2</sup> Use this value for both the calibrator output and the oscilloscope offset setting.

<b>DC Offset Accuracy (Cont.)</b>					
<b>Performance checks</b>	<b>Vertical scale</b>	<b>Vertical offset <sup>2</sup></b>	<b>Low limit</b>	<b>Test result</b>	<b>High limit</b>
<b>DPO3014, DPO3034, DPO3054:</b>					
Channel 3 DC Offset Accuracy, 20 MHz BW, 1 M $\Omega$	1 mV/div	700 mV	696.2 mV		703.8 mV
	1 mV/div	-700 mV	-703.8 mV		-696.2 mV
	2 mV/div	700 mV	696.1 mV		703.9 mV
	2 mV/div	-700 mV	-703.9 mV		-696.1 mV
	10 mV/div	1 V	993 mV		1007 mV
	10 mV/div	-1 V	-1007 mV		-993 mV
	100 mV/div	10.0 V	9.930 V		10.07 V
	100 mV/div	-10.0 V	-10.07 V		-9.930 V
	1 V/div	100 V	99.30 V		100.7 V
	1 V/div	-100 V	-100.7 V		-99.30 V
	1.01 V/div	100 V	99.30 V		100.7 V
	1.01 V/div	-100 V	-100.7 V		-99.30 V
Channel 4 DC Offset Accuracy, 20 MHz BW, 1 M $\Omega$	1 mV/div	700 mV	696.2 mV		703.8 mV
	1 mV/div	-700 mV	-703.8 mV		-696.2 mV
	2 mV/div	700 mV	696.1 mV		703.9 mV
	2 mV/div	-700 mV	-703.9 mV		-696.1 mV
	10 mV/div	1 V	993 mV		1007 mV
	10 mV/div	-1 V	-1007 mV		-993 mV
	100 mV/div	10.0 V	9.930 V		10.07 V
	100 mV/div	-10.0 V	-10.07 V		-9.930 V
	1 V/div	100 V	99.30 V		100.7 V
	1 V/div	-100 V	-100.7 V		-99.30 V
	1.01 V/div	100 V	99.30 V		100.7 V
	1.01 V/div	-100 V	-100.7 V		-99.30 V

<sup>2</sup> Use this value for both the calibrator output and the oscilloscope offset setting.

Performance checks	Low limit	Test result	High limit
<b>Sample Rate and Delay Time Accuracy</b>	-2 divisions		+2 divisions

<b>Auxiliary (Trigger) Output</b>			
Trigger Output	Low 1 M $\Omega$	—	$\leq 0.4$ V
	High 1 M $\Omega$	$\geq 3.25$ V	—
	Low 50 $\Omega$	—	$\leq 0.20$ V
	High 50 $\Omega$	$\geq 2.2$ V	—



## Performance Verification Procedures

The following three conditions must be met prior to performing these procedures:

1. The oscilloscope must have been operating continuously for twenty (20) minutes in an environment that meets the operating range specifications for temperature and humidity.
2. You must perform a signal path compensation (SPC). See *Signal Path Compensation* in the *DPO3000 Series Digital Phosphor Oscilloscopes User Manual*. If the operating temperature changes by more than 10 °C (18 °F), you must perform the signal path compensation again.
3. You must connect the oscilloscope and the test equipment to the same AC power circuit. Connect the oscilloscope and test instruments into a common power strip if you are unsure of the AC power circuit distribution. Connecting the oscilloscope and test instruments into separate AC power circuits can result in offset voltages between the equipment, which can invalidate the performance verification procedure.

The time required to complete the entire procedure is approximately one hour.



---

**WARNING.** *Some procedures use hazardous voltages. To prevent electrical shock, always set voltage source outputs to 0 V before making or changing any interconnections.*

---

### Self Test

This procedure uses internal routines to verify that the oscilloscope functions and passes its internal self tests. No test equipment or hookups are required. Start the self test with these steps:


1. Disconnect all probes and cables from the oscilloscope inputs.
2. Push the front-panel **Default Setup** button to set the instrument to the factory default settings.
3. Push the **Utility** menu button.
4. Push the **Utility Page** lower-bezel button, and turn the **Multipurpose a** knob to select **Self Test**.
5. Push the **Self Test** lower-bezel button. The Loop X Times side-bezel menu will be set to **Loop 1 Times**.
6. Push the **OK Run Self Test** side-bezel button.

7. Wait while the self test runs. When the self test completes, a dialog box displays the results of the self test.
8. Cycle the oscilloscope power off and back on before proceeding.

### Check Input Impedance (Resistance)

This test checks the Input Impedance.

1. Connect the output of the oscilloscope calibrator (for example, Fluke 9500) to the oscilloscope channel 1 input, as shown below.




2. Push the front-panel **Default Setup** button to set the instrument to the factory default settings.
3. Push the front-panel channel button for the oscilloscope channel that you are testing, as shown in the test record (for example, **1, 2, 3, or 4**).
4. Confirm that the oscilloscope and calibrator impedances are both set to 1 M $\Omega$ . The default **Impedance** setting is **1 M $\Omega$** .
5. Turn the **Vertical Scale** knob to set the vertical scale, as shown in the test record (for example, 10 mV/div, 100 mV/div, 1 V/div).
6. Measure the input resistance of the oscilloscope with the calibrator. Record this value in the test record.
7. Repeat steps 5 and 6 for each volt/division setting in the test record.
8. Change the oscilloscope impedance to 75  $\Omega$  and calibrator impedance to 50  $\Omega$  and repeat steps 5 through 7.
9. Change the oscilloscope impedance to 50  $\Omega$  and repeat steps 5 through 7.
10. Repeat steps 4 through 9 for each channel listed in the test record and relevant to the model of oscilloscope that you are testing, as shown in the test record (for example, **2, 3, or 4**).

**Check DC Balance**

This test checks the DC balance.

You do not need to connect the oscilloscope to any equipment to run this test.




1. Attach a 50  $\Omega$  terminator to the channel input of the oscilloscope being tested.
2. Push the front-panel **Default Setup** button to set the instrument to the factory default settings.
3. Push the front-panel channel button for the oscilloscope channel that you are testing, as shown in the test record (for example, **1**, **2**, **3**, or **4**).
4. Set the oscilloscope impedance to 50  $\Omega$ . Push the **Impedance** lower-bezel button to select **50  $\Omega$** .
5. Push the lower-bezel **Bandwidth** button and push the appropriate bandwidth side-bezel button for **20MHz**, **150MHz**, or **Full**, as given in the test record.
6. Turn the Horizontal **Scale** knob to 1 ms/division.
7. Turn the Vertical **Scale** knob to set the vertical scale, as shown in the test record (for example, 1 mV/div, 2 mV/div, 10 mV/div, 100 mV/div, 1 V/div).
8. Push the front-panel **Acquire** button.
9. Push the **Mode** lower-bezel button, and then, if needed, push the **Average** side bezel button.
10. If needed, adjust the number of averages to **16** with the **Multipurpose a** knob.
11. Push the **Trigger Menu** front-panel button.
12. Push the **Source** lower-bezel button.
13. Select the **AC Line** trigger source on the side menu. You do not need to connect an external signal to the oscilloscope for this DC Balance test.
14. Push the front-panel Wave Inspector **Measure** button.
15. Push the **Add Measurement** lower bezel button.
16. Use the **Multipurpose a** knob to select the **Mean** measurement.

17. Push the **OK Add Measurement** side-bezel button, and then the **Menu Off** front-panel button.
18. View the mean measurement value in the display and enter that mean value as the test result in the test record.
19. Repeat steps 7 through 18 for each volts/division value listed in the results table.
20. Push the front-panel channel button, change the oscilloscope bandwidth (for example, 20 MHz, 150 MHz, or Full), and repeat steps 5 through 19.
21. Change the oscilloscope impedance to 1 M $\Omega$  and repeat steps 5 through 20.
22. Repeat steps 3 through 20 for each channel combination listed in the test record and relevant to your model of oscilloscope (for example, 1, 2, 3, or 4).
23. Change the oscilloscope impedance to 75  $\Omega$  and repeat steps 5 through 20.
24. Repeat steps 3 through 20 for each channel combination listed in the test record and relevant to your model of oscilloscope (for example, 1, 2, 3, or 4).

### Check Bandwidth

This test checks the bandwidth at 50  $\Omega$  for each channel.

1. Connect the output of the leveled sine wave generator (for example, Fluke 9500) to the oscilloscope channel 1 input as shown below.



2. Push the front-panel **Default Setup** button to set the instrument to the factory default settings.
3. Push the channel button (**1, 2, 3, or 4**) for the channel that you want to check.
4. Set the calibrator to 50  $\Omega$  output impedance (50  $\Omega$  source impedance) and to generate a sine wave.
5. Set the oscilloscope impedance to 50  $\Omega$ . Push the **Impedance** lower-bezel button to select **50  $\Omega$** .

6. Turn the Vertical **Scale** knob to set the vertical scale, as shown in the test record (for example, 1 mV/div, 2 mV/div, 5 mV/div).
7. Push the front-panel **Acquire** button.
8. Confirm that the mode is set to **Sample**. If not, push the **Mode** lower-bezel button, if needed, and then push the **Sample** side bezel button.
9. Adjust the signal source to at least 6 vertical divisions at the selected vertical scale with a set frequency of 50 kHz. For example, at 5 mV/div, use a  $\geq 30$  mV<sub>p-p</sub> signal, at 2 mV/div, use a  $\geq 12$  mV<sub>p-p</sub> signal, at 1 mV/div, use a  $\geq 6$  mV<sub>p-p</sub> signal. Use a sine wave for the signal source.
10. Turn the Horizontal **Scale** knob to 40  $\mu$ s/division.
11. Push the front-panel Wave Inspector **Measure** button, and then the lower-bezel **Add Measurement** button.
12. Use the **Multipurpose a** knob to select the **Peak-to-peak** measurement, and then press the **OK Add Measurement** side-bezel button.
13. Push the **More** lower-bezel button to select **Gating**, and then push the **Off (Full Record)** side-bezel button.
14. Push the **Menu Off** front-panel button. This will allow you to see the display. Note the mean  $V_{p-p}$  of the signal. Call this reading  $V_{in-pp}$ .  
Record the value of  $V_{in-pp}$  (for example, 816 mV) in the test record.
15. Turn the Horizontal **Scale** knob to 10 ns/division.
16. Adjust the signal source to the maximum bandwidth frequency for the bandwidth and model desired, as shown in the following worksheet. Measure  $V_{p-p}$  of the signal on the oscilloscope using statistics, as in the previous step, to get the mean  $V_{p-p}$ . Call this reading  $V_{bw-pp}$ .

Record the value of  $V_{bw-pp}$  in the test record.

---

**NOTE.** For more information on the contents of this worksheet, refer to the bandwidth specifications in Table 1-1, starting on page 1-4.

---

**Table 2- 1: Maximum Bandwidth Frequency worksheet**

<b>Model: DPO3054, DPO3052</b>		
<b>Impedance</b>	<b>Vertical Scale</b>	<b>Maximum bandwidth frequency</b>
50 $\Omega$	10 mV/div	500 MHz
50 $\Omega$	5 mV/div	400 MHz
50 $\Omega$	2 mV/div	250 MHz
50 $\Omega$	1 mV/div	150 MHz
<b>Model: DPO3034, DPO3032</b>		
50 $\Omega$	5 mV/div	300 MHz
50 $\Omega$	2 mV/div	250 MHz
50 $\Omega$	1 mV/div	150 MHz
<b>Model: DPO3014, DPO3012</b>		
50 $\Omega$	1 mV/div	100 MHz

17. Use the values of  $V_{bw-pp}$  and  $V_{in-pp}$  obtained above and stored in the test record to calculate the *Gain* at bandwidth with the following equation:

$$Gain = V_{bw-pp}/V_{in-pp}.$$

To pass the performance measurement test, Gain should be  $\geq 0.707$ .


Enter *Gain* in the test record.

18. Repeat steps 9 through 17 for the other oscilloscope volts/div settings listed in the test record.
19. Repeat steps 3 through 18 for each channel combination listed in the test record and relevant to your model of oscilloscope (for example, **1, 2, 3, or 4**).

### Check DC Gain Accuracy

This test checks the DC gain accuracy.

1. Connect the oscilloscope to a DC voltage source. If using the Wavetek 9500 calibrator, connect the calibrator head to the oscilloscope channel to test.



2. Push the front-panel **Default Setup** button to set the instrument to the factory default settings.
3. Push the channel button (**1**, **2**, **3**, or **4**) for the channel that you want to check.
4. Confirm that the oscilloscope and calibrator impedances are both set to 1 M $\Omega$ . Push the **Impedance** lower-bezel button to select **1 M $\Omega$** .
5. Push the **20 MHz** side-bezel button to select the bandwidth (push the lower-bezel **Bandwidth** button if necessary to activate the Bandwidth menu).
6. Push the front-panel **Acquire** button.
7. Push the **Mode** lower-bezel button, and push the **Average** side bezel button. The default number of averages is **16**.
8. Push the front-panel Wave Inspector **Measure** button, and then the **Add Measurement** lower-bezel button.
9. Use the **Multipurpose a** knob to select the **Mean** measurement.
10. Push the **OK Add Measurement** side-bezel button.
11. Push the **Trigger Menu** front-panel button.
12. Push the **Source** lower-bezel button.
13. Turn the **Multipurpose a** knob to select the **AC Line** as the trigger source.
14. Turn the vertical **Scale** knob to the next setting to measure, as shown in Table 2-2.
15. Set the DC Voltage Source to  $V_{\text{negative}}$  (see Table 2-2). Push the **Measure** front-panel button, push the **More** lower-bezel button to select **Statistics**, push the **Reset Statistics** side-bezel button, and then push the **Menu Off** front-panel button. Enter the mean reading into Table 2-2 as  $V_{\text{negative-measured}}$ .

16. Set the DC Voltage Source to  $V_{\text{positive}}$  (see Table 2-2). Push the **More** lower-bezel button to select **Statistics**, push the **Reset Statistics** side-bezel button, and then push the **Menu Off** front-panel button. Enter the mean reading into Table 2-2 as  $V_{\text{positive-measured}}$ .

Table 2-2: Gain Expected worksheet

Oscilloscope Vertical Scale Setting	$V_{\text{diffExpected}}$	$V_{\text{negative}}$	$V_{\text{positive}}$	$V_{\text{negative-measured}}$	$V_{\text{positive-measured}}$	$V_{\text{diff}}$	Test Result (Gain Accuracy)
1 mV/div	7 mV	-3.5 mV	+3.5 mV				
2 mV/div	14 mV	-7 mV	+7 mV				
4.98 mV	34.86 mV	-17.43 mV	+17.43 mV				
5 mV	35 mV	-17.5 mV	+17.5 mV				
10 mV	70 mV	-35 mV	+35 mV				
20 mV	140 mV	-70 mV	+70 mV				
49.8 mV	348.6 mV	-174.3 mV	+174.3 mV				
50 mV	350 mV	-175 mV	+175 mV				
100 mV	700 mV	-350 mV	+350 mV				
200 mV	1400 mV	-700 mV	+700 mV				
500 mV	3500 mV	-1750 mV	+1750 mV				
1.0 V	7000 mV	-3500 mV	+3500 mV				

17. Calculate  $V_{\text{diff}}$  as follows:

$$V_{\text{diff}} = |V_{\text{negative-measured}} - V_{\text{positive-measured}}|$$

Enter  $V_{\text{diff}}$  in Table 2-2.

18. Calculate  $\text{GainAccuracy}$  as follows:

$$\text{GainAccuracy} = ((V_{\text{diff}} - V_{\text{diffExpected}})/V_{\text{diffExpected}}) \times 100\%$$

Write down  $\text{GainAccuracy}$  in Table 2-2 and in the test record.


19. Repeat steps 14 through 18 for each volts/division value in the test record.
20. Repeat steps 3 through 19 for each channel of the oscilloscope that you want to check.



**Check Offset Accuracy**

This test checks the offset accuracy.

1. Connect the oscilloscope to a DC voltage source to run this test. If using the Wavetek calibrator as the DC voltage source, connect the calibrator head to the oscilloscope channel to test.




2. Push the front-panel **Default Setup** button to set the instrument to the factory default settings.
3. Push the channel button (**1, 2, 3, or 4**) for the channel that you want to check.
4. Confirm that the oscilloscope and calibrator impedances are both set to 1 M $\Omega$ . Push the **Impedance** lower-bezel button to select **1 M $\Omega$** .
5. Set the calibrator to the vertical offset value shown in the test record (for example, 700 mV for a 1 mV/div setting). Set the calibrator to the same impedance as you set for the oscilloscope.
6. Push the oscilloscope **More** lower-bezel button repeatedly to select **Offset**.
7. Set the oscilloscope to the vertical offset value shown in the test record (for example, 700 mV for a 1 mV/div setting).
8. Turn the vertical **Scale** to match the value in the test record (for example, 1 mV/division).
9. Turn the Horizontal **Scale** knob to 1 ms/div.
10. Push the lower-bezel **Bandwidth** button.
11. Push the side-bezel button to set the bandwidth to **20 MHz**.
12. Check that the vertical position is set to 0 divs. If not, turn the appropriate **Vertical Position** knob to set the position to 0 divs.  
  
Or, push the lower-bezel **More** button repeatedly to select **Position**, and then press the side-bezel **Set to 0 divs** button.
13. Push the front-panel **Acquire** button.

14. Push the **Mode** lower-bezel button, and push the **Average** side bezel button. The default number of averages is **16**.
15. Push the front-panel **Trigger Menu** button.
16. Push the **Source** lower-bezel button.
17. Turn the **Multipurpose a** knob to select the **AC Line** as the trigger source.
18. Push the front-panel Wave Inspector **Measure** button.
19. Push the **Add Measurement** lower bezel button.
20. Use the **Multipurpose a** knob to select the **Mean** measurement.
21. Push the **OK Add Measurement** side-bezel button, and then the **Menu Off** button. The mean value should appear in a measurement pane at the bottom of the display.
22. Enter the measured value in the test record.
23. Repeat the procedure for each volts/division setting shown in the test record.
24. Repeat steps 3 through 23 for each channel of the oscilloscope that you want to check.

### Check Sample Rate and Delay Time Accuracy

This test checks the sample rate and delay time accuracy (time base).

1. Connect the output of the time mark generator to the oscilloscope channel 1 input using a 50  $\Omega$  cable.



2. Set the time mark generator period to **80 ms**. Use a time mark waveform with a fast rising edge.
3. Push the front-panel **Default Setup** button to set the instrument to the factory default settings.
4. Push the channel **1** button.

5. Set the impedance to 50  $\Omega$ . Push the **Impedance** lower-bezel button to select **50  $\Omega$** .
6. If adjustable, set the time mark amplitude to approximately **1 V<sub>p-p</sub>**.
7. Set the Vertical **SCALE** to **500 mV**.
8. Set the Horizontal **SCALE** to **20 ms**.
9. Adjust the Vertical **POSITION** knob to center the time mark signal on the screen.
10. Adjust the Trigger **LEVEL** knob as necessary for a triggered display.
11. Adjust the Horizontal **POSITION** knob to move the trigger location to the center of the screen (50%).
12. Turn the Horizontal **POSITION** knob counterclockwise to set the delay to exactly **80 ms**.
13. Set the Horizontal **Scale** to **400 ns/div**.
14. Compare the rising edge of the marker with the center horizontal graticule line. The rising edge should be within  $\pm 1$  divisions of center graticule. Enter the deviation in the test record.

---


**NOTE.** One division of displacement from graticule center corresponds to a 5 ppm time base error.

---

### Check Aux Out

This test checks the Aux Output.

1. Connect the Aux Out signal from the rear of the instrument to the channel 1 input using a 50  $\Omega$  cable.



2. Push the front-panel **Default Setup** button to set the instrument to the factory default settings.

3. Push the channel **1** button.
4. Set the oscilloscope impedance to  $1\text{ M}\Omega$ . The default **Impedance** setting is  $1\text{ M}\Omega$ .
5. Set the horizontal to  $4\text{ uS/div}$  and the vertical to  $1\text{ V/div}$ .
6. Push the front-panel Wave Inspector **Measure** button.
7. Push the **Add Measurement** lower-bezel button.
8. Use the **Multipurpose a** knob to select **Low** in the Measurements menu, and then push the **OK Add Measurement** side-bezel button.
9. Use the **Multipurpose a** knob to select **High** in the Measurements menu, and then push the **OK Add Measurement** side-bezel button.
10. Push the **Menu Off** button.
11. Record the high and low measurements (for example, low =  $200\text{ mV}$  and high =  $3.52\text{ V}$ ).
12. Repeat the procedure, using  $50\text{ }\Omega$  instead of  $1\text{ M}\Omega$  in step 4.

This completes the performance verification procedure.